Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR GY21852

VEVOR 20V Cordless Leaf Blower (Model GY21852) Instruction Manual

Your guide to safe and efficient operation.

1. Important Safety Instructions

Read all safety warnings and instructions before operating this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

General Safety Warnings:

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents.
- **Electrical Safety:** Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- **Personal Safety:** Always wear eye protection, hearing protection, and appropriate clothing. Do not overreach. Maintain proper footing and balance at all times.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Store idle power tools out of the reach of children.
- **Battery Tool Use and Care:** Recharge only with the charger specified by the manufacturer. Use power tools only with specifically designated battery packs.
- **Service:** Have your power tool serviced by a qualified repair person using only identical replacement parts.

Specific Leaf Blower Safety:

- Never point the blower nozzle at people or pets.
- Do not operate the blower in wet conditions or on wet surfaces.
- Ensure all guards and handles are properly attached before use.
- Keep hands, hair, and loose clothing away from moving parts.
- Always remove the battery pack when cleaning, servicing, or storing the blower.

2. Package Contents

Verify that all items listed below are included in your package. If any parts are missing or damaged, please contact VEVOR customer service.

- 1 x Main Unit (Leaf Blower)
- 1 x Air Tube
- 1 x 20V 2.0Ah Battery Pack
- 1 x Fast Charger
- 1 x User Manual

3. Product Overview

The VEVOR 20V Cordless Leaf Blower is designed for efficient and quiet outdoor cleaning tasks. It features a brushless motor and adjustable speed settings for versatile use.

Key Features:

- **Powerful Brushless Motor:** Delivers up to 450 CFM airflow and 110 MPH airspeed with low noise (62 dB(A)).
- **Adjustable Modes:** Two operating modes with a simple speed control button and a "Turbo" button for varied tasks.
- **Long-Lasting Battery:** Equipped with a 20V 2Ah battery for extended run time and quick charging.
- **Lightweight & Cordless:** Weighs only 5.29 lbs (2.4 kg) for easy one-handed operation and portability.
- **Efficient Cleaning:** Effectively handles leaves, grass clippings, dust, and small gravel.

Product Components:



Image: VEVOR 20V Cordless Leaf Blower main unit, highlighting the brushless motor and axial fan technology, with specifications like 450 CFM, 110 MPH, and 62 dB(A) low noise.



Image: Close-up of the VEVOR leaf blower's handle, showing the "Turbo" button and speed control button for adjustable airflow.

High-Performance Brushless Motor



- Our Brushless Motor
- No frequent maintenance
- Energy-efficient
- Low heat
- Quiet operation
- Powerful airflow



- Other Copper Motor
- Requires regular maintenance
- Runs hot
- High energy consumption
- Loud noise
- Weaker airflow

Image: Diagram comparing VEVOR's brushless motor benefits (no frequent maintenance, energy-efficient, low heat, quiet, powerful airflow) against other copper motors.



Image: VEVOR 20V 2Ah battery and charger, showing charging time (1.2h), run times (14 min high, 4 min turbo), and LED indicator meanings.




Image: A person easily operating the lightweight (5.29 lbs / 2.4 kg) VEVOR cordless leaf blower in a park setting.




Image: Collage demonstrating the VEVOR leaf blower's effectiveness on various debris: leaves, grass clippings, dust, and small gravel.

Product Videos:

▶ **Watch video online**

The VEVOR battery edger has PLENTY of power!

Video: A user demonstrating the VEVOR battery edger, highlighting its power. This video is relevant as it showcases a VEVOR battery-powered tool, implying similar battery performance and power delivery for the leaf blower.

4. Setup

4.1 Assembling the Leaf Blower

1. Align the air tube with the blower's outlet.
2. Push the air tube firmly onto the outlet until it clicks into place or is securely fastened. Ensure it is locked to prevent detachment during operation.

4.2 Charging the Battery

1. Insert the 20V 2.0Ah battery pack into the fast charger.
2. Plug the charger into a standard electrical outlet.
3. The LED indicator on the charger will show the charging status:
    - Flashing Green: Charging
    - Solid Green: Fully Charged
    - Light Red: Standby
    - Flashing Red: Battery Overheat or Charging Error
4. A full charge typically takes approximately 1.2 hours.
5. Once fully charged, remove the battery from the charger.

4.3 Installing the Battery

1. Ensure the leaf blower is turned off.
2. Slide the charged battery pack into the battery slot on the blower until it clicks securely into place.
3. To remove the battery, press the release button and slide the battery out.

5. Operating Instructions

5.1 Starting the Leaf Blower

1. Ensure the battery is fully charged and securely installed.
2. Hold the leaf blower firmly with one hand on the main handle.
3. Press the power button or trigger to start the blower.

5.2 Adjusting Speed Modes

The VEVOR leaf blower offers two operating modes:

- **Standard Speed:** Use the speed control button (typically a dial or lever) to adjust the airflow for general cleaning tasks like sweeping light debris.
- **Turbo Mode:** For maximum power to clear stubborn debris or heavy piles of leaves, press the "Turbo" button. This will provide the highest airflow (450 CFM / 110 MPH). Note that Turbo mode consumes battery power more quickly.

5.3 General Operation Tips

- Start blowing from the outer edges of the area and work your way inward.
- Use a sweeping motion to gather debris into piles.
- Avoid blowing debris towards open windows, cars, or other sensitive areas.
- For optimal battery life, use standard speed for lighter tasks and reserve Turbo mode for heavier debris.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your VEVOR leaf blower.

6.1 Cleaning

- Always remove the battery pack before cleaning.
- Wipe the exterior of the blower with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Clear any debris from the air intake vents and the blower nozzle to ensure proper airflow.

6.2 Storage

- Remove the battery pack from the blower before storage.
- Store the leaf blower and battery pack in a cool, dry place, away from direct sunlight and moisture.
- Keep out of reach of children.
- For long-term storage, it is recommended to store the battery pack partially charged (around 50%) to prolong its lifespan.

6.3 Battery Care

- Do not store battery packs in areas where temperatures may exceed 122°F (50°C).
- Do not expose battery packs to fire or water.
- Dispose of old or damaged battery packs responsibly according to local regulations.

7. Troubleshooting

Problem	Possible Cause	Solution
Blower does not start.	Battery not charged or improperly installed.	Ensure battery is fully charged and correctly inserted until it clicks.
Low airflow or power.	Battery charge is low; air intake/nozzle is blocked.	Recharge battery; clear any obstructions from air vents and nozzle.
Blower stops during operation.	Battery is depleted or overheated.	Recharge battery; allow battery and blower to cool down if overheated.
Unusual noise or vibration.	Loose components or internal damage.	Turn off and remove battery. Inspect for loose parts. If problem persists, contact customer service.

8. Specifications

Feature	Detail
Brand	VEVOR
Model Number	GY21852
Power Source	Battery Powered
Voltage	20 Volts (DC)

Feature	Detail
Airflow (Max)	450 CFM
Airspeed (Max)	110 MPH
Noise Level	62 dB(A)
Battery Capacity	2.0Ah
Charging Time	Approx. 1.2 hours
Run Time (High Mode)	Up to 14 minutes
Run Time (Turbo Mode)	Up to 4 minutes
Item Weight	5.29 Pounds (2.4 kg)
Product Dimensions (L x W x H)	29.92"L x 5.04"W x 9.61"H

9. Warranty and Support

VEVOR products come with a standard warranty. For detailed warranty information, technical support, or to register your product, please visit the official VEVOR website or contact their customer service directly.
Official VEVOR Website: www.vevor.com
Please have your model number (GY21852) and purchase date available when contacting support.

© 2026 VEVOR. All rights reserved. Information is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLK2XM6X

More documents and user manuals: **https://manuals.plus/**