**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**ETURBEV HBIB0003-001**

# ETURBEV Digital Kitchen Scale with Timer

## Instruction Manual for Model HBIB0003-001

### 1. Introduction

Thank you for choosing the ETURBEV Digital Kitchen Scale with Timer. This precision instrument is designed for accurate weighing and timing in various kitchen applications, including coffee brewing and general cooking. Please read this manual thoroughly before use to ensure proper operation and maintenance.

### 2. Product Overview

The ETURBEV Digital Kitchen Scale features a clear LED display, integrated timer, and multiple unit conversion options. It is powered by a rechargeable battery via a Type-C interface.




**Figure 1:** Top view of the ETURBEV Digital Kitchen Scale, showing the LED display and control buttons.

## 3. Setup

### 3.1 Unpacking

Carefully remove the scale and all accessories from the packaging. Ensure the following items are present:

- Digital Kitchen Scale
- Type-C Charging Cable
- Instruction Manual (this document)

### 3.2 Initial Charging

Before first use, fully charge the scale. Connect the provided Type-C charging cable to the scale's charging port and a suitable USB power source. The battery capacity is 250 mAh.

### 3.3 Placement

Place the scale on a flat, stable, and level surface to ensure accurate measurements. Avoid placing it near strong

electromagnetic fields or vibrating equipment.

## 4. Operating Instructions

### 4.1 Power On/Off

- To turn on the scale, press the **POWER/TIMER** button.
- To turn off the scale, press and hold the **POWER/TIMER** button for a few seconds.

### 4.2 Unit Conversion

The scale supports unit conversion between grams (g), ounces (oz), and milliliters (ml).

- Press the **oz/ml/g ZERO** button briefly to cycle through the available units. The selected unit will be displayed on the screen.




**Figure 2:** The LED display is easy to read and shows the selected unit (g, ml, or oz).

### 4.3 Zero/Tare Function

The zero/tare function allows you to reset the display to zero, effectively subtracting the weight of a container or

previous ingredients.

- Place an empty container on the scale.
- Press the **oz/ml/g ZERO** button. The display will show '0.0', indicating the container's weight has been tared.
- Add ingredients to the container; only the weight of the new ingredients will be displayed.

### 4.4 Timer Function

The integrated timer can be used independently or in conjunction with the weighing function.

- To start the timer, press the **POWER/TIMER** button briefly when the scale is on and not in weighing mode.
- Press the **POWER/TIMER** button again to pause/resume the timer.
- To reset the timer, press and hold the **POWER/TIMER** button.

### 4.5 Example Usage: Coffee Brewing Tutorial

This scale is ideal for precise coffee brewing. Follow these steps for a pour-over coffee method:

1. **Preparation:** Place your brewing equipment (e.g., pour-over cone, server) on the scale. Turn on the scale and press the ZERO button to reset the display to 0.0.
2. **Weigh:** Add the required amount of coffee grounds to the filter. The scale will display the weight. Press the ZERO button again to tare the weight of the coffee grounds.
3. **Reckon by time:** Start the timer by pressing the POWER/TIMER button. Begin pouring hot water over the grounds for the initial bloom, typically for about 30 seconds.
4. **Extract:** Continue adding water in stages until the desired total weight is reached and the brewing time is complete. Enjoy your freshly brewed coffee.




**Figure 3:** Step-by-step guide for using the scale to brew coffee.

## 5. Maintenance

### 5.1 Cleaning

The scale features an easy-to-clean surface.

- Wipe the scale surface with a soft, damp cloth.
- Do not immerse the scale in water or use abrasive cleaners.
- Ensure the scale is dry before storage or next use.

### 5.2 Storage

Store the scale in a cool, dry place away from direct sunlight and extreme temperatures. The non-slip bottom ensures stability during use and storage.

### 5.3 Battery Care

To prolong battery life, charge the scale regularly and avoid completely draining the battery frequently.




**Figure 4:** Key features for maintenance and convenience: frosted textured surface, non-slip bottom, easy-to-clean surface, and USB rechargeable.

## 6. Troubleshooting

- **Scale not turning on:** Ensure the battery is charged. Connect the Type-C charging cable and attempt to power on again.
- **Inaccurate readings:** Ensure the scale is placed on a flat, stable surface. Avoid placing it near sources of vibration or drafts. Recalibrate by turning the scale off and on, then re-tare if using a container.
- **Display error:** If an error message appears, try turning the scale off and then on again. If the issue persists, contact customer support.

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Number | HBIB0003-001 |

| Feature | Detail |
|---|---|
| Material | ABS, Aluminium Alloy |
| Weighing Range | 0.1g to 3000g (3kg) |
| Index Value / Precision | 0.1g |
| Units of Measurement | Grams (g), Ounces (oz), Milliliters (ml) |
| Power Supply | Type-C USB Charging |
| Battery Capacity | 250 mAh |
| Display | LED Screen |
| Dimensions | Approximately 0.39 x 0.39 x 0.39 inches (Package Dimensions) |
| Item Weight | Approximately 1.76 ounces (Product Weight) |




**Figure 5:** The scale offers high precision with an index value of 0.1g.

## 8. Warranty and Support

Specific warranty details are not provided within this manual. For warranty information, technical support, or service inquiries, please refer to the product packaging or contact the manufacturer directly through their official channels.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question