Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS ND116

SICOTAS ND116 Rattan Night Stand with 3 Drawers - Assembly and Care Manual

Model: ND116 | Brand: SICOTAS

Introduction | Safety | Package Contents | Assembly | Operation | Maintenance | Specifications | Troubleshooting

1. Introduction

Thank you for choosing the SICOTAS ND116 Rattan Night Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Figure 1: The SICOTAS ND116 Rattan Night Stand in Obsidian, showcasing its design and functionality.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always assemble the night stand according to the provided instructions.
- Ensure all legs are securely attached to prevent tipping.
- Do not overload drawers. Distribute weight evenly to maintain stability.
- Keep small parts and assembly hardware away from children and pets.
- Place the night stand on a flat, stable surface.
- If using an anti-tip kit (not explicitly mentioned but good practice for furniture), ensure it is properly installed to secure the unit to the wall.

3. Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

3.1. Parts List

- Top Panel (1)
- Side Panels (2)
- Back Panel (1)
- Drawer Fronts with Rattan Inset (3)
- Drawer Side Panels (6)
- Drawer Back Panels (3)
- Drawer Bottom Panels (3)
- Legs (4)
- Golden Ring Handles (3)
- Drawer Slides (6 pairs)

3.2. Hardware & Tools

- Screws (various sizes)
- Dowel Pins
- Cam Locks & Cam Bolts
- Allen Wrench (if applicable)
- Installation Tool (included)
- *Recommended: Phillips Head Screwdriver (not included)*



Figure 2: Detailed dimensions of the night stand and its drawers.

4. Assembly Instructions

Follow these steps carefully to assemble your SICOTAS ND116 Rattan Night Stand. It is recommended to have two people for assembly, though one person can manage.

4.1. Frame Assembly

1. Attach the legs to the bottom panel using the provided screws.
2. Connect the side panels to the bottom panel using dowel pins and cam locks.
3. Secure the top panel to the side panels and back panel using cam locks and bolts.
4. Insert the back panel into the grooves on the side and top/bottom panels and secure with small nails or screws.

4.2. Drawer Assembly

1. Attach the drawer slides to the inner sides of the night stand frame. Ensure they are level and aligned.
2. For each drawer, connect the side panels to the front and back panels using dowel pins and cam locks.
3. Slide the drawer bottom panel into the grooves.
4. Attach the golden ring handles to the front of each drawer.
5. Install the remaining drawer slide components to the sides of each assembled drawer.
6. Carefully insert each drawer into its designated slot in the night stand frame.




Figure 3: Various views of the assembled night stand.

▶ **Watch video online**

SICOTAS Terra Rattan Nightstand with 3 Drawers for Bedroom

Video 1: An overview of the SICOTAS Terra Rattan Nightstand, showcasing its features and design. This video provides a general visual of the product.

5. Operating Instructions

The SICOTAS ND116 Night Stand is designed for straightforward use.

- **Drawer Use:** Gently pull the golden ring handles to open the drawers. Push firmly to close. Avoid slamming drawers to ensure longevity of the slides.
- **Weight Capacity:** The top surface is suitable for lamps, alarm clocks, and small decorative items. Each drawer is designed to hold typical bedside essentials. Do not exceed the recommended weight capacity to prevent damage.



Figure 4: Illustrates the spaciousness of the three drawers.

6. Maintenance

Proper care will extend the life and appearance of your night stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish and rattan.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and

rattan.

- **Hardware:** Periodically check and tighten any loose screws or hardware to maintain stability.

7. Specifications

Feature	Detail
Brand	SICOTAS
Model Number	ND116
Product Dimensions (D x W x H)	15.5"D x 26.78"W x 25.67"H
Item Weight	45 Pounds
Frame Material	Engineered Wood
Handle Material	Metal
Color	Obsidian
Number of Drawers	3
Assembly Required	Yes
Included Components	Installation Tool

8. Troubleshooting

Here are solutions to common issues you might encounter:

- **Wobbly Night Stand:** Ensure all screws and cam locks are fully tightened. Check that the night stand is on a level surface. Adjust leg levelers if present.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned on both the drawer and the frame. Ensure no debris is obstructing the tracks.
- **Missing Parts:** If any parts are missing upon unboxing, refer to the package contents list and contact SICOTAS customer support for replacements.
- **Damaged Parts:** If any components are damaged during shipping or assembly, do not proceed with assembly. Contact customer support immediately.

9. Warranty & Support

For warranty information, product support, or to order replacement parts, please visit the official SICOTAS store or contact their customer service directly.
Visit the SICOTAS Store on Amazon for more products and support.

© 2026 SICOTAS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMJZGDZ8

More documents and user manuals: **https://manuals.plus/**