Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy HZJL718BKN

Sweetcrispy Home Office Managerial Executive Chair User Manual

Model: HZJL718BKN

Introduction

Thank you for choosing the Sweetcrispy Home Office Managerial Executive Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your chair. Please read this manual thoroughly before assembly and use, and retain it for future reference.



Image: The Sweetcrispy Home Office Managerial Executive Chair in a home office setting.

Safety Information

- **Maximum Weight Capacity:** The chair is designed to support a maximum weight of 250 lbs (113 kg). Exceeding this limit may cause damage to the chair or lead to injury.
- **Regular Cleaning:** Clean the chair regularly to maintain hygiene and ensure safe operation.
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Periodically check all screws and bolts to ensure they remain secure.
- **Usage:** Use the chair on a flat, stable surface. Avoid standing on the chair or using it as a step stool.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play on or around the chair unsupervised.

Package Contents

Before beginning assembly, please verify that all components are present and undamaged. If any parts are

missing or damaged, please contact customer support.

- Chair components (backrest, seat, armrests, base, casters, gas lift)
- Assembly Tool (Allen wrench)
- User Manual

Assembly Instructions

Assembly typically takes 10-15 minutes. Follow these steps carefully:

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.



Image: Close-up of the chair base with casters.

2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled chair base.



Image: The gas lift cylinder.

3. **Attach Mechanism to Seat:** Secure the control mechanism to the underside of the seat cushion using the provided screws and Allen wrench. Ensure the front of the mechanism aligns with the front of the seat.
4. **Attach Armrests:** Fasten the armrests to the seat cushion using the designated screws. Ensure they are securely tightened.
5. **Attach Backrest:** Connect the backrest to the seat assembly using the remaining screws. Ensure all connections are firm.
6. **Place Seat Assembly onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.

After assembly, sit on the chair to engage the gas lift and ensure all components are properly seated.

Operating Instructions

Your Sweetcrispy chair features several adjustable functions for personalized comfort:

- **Seat Height Adjustment:** To adjust the seat height, pull the lever located under the right side of the seat upwards. While pulling the lever, lift your body weight off the seat to raise it, or remain seated to lower it. Release the lever at the desired height. The adjustment range is 18.5 to 22.2 inches.
- **Rocking Function:** The chair features a 90-120 degree rocking mode. To activate the rocking function, pull the same lever (used for height adjustment) outwards. Push it inwards to lock the chair in an upright

position.

- **Rocking Tension Adjustment:** The round knob located under the front of the seat controls the rocking tension. Turn the knob clockwise to increase tension (making it harder to rock) or counter-clockwise to decrease tension (making it easier to rock).
- **360° Swivel:** The chair seat can rotate 360 degrees for flexible movement.



Image: Illustration of rocking tension adjustment and height adjustment lever.



Image: Visual representation of the chair's 360-degree swivel function.

Maintenance

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the mesh and fabric.
- **Inspection:** Periodically inspect all bolts and screws to ensure they are tight. Re-tighten if necessary to prevent loosening and ensure stability.
- **Caster Care:** Keep casters free of hair and debris to ensure smooth movement.

Troubleshooting

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift not engaged or faulty.	Ensure the lever is pulled correctly. If the issue persists, the gas lift may need replacement.
Chair wobbles or is unstable	Loose screws or uneven assembly.	Check and tighten all assembly screws. Ensure the chair is on a flat surface.

Problem	Possible Cause	Solution
Casters do not roll smoothly	Debris in casters or damaged casters.	Clean any hair or debris from the caster wheels. If damaged, casters may need replacement.
Rocking function is too stiff or too loose	Rocking tension knob not adjusted.	Adjust the rocking tension knob under the seat to your preference.

Specifications

- **Brand:** Sweetcrispy
- **Model Name:** Home Office Managerial Executive Chair
- **Model Number:** HZJL718BKN
- **Color:** Black
- **Product Dimensions:** 18.5"D x 20.08"W x 41.4"H
- **Seat Depth:** 18.5 inches
- **Chair Backrest Width:** 18.5 Inches
- **Back Style:** Mesh Back
- **Special Features:** Arm Rest, Ergonomic, Rolling, Swivel
- **Maximum Weight Recommendation:** 250 Pounds
- **Material:** Foam + Fabric (Seat), Mesh (Back)
- **Item Weight:** 21.4 pounds
- **UPC:** 734383819729

PRODUCT DIMENSION

Weight capacity: 250lbs



Image: Front view of the chair with key dimensions labeled.



Image: Side view of the chair with key dimensions labeled.

Warranty and Support

Sweetcrispy products are designed for quality and durability. For specific warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Sweetcrispy website. Please have your model number (HZJL718BKN) and purchase date available when contacting support.
For further assistance, you may contact Sweetcrispy customer service through their official channels.

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMR5S5TS

More documents and user manuals: **https://manuals.plus/**