Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH MR-2510

MERACH Ab Machine Instruction Manual

Model: MR-2510
Brand: MERACH

1. Introduction

Thank you for choosing the MERACH Ab Machine. This equipment is designed to provide an effective and comprehensive workout for your core, waist, and abdominal muscles. Please read this manual carefully before assembly and use to ensure safe and optimal performance. Keep this manual for future reference.

Important Safety Information

- Consult a physician before starting any new exercise program.
- Always warm up before exercising and cool down afterwards.
- Ensure all parts are securely assembled before each use.
- Do not exceed the maximum weight capacity of 440 lbs (200 kg).
- Keep children and pets away from the equipment during use.
- Use the machine on a flat, stable surface.
- Stop exercising immediately if you feel pain, dizziness, or nausea.

2. Included Components

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact MERACH customer support.

- AB Machine x 1
- User Manual x 1
- Assembly Tools (if applicable)

3. Setup and Assembly

Assembly of the MERACH Ab Machine is designed to be straightforward. Follow the steps below, referring to the diagrams for visual guidance.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Assemble Base Frame:** Connect the main frame components as per the provided diagrams. Ensure all bolts and

nuts are tightened securely.

3. **Attach Handlebars and Knee Pads:** Secure the ergonomic handlebars and extra-wide foam knee pads to their designated positions. These are crucial for comfort and support during your workout.
4. **Install LCD Monitor:** Attach the LCD monitor to the handlebar assembly. Ensure the sensor cable is properly connected for accurate data tracking.
5. **Final Check:** Before first use, double-check all connections and moving parts to ensure they are secure and functioning correctly.



Figure 3.1: Fully assembled MERACH Ab Machine.

4. Operating Instructions

The MERACH Ab Machine offers a versatile workout experience. Follow these guidelines for effective and safe operation.

4.1 Multi-Function Ab Training

This machine is designed to target your waist, abs, and core simultaneously. By engaging various muscle groups, it helps sculpt your waistline and strengthen your abdominal muscles.



Figure 4.1: The MERACH Ab Machine targets multiple body parts for a comprehensive workout.

4.2 Upgraded Split-Track Design

The independent dual tracks allow for alternating leg movements, simulating a mountain climbing motion. This design intensifies your core workout by engaging muscles more dynamically.



Figure 4.2: Independent dual tracks for dynamic leg movements.

4.3 Ergonomic 110° Curved Track

The 110° curved track is engineered to align with your body's natural movement, providing a smoother and more comfortable range of motion. The extended track length (50% longer) allows for deeper and more effective abdominal contractions.



Figure 4.3: The 110° curved track ensures ergonomic movement.

4.4 4-Level Height Adjustment

Adjust the intensity of your workout by selecting one of the four available height settings. Lowering the height makes the exercise easier, while increasing it provides a more challenging workout, suitable for all fitness levels from beginner to advanced.



Figure 4.4: Adjusting the machine's height for varied intensity.

4.5 Real-Time Workout Feedback (LCD Screen)

The built-in LCD screen provides essential workout data, including reps, time, and calories burned. This allows you to monitor your progress and stay on track with your fitness goals.



Figure 4.5: LCD screen displaying workout data.

4.6 Proper Form and Usage

- Place your knees on the foam pads and grip the handlebars firmly.
- Engage your core as you slide your knees upwards along the track.
- Maintain a controlled movement throughout the exercise, avoiding jerky motions.
- Breathe deeply and consistently during your workout.

5. Maintenance

Regular maintenance will ensure the longevity and optimal performance of your MERACH Ab Machine.

- **Cleaning:** Wipe down the machine with a damp cloth after each use to remove sweat and dust. Avoid abrasive cleaners.
- **Storage:** The machine is foldable for convenient storage. To fold, follow the instructions in the assembly section in reverse or refer to the quick-fold mechanism. Store in a dry place away from direct sunlight.

- **Inspection:** Periodically check all bolts, nuts, and moving parts for tightness and wear. Tighten any loose fasteners and replace worn components if necessary.



Figure 5.1: The MERACH Ab Machine can be folded for compact storage.

6. Troubleshooting

If you encounter any issues with your MERACH Ab Machine, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
LCD screen not displaying data.	Loose sensor connection or dead battery.	Check the sensor cable connection. Replace the battery in the LCD monitor.
Machine feels unstable or wobbly.	Loose assembly bolts or uneven surface.	Ensure all assembly bolts are tightened. Move the machine to a flat, level surface.

Problem	Possible Cause	Solution
Movement is not smooth.	Debris on tracks or worn components.	Clean the tracks thoroughly. Inspect for any damaged or worn parts and contact support if necessary.

If the problem persists after attempting these solutions, please contact MERACH customer support for further assistance.

7. Specifications

Feature	Detail
Brand	MERACH
Model Name	MR-2510
Color	Black
Material	Alloy Steel
Item Weight	24 Pounds (approx. 10.9 kg)
Maximum Weight Recommendation	440 Pounds (approx. 200 kg)
Dimensions (L x W x H)	38.18 x 16.36 x 7.8 inches (packaged)
Adjustments	4-Level Height Adjustment
Display	LCD (Reps, Time, Calories)

8. Warranty and Support

MERACH stands behind the quality of its products.

- **Warranty:** This MERACH Ab Machine comes with a 12-month warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please contact MERACH customer service. Refer to the contact information provided with your purchase or visit the official MERACH website.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMYGM69V

More documents and user manuals: **https://manuals.plus/**