**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Hatteker HT-596**

# Hatteker HT-596 4-in-1 Women's Electric Razor User Manual

Model: HT-596

## 1. Product Overview

The Hatteker HT-596 is a versatile 4-in-1 electric razor designed for comprehensive body and facial hair removal. This device features interchangeable heads for various grooming needs, including a body trimmer, precision shaver, nose trimmer, and facial hair remover. It is IPX7 waterproof, allowing for both wet and dry use, and is conveniently rechargeable via USB with an LED battery display.




*Image 1.1: The Hatteker HT-596 electric razor showcasing its main unit and four interchangeable heads for different grooming areas.*

## 2. Safety Information

**Please read all safety instructions carefully before using the device.**

- Always unplug and turn off the razor before use. Do not use while charging.
- Keep blades away from children.
- After use, clean and dry all parts thoroughly to prevent bacterial growth.
- Be cautious when using near water. Although the razor is waterproof, electrical hazards may still occur if not handled properly.
- Always replace the protective cap after use to prevent accidental activation.

## 3. What's in the Box

Your Hatteker HT-596 package includes the following components:

- Electric Trimmer Main Unit
- Body Shaver Head
- Nose Trimmer Head
- Facial Trimmer Head (Rotary Shaver)
- Guide Combs (various sizes)
- USB Charging Cable
- Storage Bag
- Cleaning Brush




*Image 3.1: All components included in the Hatteker HT-596 electric razor kit.*

## 4. Setup and Charging

### 4.1 Initial Charge

Before first use, fully charge the device. Connect the USB charging cable to the razor and plug the other end into a compatible USB power source (e.g., adapter, power bank, laptop, car charger).

### 4.2 Charging Indicator

The built-in LED screen will display the battery level in real-time during charging and use. A full charge typically takes approximately 90 minutes and provides up to 60 minutes of cordless runtime.




*Image 4.1: The Hatteker HT-596 electric razor connected to a USB-C charging cable, highlighting its charging time and battery life.*

## 5. Operating Instructions

### 5.1 Attaching/Detaching Heads

To attach a head, align it with the main unit and gently push until it clicks into place. To detach, twist or pull the head off, depending on the specific head design, as indicated in the maintenance section.

### 5.2 Power On/Off

Press the power button on the main unit to turn the device on or off.

### 5.3 Using the Body Trimmer Head

This wide head is designed for efficient hair removal on larger areas like legs, arms, and armpits. For best results, move the trimmer against the direction of hair growth. You can use guide combs for desired hair length.

### 5.4 Using the Precision Floating Cutting Net Head (Body Shaver)

After trimming longer hairs with the body trimmer, use this head for a close, smooth shave without leaving 'black spots'. Glide the shaver gently over the skin. The dual-head system (trim + shave) helps prevent tangling and ensures a cleaner result.



*Image 5.1: Detailed view of the dual-head design of the Hatteker HT-596, illustrating the body trimmer and the precision floating cutting net for efficient and close shaving.*

### 5.5 Using the Nose Trimmer Head

Gently insert the nose trimmer into your nostril or ear canal. Move it in a circular motion to trim unwanted hair. Do not insert too deeply.

### 5.6 Using the Facial Trimmer Head (Rotary Shaver)

This head is ideal for delicate areas like the face, upper lip, chin, and eyebrows. Gently press the shaver against the skin and move it in small circular motions for precise hair removal.




*Image 5.2: The Hatteker HT-596 electric razor being used on different parts of the body and face, demonstrating its versatility.*

### 5.7 Official Product Video: Bikini Shaver Demonstration

▶ **Watch video online**
Unmatched Precision! The Perfect Bikini Shaver

*Video 5.1: A demonstration of the Hatteker HT-596 electric razor's precision for bikini area grooming, highlighting its effectiveness and ease of use.*

## 6. Wet/Dry Versatility

The Hatteker HT-596 is IPX7 waterproof, making it suitable for both wet and dry use. You can use it in the shower with shaving foam or gel for a more comfortable experience, or use it dry for quick touch-ups. Always ensure the device is fully charged before wet use.




*Image 6.1: The Hatteker HT-596 electric razor demonstrating its IPX7 waterproof capability for both wet (in shower) and dry use.*

## 7. Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene.

1. **Turn Off and Unplug:** Always ensure the device is turned off and unplugged from any charging source before cleaning.
2. **Detach Heads:** Carefully detach the used shaving head from the main unit.
3. **Rinse:** All detachable heads can be rinsed directly under running water. For the body trimmer, you may need to open the blade assembly to rinse thoroughly.
4. **Brush:** Use the included cleaning brush to remove any trapped hairs from the blades and inside the head.
5. **Dry:** Allow all parts to air dry completely before reattaching them to the main unit or storing the device.




*Image 7.1: A visual step-by-step guide demonstrating how to detach, clean, and maintain the various heads of the Hatteker HT-596 electric razor.*

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Device does not turn on | Battery is depleted | Charge the device fully (approx. 90 minutes). |
| Poor shaving/trimming performance | Blades are dull or clogged with hair | Clean the shaving head thoroughly. If performance does not improve, consider replacing the head. |
| Device stops during use | Battery is low | Recharge the device. Monitor the LED battery display. |
| Skin irritation after use | Improper technique, dry shaving sensitive skin, or dirty blades | Ensure skin is clean. Try wet shaving with foam/gel. Clean blades before each use. Glide gently, do not press too hard. |

## 9. Specifications

| Feature | Detail |
|---|---|

| Feature | Detail |
|---|---|
| Model Name | HT-596 |
| Power Source | Battery Powered (Rechargeable Lithium-Ion) |
| Battery Average Life | 60 minutes |
| Charging Time | Approx. 90 minutes |
| Waterproof Rating | IPX7 (Full-body washable) |
| Head Type | Foil, Pivoting |
| Blade Material | Stainless Steel |
| Included Components | Electric trimmer, nose trimmer, facial trimmer, body shaver, guide combs, charging cable, storage bag, cleaning brush |

## 10. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Hatteker website. Keep your proof of purchase for any warranty claims.

© 2023 Hatteker. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0FN7NKH71**

More documents and user manuals: **https://manuals.plus/**