Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy HJ2L7261LEABN

Sweetcrispy Criss Cross Armless Office Swivel Desk Chair

Model: HJ2L7261LEABN

1. Important Safety Information

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may damage the components.
- Keep small parts away from children.
- This chair is designed for indoor use only.
- Maximum weight capacity: 300 lbs (136 kg). Do not exceed this limit.
- Regularly check all bolts and screws to ensure they remain tight.

2. Package Contents

Verify that all the following components are included in your package:

- Seat Cushion with Backrest (1)
- Base (1)
- Gas Lift Cylinder (1)
- Gas Lift Cover (1)
- Assembly Tool (1)
- Screws and Washers (various sizes, refer to assembly diagram)

3. Setup and Assembly Instructions

Follow these steps to assemble your Sweetcrispy Criss Cross Chair.

1. **Attach the Base to the Gas Lift:** Insert the gas lift cylinder into the center hole of the chair base. Place the gas lift cover over the gas lift cylinder.

2. **Connect Seat to Gas Lift:** Carefully align the central mechanism on the underside of the seat cushion with the top of the gas lift cylinder. Press down firmly until the seat is securely seated on the gas lift.
3. **Secure Backrest (if separate):** If the backrest is separate from the seat, attach it using the provided screws and assembly tool. Ensure all screws are tightened evenly.



Image 3.1: Fully assembled Sweetcrispy Criss Cross Chair in a home office setting. The chair features a brown faux leather finish, a wide seat, and a sturdy black cross-legged base without wheels.



Image 3.2: Detailed view of chair components including the metal connection for height adjustment, the metal bracket base with 300 lbs load capacity, and the handle button for adjustments. This image illustrates the robust construction and key functional parts.

4. Operating Instructions

Your Sweetcrispy chair offers several adjustable features for personalized comfort.

4.1. Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at the desired height to lock it in place.

4.2. 360° Swivel Function

The chair seat is designed to swivel a full 360 degrees, allowing for easy movement and access to different areas without needing to reposition the entire chair.

4.3. Tilt Function and Rocking Mode

The chair features a tilt mechanism allowing for up to 21° of recline. To activate or adjust the rocking mode, locate the round knob beneath the seat. Turn the knob clockwise to increase tension (making it harder to recline) or counter-clockwise to decrease tension (allowing for easier recline). The lever used for height adjustment may also control the tilt lock/unlock function; push it inwards to lock the tilt and pull it outwards to unlock.



Image 4.1: Illustration of the chair's rocking mode, showing a 21-degree tilt capability controlled by a rocking function knob. The image also displays various usage scenarios such as working, reading, gaming, and relaxing in a living room or bedroom.



Image 4.2: Visual representation of the chair's key features: height adjustment mechanism, 360-degree swivel capability, and the sturdy cross metal base with anti-slip and anti-scratch bottom pads, highlighting its stability and functionality.

5. Maintenance

Proper care will extend the life and appearance of your chair.

- **Cleaning:** Wipe clean with a damp cloth. For faux leather, use a mild soap solution if necessary, then wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten as needed.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack.
- **Weight Limit:** Do not exceed the stated weight capacity of 300 lbs.

6. Troubleshooting

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Chair wobbles or feels unstable	Loose screws or uneven assembly.	Check and tighten all screws. Ensure the chair is on a flat, even surface.
Height adjustment not working	Gas lift cylinder not properly engaged or damaged.	Ensure the gas lift is fully inserted into the base and seat mechanism. If still not working, contact customer support.
Chair does not tilt or recline	Tilt tension knob is too tight or tilt lock is engaged.	Loosen the tilt tension knob (counter-clockwise). Ensure the tilt lock lever is disengaged (pulled outwards).
Squeaking noises	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if necessary.

7. Specifications

Detailed specifications for the Sweetcrispy Criss Cross Armless Office Swivel Desk Chair:

Brand: Sweetcrispy

Model Name: HJ2L7261LEABN

Color: Brown

Product Dimensions: 26.4"D x 26"W x 32.5"H

Seat Dimensions: Approximately 25.98"W x 19.68"D

Adjustable Seat Height: 14.96" to 18.70" from floor

Back Style: Solid Back

Special Features: Adjustable Height, Ergonomic Design, 360° Swivel, 21° Tilt Function

Product Care Instructions: Wipe Clean

Maximum Weight Capacity: 300 lbs

Material: Faux Leather upholstery, High-density sponge filling, Metal base

Assembly Required: Yes

Item Weight: 27.6 pounds



Image 7.1: Detailed diagram illustrating the product dimensions, including overall width (24.40"), seat width (25.98"), backrest height (13.98"), seat depth (19.68"), and adjustable seat height range (14.96" to 18.70"). The diagram also confirms a load capacity of 300 lbs.



Image 7.2: Visual summary of chair features including overall chair size, height adjustment mechanism, 360-degree swivel, and adjustable chair back angle, providing a comprehensive overview of its adaptable design.

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Sweetcrispy customer service directly. Keep your purchase receipt as proof of purchase.
For additional assistance, visit the official Sweetcrispy store or contact their support channels.

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNC6FMMJ

More documents and user manuals: **https://manuals.plus/**