**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Einhomn EI822A2

# Einhomn 63-inch Extendable Dining Table Set (Walnut) - User Manual

Model: EI822A2

### Introduction

Thank you for choosing the Einhomn 63-inch Extendable Dining Table Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new dining set. Please read these instructions carefully before beginning assembly and retain them for future reference.

### Safety Information

**WARNING:** Assembly required - follow instructions carefully to ensure stability. Do not exceed weight capacity. Use caution around corners and edges during assembly and use. Ensure table is fully extended and locked before use. Keep children supervised during assembly due to small parts and hardware. Place on level surface to prevent tipping.
The table is designed with corner protectors to minimize collision risks. Always ensure the table is placed on a stable, level surface.



Image: Clear plastic corner protector installed on the table edge, highlighting the safety feature.

### Package Contents

Before assembly, please verify that all components listed below are present and undamaged:

- 1 x Extendable Dining Table
- 6 x Square Stools
- Complete Assembled Hardware (screws, bolts, etc.)
- Detailed Assembly Instructions

## Specifications

| Feature | Detail |
| --- | --- |
| Color | Walnut |
| Material | MDF Board, Metal Frame |
| Table Dimensions (Shrunk) | 47.3 inches (L) x 28 inches (W) x 30 inches (H) |
| Table Dimensions (Expanded) | 63 inches (L) x 28 inches (W) x 30 inches (H) |
| Stool Dimensions | 16 inches (L) x 12 inches (W) x 18 inches (H) |
| Table Weight Capacity | 330 lbs |
| Stool Weight Capacity | 550 lbs |
| Assembly Tools | Included |
| Style | 7-Piece (6 Stools) |
| Model Number | EI822A2 |




Image: Detailed specifications diagram for the Einhomn dining table and stools, including dimensions and weight limits.

## Setup and Assembly

The Einhomn dining table set is designed for effortless assembly. All necessary hardware and detailed, step-by-step instructions are included in the package. Please follow the provided instructions carefully to ensure proper construction and stability.

1. Unpack all components and verify against the package contents list.
2. Identify all hardware and tools. A double-sided ratcheting Allen wrench is provided for convenience.
3. Assemble the table frame first, ensuring all screws are tightened securely but do not overtighten until all parts are aligned.
4. Attach the tabletop sections to the assembled frame.
5. Assemble each stool following the individual instructions.
6. Once fully assembled, place the table on a level surface and check for stability.



Image: Illustration demonstrating the ease of assembly with an included tool.

Image: Close-up of an anti-slip pad on a table leg, designed to protect floors and enhance stability.

## Operating Instructions: Extending and Shrinking the Table

The Einhomn dining table features a flexible, space-saving design that allows it to easily adjust from seating 4 to 6 persons. Follow these steps to extend or shrink your table:

1. **To Extend:**
    - Locate the latch mechanism on the underside of the table. Press the latch to unlock the tabletop sections.
    - Gently pull the two main tabletop sections apart. The telescopic steel rails will guide the movement.
    - Pull out the hidden tabletop leaf from the center.
    - Push the main tabletop sections back together until they meet the extended leaf, ensuring a zero-gap surface.
    - Lock the safety latch to secure the table in its extended position.
2. **To Shrink:**
    - Unlock the safety latch.
    - Gently pull the main tabletop sections apart to create space.
    - Push the center leaf back into its storage position under the table.
    - Slide the main tabletop sections back together until they meet, ensuring a zero-gap surface.
    - Lock the safety latch to secure the table in its compact position.




Image: Visual guide illustrating the 4-step process for extending the dining table.



Image: Close-up of the smooth and durable telescopic steel rails that facilitate table extension.




Image: Illustration of the table's space-saving design, showing how stools can be stored compactly under the table.

▶ **Watch video online**

5 Pieces Extendable Dining Room Table Set for 4-6

Video: Demonstration of the Einhomn dining table's extendable feature and compact storage for stools.

## Maintenance

To ensure the longevity and appearance of your Einhomn dining table set, follow these maintenance guidelines:

- **Cleaning:** The tabletop features an easy-to-clean surface. Wipe spills immediately with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that can damage the finish.
- **Dusting:** Regularly dust the table and stools with a soft, dry cloth.
- **Protection:** Use placemats and coasters to protect the tabletop from heat, moisture, and scratches.
- **Zero-Gap Board:** The zero-gap design of the tabletop ensures a continuous, smooth surface, making it easier to clean and maintain hygiene.
- **Hardware:** Periodically check and tighten all screws and bolts to maintain structural integrity.




Image: Close-up showing water droplets on the tabletop, illustrating its easy-to-clean surface.




Image: Detail of the zero-gap board design, ensuring a smooth and continuous tabletop surface.

## TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---|---|---|
| Table is wobbly or unstable. | Loose hardware; uneven floor. | Ensure all screws and bolts are securely tightened. Place the table on a level surface. Adjust anti-slip pads if necessary. |
| Tabletop does not slide smoothly or lock properly. | Obstruction in rails; damaged sliding mechanism. | Check for any debris in the telescopic steel rails. Ensure the latch mechanism is fully engaged/disengaged. If a component is damaged, contact customer support. |
| Rubber corner protectors do not stick. | Insufficient adhesive; surface not clean. | Clean the table corners thoroughly before applying. If they still do not adhere, consider using a stronger adhesive or alternative fastening methods (e.g., small screws if appropriate for your table and not damaging). |

| Problem | Possible Cause | Solution |
|---|---|---|
| Edges feel sharp. | Manufacturing variation; corner protectors not installed. | Ensure all provided corner protectors are correctly installed. If edges remain sharp, contact customer support for assistance. |

## Warranty and Support

For any questions, concerns, or to report missing or damaged parts, please contact Einhomn customer support. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the retailer's website for warranty information. Always provide your model number (EI822A2) and purchase date when contacting support.
You can visit the Einhomn Store for more information: Einhomn Store on Amazon

© 2026 Einhomn. All rights reserved.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B0FNLDXCCN**

More documents and user manuals: **https://manuals.plus/**