Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR HS-20

VEVOR HS-20 Electric Hot Foam Cutter User Manual

Model: HS-20 | Brand: VEVOR

1. Introduction

This manual provides comprehensive instructions for the safe and efficient operation, setup, and maintenance of your VEVOR HS-20 Electric Hot Foam Cutter. This 200W tool is designed for precise cutting of various materials such as foam, polyethylene, sponge, and rubber, offering adjustable temperature control from 50°C to 500°C. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The VEVOR HS-20 Electric Hot Foam Cutter in operation, highlighting its rapid heating capability and 200W maximum power for efficient cutting.

2. Safety Instructions

WARNING: Failure to follow these safety instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including heat-resistant gloves and eye protection, when operating the hot foam cutter.
- Ensure the work area is well-ventilated to avoid inhaling fumes produced during cutting.
- Do not touch the blade or blade holder when the tool is powered on or immediately after use, as they will be extremely hot. Allow sufficient time for cooling.
- **Do not operate the tool continuously for more than 5 minutes.**Allow the tool to cool down for at least 10 minutes after 5 minutes of continuous use to prevent overheating and damage.
- Keep the power cord away from heat, oil, sharp edges, and moving parts.
- Never use the tool near flammable liquids, gases, or dust.
- Unplug the tool from the power source before changing blades, cleaning, or performing any maintenance.
- Store the tool in a dry, secure place out of reach of children.

3. Package Contents

Verify that all items are present and undamaged upon unpacking:

- 1 x VEVOR HS-20 Electric Hot Foam Cutter
- 2 x 6-inch (150 mm) Straight Blades
- 2 x 8-inch (200 mm) Straight Blades
- 2 x Cleaning Brushes
- 1 x Wrench
- 1 x Tool Case



Image 3.1: All components included in the VEVOR HS-20 Electric Hot Foam Cutter kit, neatly arranged with the tool, various blades, cleaning brushes, wrench, and storage case.

4. Setup

1. **Blade Installation:**

   Ensure the tool is unplugged. Select the appropriate blade (150mm or 200mm) for your task. Loosen the screws on the copper blade holder using the provided wrench. Insert the blade fully into the slots of the blade holder. Tighten the screws securely to ensure the blade is firmly held in place. Do not overtighten.

2. **Tool Overview:**

   Familiarize yourself with the tool's components, including the insulated housing, copper blade holder, heat dissipation vents, temperature adjustment knob, micro trigger switch, and metal hook.



Image 4.1: A detailed diagram of the VEVOR HS-20 Electric Hot Foam Cutter, pointing out its key components for user-friendly operation.

3. **Power Connection:**

   Connect the power cord to a standard electrical outlet. Ensure the voltage matches the tool's requirements (220-240V for EU models, check product label for specifics).

5. Operating Instructions

1. **Power On and Temperature Adjustment:**

   Plug in the tool. The tool features a micro trigger switch for activation. Press and hold the trigger to begin heating. Use the temperature adjustment knob located on the side of the handle to set the desired temperature between 50°C and 500°C. Start with a lower temperature and gradually increase it as needed for your material.



Image 5.1: The VEVOR HS-20 Electric Hot Foam Cutter illustrating its variable temperature control knob, allowing precise adjustment from 50°C to 500°C.

2. **Cutting Technique:**

   Allow the blade to heat up for a few seconds until it reaches the desired temperature. Gently press the hot blade into the material. Apply steady, even pressure to guide the blade through the material. Avoid forcing the blade, as this can lead to uneven cuts or damage to the tool. For best results, maintain a consistent cutting speed.



Image 5.2: A user demonstrating the cutting process with the VEVOR HS-20, showing how to achieve smooth, precise cuts on foam material.

3. **Material Compatibility:**

   This tool is suitable for cutting a wide range of materials including foam, corrugated cardboard, polyethylene, sponge, and rubber. Test on a scrap piece of material first to determine the optimal temperature and cutting speed.



Image 5.3: The VEVOR HS-20 Electric Hot Foam Cutter demonstrating its versatility by cutting different materials such as foam, KT board, polyethylene, rubber, and sponge.

4. **Lightweight Design:**

   The ergonomic and lightweight design of the VEVOR HS-20 reduces hand fatigue during extended use, making it comfortable for various cutting tasks.



Image 5.4: A user holding the VEVOR HS-20 Electric Hot Foam Cutter, illustrating its lightweight design that helps reduce hand fatigue during prolonged use.

5. **Cooling Down:**

   Release the trigger to turn off the heating element. Allow the blade to cool completely before storing the tool or changing blades. The integrated heat dissipation vents help in cooling.

6. Maintenance

- **Cleaning the Blade:**

  After the blade has cooled, use the provided cleaning brush to remove any melted material residue. Do not use abrasive cleaners or solvents. For stubborn residue, gently scrape with a non-metallic tool.

- **Storage:**

  Store the hot foam cutter and its accessories in the provided tool case in a dry, clean environment. Ensure the power cord is neatly coiled and not kinked.

- **Blade Replacement:**

  Replace blades when they become dull or damaged. Follow the blade installation steps in Section 4. Always use genuine VEVOR replacement blades.

7. Troubleshooting

Problem	Possible Cause	Solution
Tool does not heat up.	Not plugged in; power outlet fault; trigger not pressed; faulty blade connection.	Check power connection; test outlet; ensure trigger is fully pressed; verify blade is securely installed.
Poor cutting performance.	Blade not hot enough; incorrect temperature setting; dull or dirty blade; cutting too fast.	Increase temperature; clean or replace blade; reduce cutting speed.

Problem	Possible Cause	Solution
Tool overheats quickly.	Continuous operation for too long.	Allow the tool to cool down for at least 10 minutes after 5 minutes of continuous use.

8. Specifications

Feature	Detail
Model Number	HS-20
Rated Power	200 W
Working Temperature	50°C - 500°C (122°F - 932°F)
Blade Material	Nickel-Chromium Alloy
Blade Holder Material	Copper
Included Blades	2 x 150 mm (6-inch), 2 x 200 mm (8-inch)
Net Weight	1.15 kg (2.54 lbs)
Product Dimensions (L x W x H)	240 x 130 x 35 mm (9.45 x 5.12 x 1.38 inches)
Power Cord Length	3 m (9.84 ft)
UPC	197988886785



Image 8.1: Detailed technical drawing of the VEVOR HS-20 Electric Hot Foam Cutter, showing its dimensions and key specifications.

9. Contact and Support

For technical assistance, warranty information, or replacement parts, please contact VEVOR customer support through their official website or the retailer where the product was purchased. Please have your model number (HS-20) and UPC (197988886785) ready when contacting support.
For more information, visit the official VEVOR store:VEVOR Store

© 2023 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNQVY163

More documents and user manuals: **https://manuals.plus/**