Cearvol Nano

Cearvol Nano Sound Amplifier Instruction Manual

Model: Nano | Brand: Cearvol

Introduction

Welcome to your Cearvol Nano Sound Amplifier. This device is designed to enhance your hearing experience with advanced audio processing, reducing background noise and focusing on vocal clarity. Its compact, discreet design and intuitive controls make it suitable for daily use. Please read this manual carefully to ensure proper use and maintenance of your device.

What's in the Box

Your Cearvol Nano Sound Amplifier package includes the following components:

- 1x Cearvol Nano Sound Amplifier (Left/Right pair)
- 1x Charging Case
- 1x Type-C Charging Cable
- 3x Pairs of Ear Tips (Sizes: Small, Medium, Large)
- 1x Cleaning Brush
- 1x User Manual
- 1x Quick Start Guide

Image: An organized layout of all components included in the Cearvol Nano Sound Amplifier package: charging case, ear tips, cleaning brush, L/R amplifiers, Type-C cable, user manual, and quick start guide.

Setup

1. Initial Charging

Before first use, ensure both the charging case and the sound amplifiers are fully charged. Connect the provided Type-C charging cable to the charging case and then to a suitable power source (e.g., a USB wall adapter or computer USB port). The indicator lights on the case will show the charging status. A full charge typically takes approximately 2 hours.

2. Fitting the Amplifiers

Select the appropriate ear tip size (Small, Medium, or Large) that provides a comfortable and secure fit in your ear canal. A good seal is crucial for optimal sound quality and to prevent feedback. Gently insert the amplifier into your ear canal until it feels snug and stable. Ensure the amplifier is correctly oriented, with the microphone facing outwards.

Image: An elderly man wearing a Cearvol Nano amplifier in his ear, with an inset showing a close-up of the small, discreet amplifier held between fingers, highlighting its compact design.

Operating Instructions

1. Power On/Off

The Cearvol Nano Sound Amplifiers are designed for ease of use. They will automatically power on when removed from the charging case and power off when placed back into the case. Ensure they are properly seated in the charging slots.

2. Volume Control

Adjust the listening volume directly from the charging case. Use the **+** button to increase volume and the **-** button to decrease volume. There are 4 distinct volume levels to choose from.

3. Sound Programs

The device offers 3 pre-set sound programs to cater to different hearing needs:**Mild**, **Moderate**, and **Enhanced**. Cycle through these programs by pressing the designated program button on the charging case. Experiment to find the program that best suits your hearing profile.

Image: A diagram illustrating an ear with the Cearvol Nano amplifier and a graph depicting three distinct sound programs (Program 1, Program 2, Program 3) with varying gain levels, allowing users to choose the best fit for their hearing needs.

4. Environmental Modes

The Cearvol Nano features 3 environmental modes to optimize sound clarity in various settings:

- **Indoor Mode:** Ideal for quiet home environments, focusing on clear conversations.
- **Outdoor Mode:** Reduces wind noise and enhances sounds in open spaces.
- **Restaurant Mode:** Minimizes background chatter and focuses on speech in noisy environments.

Switch between these modes using the 'M' button on the charging case.

Image: Three distinct scenarios illustrating the application of the Cearvol Nano's environmental modes: a person in a restaurant setting, an outdoor conversation, and an individual relaxing indoors, demonstrating optimized hearing for each environment.

5. Charging Case Controls

The charging case is your central control unit. It allows you to adjust volume, select sound programs, and switch environmental modes without needing a smartphone app. Refer to the diagram below for a visual guide to the button functions.

Image: A close-up view of the Cearvol Nano charging case, with a finger pressing the '+' volume button, clearly demonstrating the integrated controls for volume, mode, and program selection.

6. Battery Life and Quick Charge

The amplifiers provide up to 17 hours of continuous use on a single charge. The charging case extends the total usage time to 54 hours. A quick 15-minute charge in the case can provide an additional 3 hours of listening time.

Image: The Cearvol Nano charging case connected to a Type-C charging cable, with text indicating 17 hours of amplifier use and 54 hours total with the case, alongside a graphic showing a 15-minute quick charge provides 3 hours of use.

Maintenance

1. Cleaning

Regular cleaning is essential for maintaining the performance and hygiene of your Cearvol Nano Sound Amplifiers. The charging case features an integrated UV sanitization light that activates during charging, eliminating up to 99.9% of bacteria. Additionally, use the provided cleaning brush to gently remove any earwax or debris from the ear tips and amplifier openings. Do not use liquids or harsh chemicals directly on the amplifiers.

Image: The Cearvol Nano charging case with a transparent lid, showing the amplifiers inside being sanitized by UV light, with '99.9%' and 'UV' indicators, emphasizing the integrated hygiene feature.

2. Storage

When not in use, always store the amplifiers in their charging case. This protects them from dust and damage, and ensures they remain charged and ready for your next use.

Troubleshooting

If you encounter any issues with your Cearvol Nano Sound Amplifier, please refer to the following common solutions:

- **No Sound:** Ensure the amplifiers are fully charged and correctly inserted into your ears. Check that the volume is not set to the lowest level.
- **Poor Sound Quality or Feedback (Whistling):** This often indicates an improper fit. Try a different size of ear tip to achieve a better seal in your ear canal. Ensure the amplifiers are clean and free of earwax. Adjust the sound program or environmental mode.
- **Charging Issues:** Verify that the Type-C charging cable is securely connected to both the charging case and the power source. Ensure the power source is active. Clean the charging contacts on both the

amplifiers and the case.

- **Amplifier Not Turning On:** Ensure the amplifiers are fully charged. If they do not turn on automatically when removed from the case, try placing them back in the case for a few seconds and then removing them again.

If these steps do not resolve the issue, please contact Cearvol customer support for further assistance.

Specifications

Feature	Detail
Brand	Cearvol
Model Name	Nano
Color	Galassia (Galaxy)
Material	Plastic
Style	In-ear
Power Source	Rechargeable Battery
Special Features	Volume Control, Sweat Resistant, Rechargeable
Form Factor	In-ear
Battery Type	Lithium Polymer (3 batteries included)
Compatible Devices	Television, Tablet, Smartphone
Control Type	Button Control (via charging case)
Battery Weight	4.7 Grams
Noise Control	None (Focuses on vocal clarity and background noise reduction)
Recommended Use	3 Environmental Modes, 3 Sound Programs (Mild, Moderate, Enhanced)
IP Rating	IPX5 (Resistant to light rain and sweat)
Amplifier Battery Life	Up to 17 hours
Total Battery Life (with case)	Up to 54 hours
Quick Charge	15 minutes for 3 hours of use

Warranty and Support

Cearvol is committed to providing quality products and excellent customer service. Your Cearvol Nano Sound Amplifier comes with a standard manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included in your package or visit the official Cearvol website.

Customer reviews frequently highlight Cearvol's responsive and helpful post-sale support. If you have any questions or require assistance, do not hesitate to reach out to their customer service team.

© 2026 Cearvol. All rights reserved.