Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOFJAJHQ ZP.256E.818R00

GOFJAJHQ ZP.256E.818R00 Network TV Driver Board

User Manual

Model: ZP.256E.818R00 | Brand: GOFJAJHQ

1. Introduction

This manual provides essential information for the installation, operation, and maintenance of the GOFJAJHQ ZP.256E.818R00 Network TV Driver Board. This board is designed to serve as a replacement or upgrade component for compatible display equipment, offering stable performance and restoring audio/video functionality. Please read these instructions carefully before proceeding with installation or use.

2. Product Overview

The ZP.256E.818R00 is a network TV driver board featuring 1GB RAM and 8GB storage, integrated with an inverter for display equipment. It supports a resolution of 1920x1080 and has a power output of 25W. This component is crucial for the proper functioning of your television's display and network capabilities.

Key Features:

- **Enhanced Stability:** Designed to resolve issues of frequent system crashes often caused by aging components in the original TV motherboard.
- **Restored Audio/Video:** Capable of restoring clear audio and video output, addressing problems like no sound or distorted pictures.
- **Hardware Protection:** Helps prevent potential short-circuits and damage to other TV components by replacing a faulty motherboard.
- **Extended TV Lifespan:** Offers a cost-effective solution to prolong the operational life of your television without needing a full replacement.
- **Integrated Inverter:** Features a built-in inverter for efficient power management.



Figure 1: Front view of the GOFJAJHQ ZP.256E.818R00 Network TV Driver Board, showing various integrated circuits, capacitors, and connectors. This image highlights the main components and layout of the board.

3. Specifications

Feature	Detail
Model Number	ZP.256E.818R00
RAM	1GB
Storage	8GB
Resolution Support	1920x1080
Inverter Power	25W
Item Weight	1.76 ounces (approx. 50 grams)
Package Dimensions	0.39 x 0.39 x 0.39 inches (approx. 1 x 1 x 1 cm)
Manufacturer	sensen tao

4. Installation Guide

Important: Installation of this TV driver board requires technical expertise and should ideally be performed by a qualified technician. Improper installation can lead to damage to the board, the television, or personal injury. Always disconnect the TV from the power source before beginning any installation.

General Installation Steps:

1. **Preparation:** Ensure the television is unplugged and allowed to cool down. Lay the TV face down on a soft, clean surface to protect the screen.
2. **Access the Mainboard:** Carefully remove the back panel of the television to expose the internal components, including the existing driver board.
3. **Disconnect Cables:** Document or photograph the connections before disconnecting all cables (power, data, ribbon cables, etc.) from the old driver board.
4. **Remove Old Board:** Unscrew and carefully remove the old driver board from its mounting points.
5. **Install New Board:** Position the GOFJAJHQ ZP.256E.818R00 board in place and secure it with the appropriate screws.
6. **Reconnect Cables:** Reconnect all cables to the new board, ensuring they are seated firmly and correctly according to your documentation.
7. **Test:** Before reattaching the back panel, carefully plug in the TV and perform a basic power-on test to ensure functionality.
8. **Final Assembly:** If the test is successful, unplug the TV again and reattach the back panel.



Figure 2: Back view of the GOFJAJHQ ZP.256E.818R00 Network TV Driver Board, showing the reverse side of the PCB and a barcode label. The barcode number visible is 3968-23111100823, which may be used for identification or tracking.

5. Operation

Once correctly installed, the ZP.256E.818R00 Network TV Driver Board operates automatically as the central control unit for your television's display and network functions. No direct user interaction with the board itself is required. The board facilitates the processing of video signals, audio output, and network connectivity, allowing your TV to function as intended.

6. Maintenance

The GOFJAJHQ ZP.256E.818R00 Network TV Driver Board is designed for long-term reliability and generally requires no routine maintenance. To ensure its longevity and optimal performance:

- **Keep Clean:** Ensure the interior of the TV remains free from excessive dust accumulation, which can impede cooling and lead to component failure.
- **Ventilation:** Maintain proper ventilation around the television to prevent overheating of internal components.
- **Stable Power:** Connect the television to a stable power source, ideally with surge protection, to prevent damage from power fluctuations.

7. Troubleshooting

If you encounter issues after installing the ZP.256E.818R00 driver board, consider the following common troubleshooting steps:

- **No Power/TV Not Turning On:**
  - Verify all power connections are secure.
  - Check the power outlet and TV power cord.
  - Ensure the new board is correctly seated and all screws are tightened.
- **No Audio or Distorted Video:**
  - Recheck all ribbon cables and data connections to ensure they are fully inserted and not damaged.
  - Confirm that external audio/video sources are functioning correctly.
- **Frequent Crashes or Freezing:**
  - Ensure the board is compatible with your specific TV model and panel.
  - Check for any loose connections or signs of overheating.
- **No Network Connectivity:**
  - Verify the Ethernet cable connection or Wi-Fi module connection.
  - Check TV network settings.

If problems persist, it is recommended to consult a professional TV repair technician.

8. Warranty and Support

For information regarding warranty coverage, technical support, or replacement parts, please refer to the purchase documentation or contact your seller directly. Keep your purchase receipt and product model number (ZP.256E.818R00) readily available when seeking support.

© 2025 GOFJAJHQ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FR8FRYTX

More documents and user manuals: **https://manuals.plus/**