Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Acaspresso AR-11G

Acaspresso Slushie Machine AR-11G Instruction Manual

Model: AR-11G | Brand: Acaspresso

Introduction

This manual provides detailed instructions for the safe and efficient operation and maintenance of your Acaspresso Slushie Machine, Model AR-11G. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Warnings

- Always ensure the machine is unplugged before cleaning or maintenance.
- Do not immerse the main unit in water or other liquids.
- Keep hands and utensils out of the vessel during operation to prevent injury.
- Ensure the sealing ring is properly installed before assembling the loading bucket.
- Do not add ice, solid, or hot ingredients directly into the freezing chamber. Only add liquids.
- Keep the unit running during dispensing to maintain consistency.
- For best slushie texture, ensure drinks contain at least 6% sugar. Artificial sweeteners may not yield desired results.
- For alcoholic slushies, maintain alcohol content between 2.8% and 16% when using 'Spiked Slush' mode. Exceeding 16% alcohol may prevent proper freezing.
- Keep out of reach of children.

Package Contents

Verify that all items are included in your package:

- Main Unit

- Easy-Fill Vessel (81oz / 2.4L capacity)
- Rotating Auger
- Comfort Handle
- Drip Tray
- Water Tank
- Outlet Silicone Sleeve
- Sealing Ring
- User Manual
- Quick Use Guides (English, Spanish, French)
- Recipe Guide



Figure 1: Exploded view of the Acaspresso Slushie Machine and its components.

Setup and Installation

Follow these steps to set up your slushie machine before first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash all detachable parts (vessel, auger, handle, drip tray, water tank, silicone sleeve, sealing ring) with warm, soapy water. Rinse thoroughly and dry. The detachable parts are dishwasher safe.
3. **Assemble Auger:** Insert the rotating auger into the cooling cylinder inside the main unit. Ensure it is securely in place.
4. **Install Sealing Ring:** Place the sealing ring properly around the opening of the vessel.
5. **Attach Vessel:** Align the vessel with the main unit and secure it by turning the locking knob.
6. **Attach Drip Tray:** Slide the drip tray into the designated slot at the base of the machine.
7. **Position:** Place the machine on a stable, flat surface with adequate ventilation.
8. **Power:** Plug the power cord into a grounded electrical outlet.

▶ **Watch video online**
How to Use & Clean

Video 1: This video demonstrates the easy installation process of the Acaspresso Slushie Machine, showing how to assemble the main components and prepare it for use.

Operating Instructions

Your Acaspresso Slushie Machine features rapid freezing technology and 8 preset programs for various frozen drinks. No ice is needed, ensuring a smoother, undiluted taste.

1. Preparing Your Drink

- **Liquid Only:** Ensure you only add liquid ingredients to the vessel. Do not add ice, solid fruits, or hot liquids directly.
- **Sugar Content:** For optimal slushie texture, your drink should contain at least 6% sugar. Artificial sweeteners may not freeze correctly.
- **Alcohol Content (Spiked Slush):** If making alcoholic slushies, keep the alcohol content between 2.8% and 16%. Higher alcohol percentages may prevent proper freezing.
- **Capacity:** The vessel has an 81oz (2.4L) capacity. For cold drinks, the maximum fill is 68oz (2L). For slushies, the maximum fill is 51oz (1.5L) to allow for expansion during freezing.



Figure 2: Simple three-step process for making a slushie: Pour, Slush, Enjoy.

Figure 3: Guide on checking sugar content for optimal slushie texture.



Figure 4: Recommended alcohol content for 'Spiked Slush' mode.

2. Using Preset Modes and Timer

- **Power On:** Press the power button () to turn on the machine.
- **Select Mode:** Choose from 8 preset modes: Slush, Frappé, Spiked Slush, Milkshake, Frozen Juice, Cold Drinks, Clean, or Custom Made.
- **Adjust Thickness:** Each preset mode offers 7 thickness levels. Use the '+' and '-' buttons to adjust the texture to your preference.
- **Set Timer:** Utilize the 6-hour timer function to prepare your drink in advance. The machine will start the freezing process when the timer finishes.
- **Start:** Press the play/pause button () to begin the selected program. The machine will typically take 15-60 minutes to prepare a slushie.



Figure 5: Control panel with 8 preset modes and timer function.



Figure 6: How to use the 6-hour timer for convenient preparation.

▶ **Watch video online**

Video 2: This video provides a general overview of the Acaspresso Slushie Machine, demonstrating its ease of use and the quality of the frozen drinks it produces.

3. Dispensing Your Drink

- Once your drink is ready, place a cup under the dispenser.
- Pull the comfort handle forward to dispense the slushie.
- Release the handle to stop dispensing.
- Keep the unit running during dispensing to ensure consistent texture.



Figure 7: Easy-fill vessel and self-serve handle for hassle-free operation.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygiene of your Acaspresso Slushie Machine.

1. Self-Cleaning Mode

- After each use, pour clean water into the vessel.
- Select the 'Clean' preset mode on the control panel.
- Allow the machine to run through the cleaning cycle.
- Dispense the water and wipe the interior of the vessel.

2. Deep Cleaning

- **Unplug:** Always unplug the machine from the power outlet before disassembling for deep cleaning.
- **Disassemble:** Carefully remove the vessel, rotating auger, comfort handle, drip tray, water tank, silicone sleeve, and sealing ring.
- **Wash Detachable Parts:** All detachable parts are dishwasher safe. Alternatively, hand wash them with warm, soapy water, rinse thoroughly, and dry completely.
- **Clean Main Unit:** Wipe the exterior and the cooling cylinder of the main unit with a damp cloth. Do not immerse the main unit in water.
- **Reassemble:** Once all parts are dry, reassemble the machine following the setup instructions in reverse order.



Figure 8: Self-cleaning and dishwasher-safe components for easy maintenance.

▶ Watch video online

Video 3: This video demonstrates both the usage and cleaning procedures for the Acaspresso Slushie Machine, including disassembling and washing parts.

Specifications

Feature	Detail

Feature	Detail
Brand	Acaspresso
Model Name	AR-11G
Color	Gunmetal
Product Dimensions	17"D x 6.7"W x 16"H
Item Weight	28 pounds
Vessel Capacity	81oz (2.4L) Total; 68oz (2L) Max for Cold Drinks; 51oz (1.5L) Max for Slushie
Special Features	Rapid Freezing Technology, 8 Preset Modes, 6-Hour Timer, Self-Cleaning, Dishwasher Safe Parts, Temperature Control (7 thickness levels), WhisperChill Compressor
Operation Mode	Fully Automatic
UPC	738211160533
ASIN	B0FVDF5DMD

Troubleshooting

No specific troubleshooting steps were provided in the product information. If you encounter issues, please refer to the general tips below or contact customer support.

- **Machine not turning on:** Ensure the power cord is securely plugged into a working electrical outlet.
- **Drink not freezing:** Verify that the liquid has at least 6% sugar content. For 'Spiked Slush' mode, ensure alcohol content is within the recommended 2.8%-16% range. Ensure the ambient temperature is not excessively high.
- **Slushie too thin/thick:** Adjust the thickness level using the '+' and '-' buttons in your selected preset mode.
- **Leaking:** Check that the sealing ring is correctly installed and the vessel is securely locked onto the main unit.

Warranty and Customer Support

Specific warranty details and customer support contact information were not provided in the product data. Please refer to the product packaging or the manufacturer's official website for warranty information and how to contact customer support for assistance.
For more information about Acaspresso products, visit the Acaspresso Store on Amazon.

© 2025 Acaspresso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVDF5DMD

More documents and user manuals: **https://manuals.plus/**