Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SICOTAS B0FVM91WGB

SICOTAS 6-Drawer Extra-Wide Dresser Instruction Manual

Model: B0FVM91WGB | Brand: SICOTAS

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your SICOTAS 6-Drawer Extra-Wide Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This dresser features a dark grey oak finish, six spacious drawers, and is designed for use in bedrooms, nurseries, living rooms, or closets.

Safety Information

WARNING: To prevent serious injury, this product must be securely attached to the wall using the anti-tip anchor provided. Children can be seriously injured by furniture tipping over. Always install the anti-tip restraint. Never allow children to climb or hang on drawers, doors, or shelves. Place heaviest items in the lowest drawers. Do not place heavy objects on top of the dresser that could cause it to become unstable.
Ensure all parts are present and undamaged before assembly. Do not use power tools for assembly unless specifically instructed, as overtightening screws can cause damage.

Product Overview

The SICOTAS 6-Drawer Extra-Wide Dresser offers ample storage with a modern design. It features a durable engineered wood construction with a wood grain finish and metal handles.



Image: The SICOTAS 6-Drawer Extra-Wide Dresser in a dark grey oak finish, positioned in a bedroom with a lamp and artwork on top.



Image: Detailed dimensions of the dresser: 56.4 inches wide, 16.9 inches deep, 31.3 inches high. Individual drawer dimensions are 24.1 inches wide, 13.2 inches deep, and 5.8 inches high. The top surface supports up to 77 lbs, and each drawer supports up to 16 lbs.



Image: Close-up views highlighting key features: 3D drawer front design, elegant metal handles, sturdy wood construction, and a raised edge on the top surface to prevent items from falling.

Assembly Instructions

Assembly is required for this dresser. Please follow the step-by-step instructions provided in the packaging. Ensure you have all necessary tools and components before starting. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches.

Drawer Slide Installation and Operation

Proper installation of the drawer slides is crucial for smooth operation. Refer to the following video for guidance on installing and troubleshooting drawer slides.

▶ **Watch video online**
Drawer Not Sliding? Quick Fix Guide

Video: Instructional guide on how to fix a drawer that is not sliding smoothly. This video demonstrates the correct method for installing

and adjusting drawer slides to ensure proper function.

1. **Step 1:** Slide the inner rail all the way to the front.
2. **Step 2:** Place the drawer level and straight. Avoid tilting.
3. **Step 3:** Align one side of the drawer first, then the other, with the corresponding slide rails.
4. **WARNING:** Incorrect start position or forcing the drawer will cause ball bearings to fall out and damage the slide.
5. **NOTE:** If the drawer doesn't slide in smoothly, gently remove it, realign, and retry.
6. To remove the drawer, pull down the lever on one side and pull up the lever on the other side, then pull the drawer out.

Operating Instructions

To open a drawer, gently pull the metal handle. To close, push the drawer firmly until it is fully seated. The high-quality metal slides ensure smooth operation. Avoid overloading drawers to maintain their functionality and structural integrity.



Image: The dresser with several drawers open, showcasing the spacious interior for organizing clothes and other items.

Maintenance and Care

- **Cleaning:** Wipe the dresser with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking of the wood.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the dresser remains stable and secure.

Troubleshooting

Drawer Not Sliding Smoothly

If a drawer does not slide smoothly, it may be due to misalignment or issues with the ball bearings in the slide mechanism. Refer to the "Drawer Slide Installation and Operation" video in the Assembly Instructions section for a quick fix guide. Ensure the drawer is level and properly aligned with the slides. If the issue persists, contact customer support.

Specifications

Brand	SICOTAS
Model Name	Dresser
ASIN	B0FVM91WGB
UPC	635508493087
Material	Engineered Wood
Finish Type	Wood Grain (Dark Grey Oak)
Product Dimensions (D x W x H)	16.93"D x 56.42"W x 31.3"H
Number of Drawers	6
Item Weight	130.5 Pounds
Drawer Type	Ball Bearing Slide
Required Assembly	Yes

Warranty and Support

For any questions, missing parts, or assistance with assembly, please contact SICOTAS customer service. Our team is available to provide support and ensure your satisfaction with the product.
Please refer to your purchase documentation for specific warranty details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVM91WGB

More documents and user manuals: **https://manuals.plus/**