Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee PHK_33GBWQ4Gr8dT

Garvee 9-Drawer Dresser Instruction Manual

Model: PHK_33GBWQ4Gr8dT

1. Introduction

Thank you for choosing the Garvee 9-Drawer Dresser. This modern wooden storage chest is designed to provide ample storage and a sleek aesthetic for your bedroom, living room, or hallway. It features nine spacious drawers, a durable construction, and an integrated power outlet for convenience. This manual provides essential information for safe assembly, operation, and maintenance of your new dresser.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Kit:** This dresser includes an anti-tipping kit. It is crucial to install this kit securely to a wall stud to prevent the dresser from tipping over, especially in households with children or pets.
- **Weight Distribution:** Place heavier items in the lower drawers to improve stability. Avoid placing excessively heavy objects on the top surface.
- **Children's Safety:** Do not allow children to climb on or play with the dresser. Keep small parts and hardware out of reach of children.
- **Power Outlet Safety:** Only use the integrated power outlet for devices within its specified voltage and current limits. Do not overload the outlets. Keep liquids away from the power strip.
- **Assembly:** Assembly requires two people. Do not attempt to assemble alone. Ensure all fasteners are tightened securely before use.



Image: The anti-tilting kit is essential for securing the dresser to the wall, preventing accidental tipping.

3. Package Contents

Before beginning assembly, ensure all parts and hardware are present. Refer to the detailed guide included in your

package for a complete list and identification of components.

- Dresser panels (top, bottom, sides, back)
- Drawer panels and bases (for 9 drawers)
- Metal handles
- Ball-bearing drawer slides
- Integrated power outlet unit with power cord
- Anti-tipping kit
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions manual

4. Setup and Assembly

Assembly of this dresser requires two individuals. Follow the step-by-step instructions provided in the separate assembly guide carefully. All components are labeled for easy identification.

Key Assembly Steps:

1. **Prepare Workspace:** Clear a spacious area for assembly. Lay out all parts and hardware.
2. **Assemble Frame:** Connect the main dresser panels according to the instructions. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the ball-bearing drawer slides to the dresser frame and to the drawer sides.
4. **Assemble Drawers:** Construct each of the nine drawers, ensuring the bases are properly seated and handles are attached.
5. **Install Power Outlet:** Integrate the power outlet unit into the designated slot on the dresser top or back panel as per instructions. Connect the power cord.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots.
7. **Install Anti-Tipping Kit:** Securely attach the anti-tipping kit to the back of the dresser and to a wall stud using the provided hardware. This step is critical for safety.

5. Operating Instructions

Drawer Usage:

The nine drawers are equipped with smooth ball-bearing slides for effortless opening and closing. To open, gently pull the metal handle. To close, push the drawer until it is fully seated.

Image: The nine spacious drawers provide extensive storage for organizing clothing, accessories, and personal items.

Integrated Power Outlet:

The dresser features a built-in power strip with 3 AC outlets and 2 USB charging ports. Plug the dresser's main power cord into a wall outlet. You can then connect up to five devices simultaneously for charging or powering small appliances.



Image: The integrated charging station offers convenient access to power for various electronic devices and small appliances.

Top Surface Use:

The expansive 63-inch top surface can be used for displaying decorative items, photographs, or as a TV stand. It is suitable for TVs up to 70 inches.



Image: The dresser's top surface can accommodate televisions up to 70 inches, serving as a functional media console.

6. Maintenance

To maintain the pristine appearance and functionality of your Garvee 9-Drawer Dresser, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the dresser surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone-based lubricant can be applied to the ball-bearing slides.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common troubleshooting tips:

- **Drawers are Stiff or Uneven:**
  - Check if the drawer slides are properly aligned and securely attached to both the drawer and the dresser frame.
  - Ensure the drawer is not overloaded or unbalanced.
  - Apply a small amount of silicone lubricant to the drawer slides.
- **Dresser Wobbles:**
  - Verify that all assembly screws are fully tightened.
  - Ensure the dresser is placed on a level surface. Adjust furniture levelers if present.

- Confirm the anti-tipping kit is securely installed to a wall stud.

- **Power Outlet Not Working:**
  - Ensure the dresser's main power cord is securely plugged into a functional wall outlet.
  - Check if the power outlet unit itself is properly connected internally within the dresser.
  - Test the wall outlet with another device to confirm it has power.
  - Avoid overloading the power strip; unplug some devices and try again.

8. Specifications

Brand	Garvee
Model Number	PHK_33GBWQ4Gr8dT
Product Dimensions (L x W x H)	62.99" x 15.75" x 31.5"
Number of Drawers	9
Drawer Depth	12.6 inches (internal)
Material	Engineered Wood (MDF)
Item Weight	135.9 pounds
Power Outlet	3 AC Outlets, 2 USB Ports
Power Cord Length	4.92 feet
Assembly Required	Yes

Image: Overall and internal drawer dimensions of the Garvee 9-Drawer Dresser.

9. Warranty and Support

For warranty information, please refer to the documentation included with your product or contact Garvee customer support directly. Garvee is committed to providing quality products and customer satisfaction.

Customer Support:

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Garvee customer support. Contact details are typically found on the product packaging or the manufacturer's official website.

© 2025 Garvee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FVX5XQ9J

More documents and user manuals: **https://manuals.plus/**