Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee B0FWK3VXGT

Garvee Fluted TV Stand 70-inch Wide Entertainment Center User Manual

Model: B0FWK3VXGT

1. Introduction

Thank you for choosing the Garvee Fluted TV Stand. This 70-inch wide entertainment center is designed to provide a stylish and functional solution for your media storage needs. Crafted from high-quality engineered wood with a walnut finish and distinctive fluted doors, it offers ample space for televisions up to 80 inches, media players, game consoles, and other decor items. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal use of your new furniture.



Image 1.1: The Garvee Fluted TV Stand, 70-inch wide, featuring its walnut finish and fluted cabinet doors, positioned under a large television.

2. Safety Information

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Keep Children Away:** During assembly, keep all small parts and packaging materials away from children and pets, as they could pose a choking hazard.
- **Two-Person Assembly:** Assembly of this TV stand is recommended with two people to prevent injury and ensure proper alignment.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 250 pounds for the top surface. Ensure items are distributed evenly.
- **Anti-Tip Device:** If an anti-tip device is included, it is strongly recommended to install it to prevent the unit from tipping over, especially in households with children.

- **Stable Surface:** Place the TV stand on a flat, level, and stable surface to prevent wobbling or tipping.
- **Ventilation:** Ensure adequate ventilation for electronic devices placed within the stand's compartments to prevent overheating.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Fluted TV Stand components (various panels, doors, shelves)
- Hardware pack (screws, dowels, cam locks, handles, hinges, adjustable feet)
- Installation Tool (e.g., Allen wrench)
- Installation Instruction Manual

4. Setup and Assembly

Follow these step-by-step instructions for assembling your Garvee Fluted TV Stand. All parts and screws are labeled for easy identification.

4.1 Unpacking and Preparation

1. Clear a spacious area for assembly, preferably on a soft, clean surface like a carpet to prevent scratches.
2. Unpack all components and hardware. Organize them by their labels.
3. Review the included installation instruction manual for detailed diagrams.

4.2 Assembly Steps (General)

1. Attach cam locks and dowels to the designated panels as per the instruction manual.
2. Connect the side panels to the base and top panels, ensuring all connections are secure.
3. Install the back panel, aligning it with the pre-drilled holes.
4. Attach the hinges to the fluted cabinet doors and then mount the doors to the main frame. Adjust hinges as needed for proper door alignment.
5. Insert the adjustable shelves into the desired height slots.
6. Attach the golden handles to the cabinet doors.
7. Install the anti-tip device to the back of the TV stand and secure it to a wall stud, if applicable.



Image 4.1: Dimensional view of the Garvee Fluted TV Stand, illustrating its overall width (70.1"), height (23.1"), and depth (15.7").

5. Operating Instructions

The Garvee Fluted TV Stand is designed for versatile use in your living space.

5.1 Placing Your Television

This TV stand is suitable for flat screens and curved TVs up to 80 inches. Carefully place your television on the top surface, ensuring it is centered and stable. Do not exceed the maximum weight capacity.

5.2 Utilizing Storage Space

The stand features two side storage cabinets with fluted doors and two open storage shelves in the center. These provide ample space for media players, game consoles, books, and other items.



Image 5.1: The Garvee Fluted TV Stand with its cabinet doors open, showcasing the adjustable shelves and internal storage compartments for various media and decorative items.

5.3 Adjustable Shelves

The shelves within the central open compartments can be adjusted to 3 different heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and then place the shelf back onto the pins.

5.4 Cable Management

Wiring holes are provided on the inner back wall of the TV cabinet to help organize electrical appliance cables, keeping your setup tidy and preventing tangles.

6. Maintenance

Proper care will help maintain the appearance and longevity of your Garvee Fluted TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that

may damage the finish.

- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Hardware Check:** Periodically check and tighten all screws and fasteners to ensure the stand remains stable.

7. Troubleshooting

If you encounter any issues with your TV stand, refer to the following common problems and solutions.

- **Wobbly Stand:**
  Solution: Ensure the stand is on a level surface. Check all assembly hardware and tighten any loose screws. Adjust the leveling feet if present.
- **Doors Not Aligning:**
  Solution: Adjust the hinges on the cabinet doors. Most hinges allow for minor adjustments in height, depth, and side-to-side movement. Refer to the detailed assembly instructions for hinge adjustment specifics.
- **Missing Parts:**
  Solution: Double-check the packaging and compare with the package contents list. If parts are genuinely missing, contact Garvee customer support with your purchase details.
- **Scratches/Dents:**
  Solution: For minor scratches, furniture repair markers or wax sticks matching the walnut finish can be used. For significant damage, contact customer support for advice.

8. Specifications

Detailed specifications for the Garvee Fluted TV Stand.

Model Number	B0FWK3VXGT
Brand	Garvee
Color	Walnut
Material Type	Engineered Wood
Item Dimensions (W x H x D)	70.1 x 23.1 x 15.7 inches
Item Weight	81.9 Pounds
Assembly Required	Yes
Maximum TV Size Supported	Up to 80 inches
Weight Capacity (Top Surface)	250 pounds
UPC	199809037222



Image 8.1: Visual representation of the Garvee TV Stand's compatibility with various television sizes, specifically 65-inch, 70-inch, and 80-inch models.

9. Warranty and Support

Garvee is committed to providing high-quality products. For any questions, concerns, or assistance with your Garvee Fluted TV Stand, please contact our customer support team.

- **Customer Support:** Refer to your purchase documentation or the Garvee brand store on Amazon for contact information.
- **Warranty Information:** Specific warranty details may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FWK3VXGT

More documents and user manuals: **https://manuals.plus/**