**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**GarveeTech BST-8602**

# GarveeTech 61 Key Portable Electronic Keyboard for Kids

INSTRUCTION MANUAL - MODEL: BST-8602

## 1. INTRODUCTION

Thank you for choosing the GarveeTech 61 Key Portable Electronic Keyboard, Model BST-8602. This digital piano is designed for beginners and children, offering a lightweight and compact solution for music learning, practice, and entertainment. Crafted from durable HIPS plastic, it provides a safe and engaging musical experience.

## 2. SAFETY INFORMATION

- Keep the keyboard away from water and moisture to prevent electric shock.
- Do not expose the unit to direct sunlight or extreme temperatures.
- Use only the specified power adapter or batteries.
- Supervise young children during use to ensure safe operation.
- Avoid dropping or subjecting the keyboard to strong impacts.

## 3. PACKAGE CONTENTS

Please check that all items are present in your package:

- GarveeTech 61 Key Portable Electronic Keyboard (Model BST-8602)
- Music Stand/Holder
- Microphone
- Power Adapter/Charger
- Note Stickers




Figure 3.1: Included accessories with the GarveeTech 61 Key Portable Electronic Keyboard.

## 4. Setup

### 4.1 Powering the Keyboard

- **Battery Power:** Insert 6 'AA' size batteries (not included) into the battery compartment located on the underside of the keyboard. Ensure correct polarity.
- **AC Power:** Connect the provided power adapter to the DC 9V input jack on the rear of the keyboard and plug the other end into a standard wall outlet.

### 4.2 Connecting Accessories

- **Microphone:** Plug the microphone into the 'MIC' input jack on the rear panel.
- **Headphones:** For private practice, connect headphones (not included) to the 'AUDIO OUT' jack. This will mute the internal speakers.
- **External Audio Input:** Connect an external audio device (e.g., MP3 player, smartphone) to the 'AUDIO IN' jack to play along with your favorite songs.




Figure 4.1: Rear panel connections for power and audio accessories.

### 4.3 Music Stand Assembly

Attach the included music stand to the designated slots on the top panel of the keyboard. This provides a convenient place for sheet music or a tablet.

### 4.4 Applying Note Stickers

For beginners, carefully apply the provided note stickers to the corresponding keys as indicated in the sticker guide. This aids in learning note identification.

## 5. Operating Instructions

### 5.1 Power On/Off

Slide the 'POWER' switch located on the left side of the control panel to the 'ON' position to turn on the keyboard. Slide it to 'OFF' to power down.

### 5.2 Volume Control

Use the 'VOLUME +' and '-' buttons to adjust the master volume of the keyboard. Adjust the 'ACCOMP VOL' for accompaniment volume and 'CHORD VOL' for chord volume.

### 5.3 Selecting Tones (Instruments)

The keyboard features 200 different tones. To select a tone, press the 'TONE' button and then use the number pad to enter the desired two-digit tone number (e.g., 00 for Piano). Refer to the tone list printed on the keyboard for available options.

### 5.4 Selecting Rhythms

The keyboard includes 200 rhythms. To select a rhythm, press the 'RHYTHM' button and then use the number pad to enter the desired two-digit rhythm number. Refer to the rhythm list printed on the keyboard.

### 5.5 Demo Songs

The keyboard has 70 demo songs. Press the 'DEMO SONG' button to cycle through the available demonstration songs. Press 'START/STOP' to stop playback.




Figure 5.1: Control panel detailing tone, rhythm, and demo song selection.

## 5.6 Recording and Playback

To record your playing, press the 'REC' button. Play your desired melody. Press 'PLAY' to listen to your recorded performance. Press 'PROG' to program a rhythm sequence.

## 5.7 Tempo and Transpose

- **Tempo:** Use the 'TEMPO +' and '-' buttons to increase or decrease the speed of rhythms and demo songs.
- **Transpose:** Use the 'TRANSPOSE +' and '-' buttons to shift the pitch of the keyboard up or down.

## 5.8 Microphone Usage

Once the microphone is plugged in, you can sing along while playing the keyboard. Adjust the microphone volume using the dedicated controls if available, or the master volume.




Figure 5.2: The keyboard in use, demonstrating the microphone feature.

## 6. Maintenance

- **Cleaning:** Wipe the keyboard with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove batteries to prevent leakage.
- **Key Care:** Keep the keys clean and free from dust. Avoid pressing keys with excessive force.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| No sound | Volume too low; headphones connected; power issue | Increase volume; disconnect headphones; check power adapter/batteries |
| Keys not responding | Keyboard is off; internal malfunction | Turn on keyboard; contact customer support if issue persists |
| Distorted sound | Volume too high; low battery | Lower volume; replace batteries or use AC adapter |

## 8. Specifications

- **Model:** BST-8602
- **Number of Keys:** 61
- **Material:** HIPS Plastic
- **Dimensions:** 37.4"D x 13.78"W x 5.51"H
- **Item Weight:** 8.47 Pounds
- **Power Source:** Battery Powered (6x 'AA' batteries, not included) or AC Adapter (included)
- **Tones:** 200
- **Rhythms:** 200
- **Demo Songs:** 70
- **Manufacturer:** GarveeTech

## 9. Warranty and Support

GarveeTech products are designed for quality and reliability. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official GarveeTech website. Please retain your proof of purchase for warranty purposes.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0FX2WM2BK**

More documents and user manuals: **https://manuals.plus/**