Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave Queen Over King Bunk Bed

Bellemave Queen Over King Bunk Bed Instruction Manual

Model: Queen Over King Bunk Bed | Brand: Bellemave

Important Safety Information

Please read and understand all instructions and safety warnings before assembly and use of this bunk bed. Failure to follow these instructions can result in serious injury.

- Always use the guardrail and ladders when using the bunk bed.
- Be cautious of the low bunk design to avoid head injuries. The height between the upper and lower bed is approximately 40 inches.
- Do not exceed the weight capacity:**Upper Bed: 300 lbs**, **Bottom Bed: 350 lbs**.
- Always follow the assembly instructions carefully to ensure stability and prevent collapse.
- This bunk bed is equipped with anti-tipping devices. Ensure they are properly installed.
- This queen over king bunk bed cannot be converted into two single beds.
- Regularly check all fasteners and connections to ensure they remain tight.

Setup and Assembly

The Bellemave Queen Over King Bunk Bed is designed for straightforward assembly. It comes with detailed instructions and all necessary numbered parts for convenient step-by-step installation. Please note that the product will arrive in two separate boxes.

Before You Begin:

- Unpack all components and verify against the parts list provided in your package.
- Ensure you have adequate space for assembly.
- Keep children and pets away from the assembly area.
- Do not fully tighten screws until all parts are correctly aligned.

Assembly Overview:

The bunk bed frame consists of heavy-duty metal components, including thickened steel legs and slats, designed for durability and stability. The design incorporates two side ladders and full-length guardrails for safety.




Image: Overall view of the Bellemave Queen Over King Bunk Bed frame, showcasing its structure and two ladders.



Image: Close-up details of the heavy-duty metal slats, noise-reducing rubber stoppers, and the integrated ladder design.

Follow the step-by-step instructions provided in the packaging for detailed assembly. Ensure all connections are secure and stable before use.

Operating Guidelines

This bunk bed is designed to provide a safe and comfortable sleeping solution. Adhere to the following guidelines for proper use:

- **Weight Capacity:** The upper bed supports up to 300 lbs, and the bottom bed supports up to 350 lbs. Do not exceed these limits.
- **Ladder Use:** Always use the provided ladders for accessing the upper bunk. Do not climb on the frame directly.
- **Guardrails:** The upper bunk is equipped with full-length guardrails for safety. Ensure mattresses do not exceed the height of the guardrails.
- **Noise Reduction:** The frame features noise-reducing rubber stoppers to prevent slats from moving and creating

noise.

- **Space Saving:** The bunk bed design offers a spacious 9.8-inch high storage area underneath the bottom bunk, ideal for storing items like trunks, toys, shoes, or books.




Image: Illustration highlighting the 9.8-inch under-bed clearance for storage.



Image: Detail showing the 13.6-inch guardrail height and the presence of two ladders for access.

Maintenance

Proper maintenance will ensure the longevity and safety of your Bellemave bunk bed.

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the powder-coated finish.
- **Fastener Checks:** Periodically check all bolts, screws, and connections to ensure they are tight. Re-tighten as necessary to maintain stability and prevent wobbling.
- **Rust Prevention:** The frame is made of rust-proof metal. However, avoid prolonged exposure to moisture to prevent potential damage.
- **Slat Inspection:** Inspect the metal slats regularly for any signs of damage or bending. Replace any damaged slats immediately.

Troubleshooting

If you encounter issues with your bunk bed, refer to the following common troubleshooting steps:

- **Wobbling or Instability:**
  - Ensure all screws and bolts are fully tightened. Sometimes, screws may not bite properly if not aligned correctly during initial assembly. Disassemble and reassemble the problematic section, ensuring proper alignment.
  - Verify that the bunk bed is placed on a level surface. Uneven flooring can cause instability.
  - Check that all parts are installed according to the instruction manual. Missing or incorrectly installed components can affect stability.
- **Noise from Slats:**
  - Confirm that the noise-reducing rubber stoppers are correctly positioned and securely holding the slats.
  - Ensure the mattress is properly seated on the slats and not causing excessive movement.
- **Missing Parts:**
  - If you find any parts missing upon unboxing, contact Bellemave customer support immediately.

Specifications



Image: Dimensional diagram of the Bellemave Queen Over King Bunk Bed.

Feature	Detail
Model Number	Queen Over King Bunk Bed
Brand	Bellemave
Size	Queen over King
Material	Metal (Powder Coated)
Product Dimensions (L x W x H)	83"L x 79"W x 64"H
Item Weight	56 Pounds
Upper Bed Weight Capacity	300 lbs
Bottom Bed Weight Capacity	350 lbs
Number of Slats	20 pcs slats + 1 center support bar (upper and bottom bed)
Under-bed Storage Height	9.8 inches
Height Between Beds	40 inches
Guardrail Height	13.6 inches

Feature	Detail
Included Components	Guardrails, Ladders (2), Slats
Special Features	Guardrail, Ladder, No Box Spring Needed, Slats, Space Saving, Noise Reduced
Assembly Required	Yes
Color	Black

Product Overview Video

Your browser does not support the video tag.

Video: An overview of the Bellemave Queen Over King Bunk Bed, demonstrating its features and design. This video provides a visual guide to the product's appearance and functionality.

Warranty and Support

For specific warranty information, please refer to the documentation included with your product packaging. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support.

You can also visit the official Bellemave store for more product information and support:Bellemave Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FXFWG4Q8

More documents and user manuals: **https://manuals.plus/**