Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Erivess HA601B-ES1

Erivess 20L Beverage Refrigerator Cooler and Skincare Mini Fridge

Model: HA601B-ES1

User Instruction Manual

1. Important Safety Information

Please read all instructions carefully before using this appliance to ensure safe operation and to prevent damage. Keep this manual for future reference.

- **Electrical Safety:** Ensure the appliance is connected to a grounded outlet with the correct voltage (110 Volts). Do not use extension cords.
- **Placement:** Place the refrigerator on a stable, level surface. Allow adequate ventilation space around the unit (at least 4 inches from walls) to ensure proper cooling and energy efficiency.
- **Flammable Materials:** Do not store explosive substances or flammable materials inside the appliance.
- **Cleaning:** Always unplug the appliance before cleaning. Use a soft cloth and mild detergent. Avoid abrasive cleaners.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. Product Overview

The Erivess 20L Beverage Refrigerator Cooler is a versatile and compact appliance designed for cooling beverages, cosmetics, and skincare products. It features a mirrored front door, adjustable temperature control, and removable shelving for flexible storage.



Figure 2.1: Erivess 20L Beverage Refrigerator Cooler

Key Features:

- **2-in-1 Functionality:** Combines a beauty fridge for cosmetics/skincare with a beverage cooler.
- **Mirrored Front Door:** Provides a stylish aesthetic and can double as a vanity mirror.
- **Precise Temperature Control:** Adjustable settings for optimal chilling.
- **Energy Efficient:** Energy Star rated for minimal power consumption.
- **Ultra-Quiet Operation:** Low-noise compressor (under 40 dB) suitable for bedrooms and offices.
- **Smart Storage:** Removable glass shelves and side door racks for flexible organization.
- **Reversible Door:** Allows for left or right opening to suit room layout.
- **LED Interior Light:** Illuminates contents for easy access.



Figure 2.2: Product Details - Glass Seal and Removable Shelves



Figure 2.3: Compact Design and Dimensions

3. Setup

Unpacking:

1. Carefully remove all packaging materials, including foam and tape.
2. Inspect the appliance for any shipping damage. If damaged, do not plug it in and contact customer support.
3. Remove any internal accessories and protective films.

Placement:

- Choose a location with a stable, level surface that can support the weight of the refrigerator when fully loaded.
- Ensure there is at least 4 inches (10 cm) of space around the back and sides of the unit for proper air circulation.
- Avoid direct sunlight or heat sources, as this can affect cooling performance and energy consumption.
- The appliance is designed for freestanding, countertop, or built-in installation.

Initial Power-On:

1. After placing the unit, wait at least 2-4 hours before plugging it in. This allows the refrigerant to settle.
2. Plug the power cord into a dedicated, grounded 110V electrical outlet.
3. The refrigerator will begin cooling. Allow several hours for the internal temperature to stabilize before loading items.

4. Operating Instructions

Temperature Control:

The refrigerator features an adjustable temperature control dial located on the back of the unit. The temperature range is approximately 40°F to 61°F (4.4°C to 16.1°C).



Figure 4.1: Temperature Control Dial

- Rotate the dial to select your desired temperature setting. Lower numbers indicate colder temperatures.
- For optimal beverage cooling, set the dial to a lower temperature.

- For skincare and cosmetics, a slightly higher temperature within the recommended range may be preferred.
- Allow several hours for the temperature to adjust after making changes.

Shelving and Storage:

The refrigerator includes removable shelves and side door racks to customize your storage space.

- To adjust or remove shelves, gently lift and slide them out.
- Arrange items to allow for proper air circulation, which helps maintain consistent temperatures.
- The unit can hold up to 24 standard cans or various sizes of bottles and cosmetic containers.

Interior LED Light:

The interior LED light can be turned on or off via a control button, typically located near the temperature display, for visibility in low-light conditions.

5. Maintenance

Cleaning:

- **Interior:** Unplug the refrigerator. Remove all items and shelves. Wash the interior surfaces with a solution of warm water and mild soap. Rinse thoroughly and dry with a soft cloth.
- **Exterior:** Clean the exterior with a soft cloth dampened with water and mild detergent. Do not use abrasive cleaners or solvents.
- **Door Seal:** Regularly clean the door gasket to ensure a tight seal, which is crucial for energy efficiency.

Defrosting:

This appliance features an automatic defrost system. Frost may occasionally accumulate on the interior back wall, but it will typically melt during the compressor's off-cycle. The water is then drained and evaporated.

- If excessive frost builds up, manually defrost the unit by unplugging it and leaving the door open until the frost melts.
- Do not use sharp objects to remove frost, as this can damage the cooling system.

Wiring Harness Check:

For advanced troubleshooting or maintenance, it may be necessary to inspect the wiring harness. This procedure should only be performed by qualified personnel.

▶ **Watch video online**
How to check the wiring harness

Video 5.1: How to check the wiring harness (provided by Erivess)

This video demonstrates the process of accessing and checking the wiring harness at the back of the refrigerator. This is an advanced maintenance step and should only be attempted by individuals with appropriate technical knowledge and safety precautions.

6. Troubleshooting

Before contacting customer service, please review the following common issues and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Refrigerator does not operate	No power; Plug not fully inserted; Circuit breaker tripped.	Check power supply; Ensure plug is secure; Reset circuit breaker.
Temperature is not cold enough	Temperature setting too high; Door opened too frequently; Poor ventilation; Excessive items loaded.	Adjust temperature dial to a colder setting; Minimize door openings; Ensure adequate space around unit; Reduce load.
Unusual noises	Unit not level; Items rattling inside; Normal compressor operation.	Adjust leveling legs; Rearrange items; Compressor noise is normal.
Water on floor	Drain tube blocked or dislodged; Excessive humidity.	Check and clear drain tube; Ensure proper ventilation.

7. Specifications

Feature	Detail
Product Dimensions (D x W x H)	11"D x 15"W x 16.5"H
Brand	Erivess
Capacity	0.95 Cubic Feet (approx. 20L)
Configuration	Compact Internal Freezer
Color	Black
Special Features	Adjustable Shelves, Compact, Energy Efficient, Frost Free, Portable
Installation Type	Freestanding/Countertop/Built-in
Number of Doors	1
Defrost System	Automatic
Voltage	110 Volts
Cooling Method	Compressor
Number Of Shelves	1
Adjustable Temperature Control	Yes
Door Orientation	Left (Reversible)
Item Weight	22.27 Pounds
Annual Energy Consumption	65 Kilowatt Hours
Model Number	HA601B-ES1

8. Warranty and Support

Warranty Information:

This Erivess refrigerator comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

Protection Plans:

Extended protection plans may be available for purchase separately:

- 2-Year Protection Plan
- 3-Year Protection Plan

For details on extended protection plans, please refer to the retailer where you purchased the product.

Customer Support:

If you have any questions, require technical assistance, or need to make a warranty claim, please contact Erivess customer support through the retailer's platform or visit the official Erivess store for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZJRQLJ2

More documents and user manuals: **https://manuals.plus/**