Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy C-2892-1B-BK-2P

Sweetcrispy Ergonomic Office Chair Instruction Manual

Model: C-2892-1B-BK-2P

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sweetcrispy Ergonomic Computer Gaming Office Chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

2. Safety Information

- This chair has a maximum weight recommendation of 275 pounds (125 kg). Do not exceed this weight limit.
- Always assemble the chair according to the instructions provided.
- Keep the chair away from heat sources and sharp objects to prevent damage to the material.
- Ensure all bolts and screws are tightened securely before use. Periodically check and re-tighten as necessary.
- Do not stand on the chair.
- Use the chair on a level surface.

3. Package Contents

Your package should contain the following items:

- 2 x Sweetcrispy Ergonomic Office Chair (disassembled components)
- All necessary hardware (screws, bolts, washers)
- Assembly tools (e.g., hexagonal wrench)
- Instruction manual

4. Setup and Assembly

Assembly of the Sweetcrispy Office Chair is designed to be straightforward, typically taking 15-20 minutes. All required hardware and tools are included. For optimal ease, it is recommended to have a second person assist, especially when attaching the backrest to the seat.

Assembly Steps:

1. Begin by assembling the chair base, attaching the rolling wheels to the heavy-duty nylon wheelbase.

2. Attach the gas lift cylinder to the base.
3. Secure the seat mechanism to the underside of the seat cushion.
4. Carefully align and attach the backrest to the seat cushion using the provided hardware. Assistance from a second person can simplify this step.
5. Place the assembled seat and backrest onto the gas lift cylinder.
6. Ensure all connections are tight and stable before using the chair.

5. Operating Instructions

Your Sweetcrispy Office Chair offers several adjustable features for personalized comfort and functionality.

5.1. Adjustable Height

To adjust the chair's height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at your desired height.



Figure 1: Adjustable Height Mechanism

5.2. Flip-up Armrests

The armrests are designed to flip up, allowing you to push the chair closer to your desk or to provide more flexibility and motion range when desired. Simply lift the armrests upwards until they lock into a vertical position. To lower them, pull them down.



Figure 2: Flip-up Armrests

5.3. Tilt Function and Lock

The chair features a tilt function with a position lock and 120° back adjustment. To recline, pull the same lever used for height adjustment outwards. To lock the chair in an upright position, push the lever inwards. The rocking pressure mechanism can be adjusted by turning the round knob located under the seat, allowing you to control the tension of the tilt.



Figure 3: Tilt Tension Knob



Figure 4: Tilt Lock Lever

5.4. 360° Swivel and Rolling Wheels

The chair features 360° swivel capability and smooth-rolling wheels, allowing for easy movement and rotation in your workspace.



Figure 5: Rolling Wheels



Figure 6: 360° Swivel

5.5. Ergonomic Design

The chair is designed with an ergonomic high back to support the cervical vertebrae, reducing back and spinal pain during prolonged sitting. It features segmented padded high back and seat with ultra cushioning, S-shape lumbar support, and hip and leg support.



Figure 7: Ergonomic Support Points

5.6. Product Overview Video

▶ **Watch video online**
Sweetcrispy PU Leather Office Chair with Flip-up Arms

Video 1: Sweetcrispy PU Leather Office Chair with Flip-up Arms - This video demonstrates the chair's features, including the flip-up armrests and overall design, from the manufacturer.

6. Maintenance

To ensure the longevity and appearance of your Sweetcrispy Office Chair:

- **Cleaning:** For the PU leather, wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the material.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the PU leather to fade or crack.
- **Protect from Sharp Objects:** Prevent punctures or tears by keeping sharp objects away from the chair's surface.

7. Troubleshooting

If you encounter any issues with your chair, consider the following common solutions:

- **Chair feels unstable:** Check all assembly screws and bolts. Ensure they are fully tightened.
- **Difficulty adjusting height:** Ensure the height adjustment lever is fully engaged or disengaged. If the gas lift is not responding, contact customer support.
- **Wheels not rolling smoothly:** Check for any debris (hair, dust) caught in the wheels. Clean them if necessary. Ensure the chair is on a suitable surface.
- **Squeaking noises:** Apply a small amount of lubricant to moving parts or re-tighten connections.

If problems persist, please refer to the warranty and support information.

8. Specifications

Feature	Specification
Brand	Sweetcrispy
Model Name	Ergonomic Computer Gaming Office Chair Set of 2
Model Number	C-2892-1B-BK-2P
Color	Inky Black
Material	Faux Leather (Seat & Back), Metal (Frame)
Product Dimensions (D x W x H)	21.66" x 21.87" x 44.5"
Item Weight	36.8 Pounds
Maximum Weight Recommendation	275 Pounds
Arm Style	Flip-up
Back Style	Split Back
Reclining Position Count	1 (with 120° back adjustment)
Included Components	2 x Office Chair
UPC	751074087199



Figure 8: Product Dimensions

9. Warranty and Support

The Sweetcrispy Ergonomic Office Chair comes with a one-year limited warranty from the manufacturer. For warranty claims, technical support, or any questions regarding your product, please contact Sweetcrispy customer service through your purchase platform or the official Sweetcrispy website.

Please have your model number (C-2892-1B-BK-2P) and proof of purchase ready when contacting support.

© 2026 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G2BWPD5M

More documents and user manuals: **https://manuals.plus/**