Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SYMIK SMK-BAK-ULTRA

SYMIK Carrying Case and Accessory Kit for Insta360 GO Ultra User Manual

Model: SMK-BAK-ULTRA

Introduction

This manual provides instructions for the SYMIK carrying case and accessory kit designed for the Insta360 GO Ultra camera. It covers the proper use, installation, and maintenance of the portable hard case, silicone lens cap, and screen protectors.

Package Contents

Before proceeding, please verify that all items listed below are present in your package.



Image description: The image displays the complete accessory bundle. It includes a mini storage carrying case, two carabiners, a wrist strap, two silicone lens protection caps, two tempered glass screen protectors, and two alcohol installation kits for the screen protectors.

- 1 x Mini Storage Carrying Case
- 2 x Carabiners
- 1 x Wrist Strap
- 2 x Silicone Lens Protection Caps
- 2 x Tempered Glass Screen Protectors
- 2 x Alcohol Installation Kits (for screen protectors)

Setup and Installation

Installing the Tempered Glass Screen Protector

1. Use the provided alcohol wipe (Wipes 1) to clean the camera screen thoroughly.
2. Use the dry wipe (Wipes 2) to dry the screen completely.
3. Use the dust absorber to remove any remaining dust particles.

4. Carefully peel off the protective film from the screen protector (Step 1).
5. Align the screen protector with the camera screen.
6. Gently place the screen protector onto the screen, allowing it to adhere. Smooth out any bubbles.
7. Remove the top protective film (Step 2).



Image description: This image illustrates the tempered glass screen protectors. One protector is shown applied to the Insta360 GO Ultra camera screen, highlighting its clear finish and precise fit. Another part of the image shows two screen protectors alongside the alcohol wipes, dry wipes, and dust absorbers included in the installation kit.

Installing the Silicone Lens Protective Cover

1. Ensure the camera lens is clean and free of dust.
2. Gently stretch the silicone lens cover over the camera lens.
3. Adjust the cover to ensure a snug and secure fit, protecting the lens from scratches and wear.



Image description: The image displays the Insta360 GO Ultra camera with a black silicone lens protective cover securely fitted over the lens. This cover is designed to be anti-fall, wear-resistant, and anti-scratch, providing comprehensive protection for the camera lens during daily use.

Operating Instructions

Using the Mini Storage Carrying Case

1. Open the carrying case using the dual zipper design.
2. Place your Insta360 GO Ultra camera inside the case. The case features a raised design around the lens area to prevent jamming and ensure a perfect fit.
3. Secure the camera using the built-in elastic bandage to prevent movement during transport.
4. Close the case using the dual zippers. The dual zipper design allows for easy access and secure closure.



Image description: This image demonstrates the internal security feature of the carrying case. A hand is shown placing the Insta360 GO Ultra camera into the case, and an elastic bandage is visible, designed to tightly lock the camera in place for secure protection during transport.



Image description: This image illustrates the design features of the carrying case. It shows the case's interior with a raised area for the camera lens, ensuring a perfect fit. The image also highlights the case's shockproof, wear-resistant, and splash-proof properties, demonstrating its robust protection against elements.

Compatibility with Accessories

The carrying case is designed with thoughtful reserved space, allowing the Insta360 GO Ultra to be stored even when equipped with silicone sleeves or rabbit cages (not included).



Image description: This image demonstrates the carrying case's compatibility. It shows the Insta360 GO Ultra camera stored inside the case, first with an aluminum cage (not included) and then with a silicone sleeve (not included), illustrating how the case accommodates the camera with these additional accessories.

Carrying Options

The portable design of the case offers multiple carrying options:

- Attach to backpack buckles using the carabiners.
- Store inside a larger bag or pouch.
- Carry by hand.
- Hang on the chest using a lanyard (lanyard not included).



Image description: This image illustrates the versatility of the carrying case for different occasions. It shows the case being clipped onto backpack buckles, fitting inside a larger bag, being carried by hand, and hanging on the chest (lanyard not included), demonstrating its adaptability for transport.

Maintenance and Care

Carrying Case

To clean the exterior of the carrying case, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure the case is dry before storing your camera.

Silicone Lens Cap

The silicone lens cap can be rinsed with water and air-dried. Ensure it is completely dry before placing it back on the camera lens.

Screen Protectors

Once applied, clean the screen protector with a soft, lint-free cloth. Avoid excessive pressure.

Troubleshooting

If you encounter any issues with the product, please refer to the following common solutions:

- **Camera not fitting in case:** Ensure the camera is oriented correctly and any additional accessories (like cages or sleeves) are compatible with the case's internal dimensions. The case is designed for the Insta360 GO Ultra.
- **Screen protector bubbles:** During installation, ensure the screen is thoroughly cleaned and free of dust. Use a soft card or finger to gently push out any small bubbles towards the edges.
- **Lens cap loose:** Ensure the silicone lens cap is correctly aligned and fully seated over the camera lens.

For further assistance, please contact SYMIK customer support.

Specifications

Feature	Detail
Model Number	SMK-BAK-ULTRA
Dimensions	10.9 x 8.6 x 4.9 cm
Item Weight	90 Grams
Material	Polyurethane (PU), Ethylene-vinyl acetate (EVA)
Closure Type	Zipper
Case Type	Hard Case
Color	Black

Warranty and Support

Warranty Information

This product is covered by the standard warranty provided by SYMIK. Please refer to the product packaging or the official SYMIK website for specific warranty terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, product inquiries, or warranty claims, please contact SYMIK customer support. Contact details can typically be found on the SYMIK official website or on the product packaging.

© 2026 SYMIK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GCCZMNSP

More documents and user manuals: **https://manuals.plus/**