Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave N7090002238

Bellemave Queen Over Queen Bunk Bed Instruction Manual

Model: N7090002238
Brand: Bellemave

1. Important Safety Information

Please read and understand all instructions before beginning assembly and use of this bunk bed. Keep this manual for future reference.

- **Maximum Weight Capacity:** The upper bunk and lower bunk each have a maximum weight capacity of 600 pounds. Do not exceed this limit.
- **Guardrails:** The upper bunk is equipped with guardrails for safety. Ensure they are properly installed and secured at all times.
- **Mattress Thickness:** For the upper bunk, use a mattress no thicker than 6 inches. For the lower bunk, use a mattress between 8-10 inches thick.
- **Assembly:** Assembly should be performed by at least two adults. Ensure all hardware is tightened securely before use. Periodically check and re-tighten all connections.
- **No Box Spring Needed:** This bunk bed features an integrated wood slat system designed to support mattresses directly, eliminating the need for a box spring.
- **Children's Safety:** Do not allow children under 6 years of age on the upper bunk. Always use the ladder for access to the upper bunk.

2. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact Bellemave customer support.

- Bed Frame Components (Headboards, Footboards, Side Rails, Ladder, Slats)
- Storage Shelves
- USB Ports and Power Outlets Unit
- All necessary assembly tools
- Installation Manual (separate detailed guide)
- Hardware Pack (screws, bolts, nuts, etc.)

3. Setup and Assembly Instructions

This bunk bed requires assembly. A detailed installation manual with step-by-step diagrams is included in your package. Please follow those instructions carefully.

General Assembly Steps:

1. **Unpack and Organize:** Lay out all parts on a clean, soft surface (like a carpet) to prevent scratches. Identify each component using the parts list in the detailed manual.
2. **Assemble Main Frame:** Begin by connecting the headboards and footboards to the side rails for both the upper and lower bunks.
3. **Install Slats:** Secure the wooden slats onto the bed frames. Ensure they are evenly spaced and firmly attached.
4. **Attach Ladder:** Securely fasten the ladder to the bunk bed frame as indicated in the manual.
5. **Install Storage Shelves:** Attach the storage shelves to the designated areas on both the upper and lower bunks.
6. **Integrate Charging Station:** Install the USB ports and power outlets unit into the pre-drilled slots. Connect the power cord.
7. **Final Check:** Once assembled, ensure all bolts, screws, and connections are tight and secure. Do not use power tools for tightening to avoid overtightening and damaging the wood.



Image: Empty Bellemave Queen Over Queen Bunk Bed frame, front view, showing the structure before mattresses and accessories are added.



Image: Close-up view of the Bellemave bunk bed frame, highlighting the wooden slats and sturdy construction.

4. Operating Instructions

Using the Storage Shelves:

The bunk bed is equipped with convenient storage shelves on both the upper and lower bunks. These shelves are designed to hold books, small electronics, decorative items, and other personal belongings. Ensure items are placed securely and do not obstruct movement or pose a falling hazard.



Image: Bellemave bunk bed with items on the storage shelves, viewed from the side, showcasing the integrated shelving.

Using the Dual-Level Charging Stations:

This bunk bed includes a charging station on both the upper and lower bunks, featuring standard electrical outlets and USB ports. To use:

1. Ensure the bunk bed's main power cord is plugged into a functional wall outlet.
2. Plug your electronic devices (phones, tablets, laptops, lamps) into the available USB ports or electrical outlets.
3. Always ensure cords are neatly managed to prevent tripping hazards or damage.



Image: Bellemave bunk bed with a close-up highlighting the integrated charging station with USB ports and electrical outlets.



Image: Detailed close-up of the power outlet and USB ports integrated into the bunk bed's shelf.

5. Maintenance

- **Cleaning:** Wipe down the bed frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Re-tighten any loose hardware to ensure the bed remains stable and safe.
- **Slat Inspection:** Check the wooden slats for any signs of damage or cracking. Replace any damaged slats immediately to maintain mattress support.
- **Electrical Components:** Ensure the power cord for the charging station is not pinched or damaged. If the charging station malfunctions, unplug it immediately and contact customer support.

6. Troubleshooting

- **Bed feels wobbly:** Check all assembly hardware. Ensure every bolt and screw is securely tightened. If the issue persists, disassemble and reassemble carefully, ensuring all parts are correctly aligned.
- **Charging station not working:**
  - Verify the main power cord is firmly plugged into a functional wall outlet.
  - Check if the wall outlet itself is working by plugging in another device.
  - Ensure the charging unit is properly seated in its designated slot on the bed frame.
  - If still not working, contact customer support. Do not attempt to repair electrical components yourself.
- **Missing parts:** Refer to the package contents list. If any parts are missing upon delivery, contact Bellemave customer support with your purchase details.

7. Specifications

Feature	Detail
Model Number	N7090002238
Size	Queen/Queen
Product Dimensions (L x W x H)	82.18"L x 65.1"W x 65.9"H
Material	Engineered Wood, Pine Wood
Color	White
Style	Modern
Special Features	Storage Shelves, USB Port, Plug Outlets
Maximum Weight Recommendation (Each Bunk)	600 Pounds
Upper Bed Support	14 Solid Wood Slats
Recommended Upper Mattress Thickness	6 inches
Recommended Lower Mattress Thickness	8-10 inches
Box Spring Required	No
Item Weight	158.6 Pounds
Required Assembly	Yes




Image: Diagram showing the dimensions of the Bellemave Queen Over Queen Bunk Bed in inches: 82.2 inches length, 65.1 inches width, and 65.9 inches height.

8. Warranty and Support

For warranty information, product support, or to order replacement parts, please contact Bellemave customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Contact Information: Please refer to the contact information provided with your original purchase or visit the official Bellemave website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GDW6CQNW

More documents and user manuals: **https://manuals.plus/**