Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee HJS-GV-GrillTent-2Side-Claret-0z

Garvee 8x5 Grill Gazebo Outdoor BBQ Canopy Instruction Manual

Model: HJS-GV-GrillTent-2Side-Claret-0z

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Garvee 8x5 Grill Gazebo Outdoor BBQ Canopy. Please read this manual thoroughly before attempting to assemble or use the product to ensure safe and correct operation. Keep this manual for future reference.

Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always keep the gazebo at least 3 feet away from any heat sources or open flames.
- Do not use the included light in rain or damp conditions.
- Always follow the assembly and disassembly instructions carefully.
- Secure the gazebo to the ground using the included metal stakes to prevent it from tipping over, especially in windy conditions.
- This gazebo is designed for outdoor use only and should not be used in enclosed spaces.

Package Contents

Before assembly, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer service.

- Steel Frame Components (legs, beams, connectors)
- Double-Tier Canopy Fabric
- Adjustable Dual Side Awnings
- 2 Ventilated Metal Side Shelves
- 7 Utility Hooks
- Ceiling Light Hook
- 8 Metal Ground Stakes
- Assembly Hardware (bolts, nuts, washers, tools)
- Instruction Manual

Setup and Assembly

Assembly typically requires two adults. Follow the steps below carefully. Refer to the diagrams in the included printed manual for visual guidance.

1. **Unpack and Identify Parts:** Lay out all components on a clean, flat surface. Compare each part with the parts list to ensure everything is present.
2. **Assemble the Main Frame:** Connect the leg posts to the top beams using the provided hardware. Ensure all connections are secure but do not fully tighten bolts until the entire frame is assembled.
3. **Install Side Awnings:** Attach the side awning frames to the main frame. The awnings are designed for multi-angle adjustment.
4. **Attach Canopy Fabric:** Drape the double-tier canopy fabric over the assembled frame. Secure the canopy to the frame using the integrated fasteners. Ensure the top tier is properly seated for ventilation.
5. **Install Side Shelves and Hooks:** Mount the two ventilated metal side shelves to the designated locations on the frame. Attach the utility hooks to the shelves.
6. **Secure to Ground:** Once the gazebo is fully assembled, use the 8 included metal ground stakes to firmly anchor each leg to the ground. This is crucial for stability, especially in windy conditions.
7. **Final Tightening:** Go back and fully tighten all bolts and connections on the frame.



Image: Grill Tent Size Details. This diagram illustrates the overall dimensions of the gazebo, including height, length, and width, to assist with placement and assembly.



Image: Multi-Angle Adjustment. This image highlights the three adjustable height settings for the side awnings, allowing users to control the desired shade level.



Image: Little Details You Love. This image showcases practical features such as the built-in bottle opener, mesh placement shelves, integrated hooks for utensils, and the magnetic LED lights.

Operating Instructions

Your Garvee Grill Gazebo is designed for ease of use and functionality.

- **Adjusting Side Awnings:** The dual side awnings can be adjusted to three different angles. Simply push or pull the awning frame to the desired position until it locks into place. This allows you to customize shade coverage based on sun direction.
- **Using Side Shelves and Hooks:** The two ventilated metal side shelves provide convenient surfaces for placing food, drinks, and grilling accessories. Use the integrated hooks to hang grilling tools, towels, or other items for easy access.
- **Ceiling Light Hook:** A built-in hook is located at the center of the gazebo ceiling. This can be used to hang a light, fan, or decorative item (light fixture not included).
- **Ventilation:** The double-tier canopy design promotes air circulation and allows smoke to escape easily, enhancing comfort while grilling.

▶ **Watch video online**

The bbq tent brings warm moments to the whole family.

Video: The BBQ Tent. This short video demonstrates the gazebo in use, highlighting its features and how it enhances outdoor grilling experiences.

Maintenance

Regular maintenance will extend the life of your grill gazebo.

- **Cleaning Canopy Fabric:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners, as this may damage the fabric's protective coating. Allow to air dry completely before storage.
- **Frame Inspection:** Periodically inspect the steel frame for any signs of rust, loose connections, or damage. Tighten any loose bolts. If rust appears, clean the area and apply a rust-inhibiting paint.
- **Securing the Gazebo:** Always ensure the gazebo is securely anchored to the ground with the provided stakes. In anticipation of strong winds or severe weather, it is recommended to remove the canopy fabric to prevent damage.
- **Storage:** During off-seasons or prolonged periods of non-use, disassemble the gazebo and store all components in a dry, protected area to prevent weather damage and extend product lifespan.

Troubleshooting

If you encounter issues with your Garvee Grill Gazebo, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Gazebo feels unstable or wobbly.	Loose connections; inadequate anchoring.	Ensure all bolts are fully tightened. Verify ground stakes are firmly inserted and secure. Consider additional anchoring in very windy areas.
Canopy fabric does not fit correctly or sags.	Incorrect assembly of frame or canopy.	Review assembly steps for the frame and canopy. Ensure the canopy is stretched taut and all fasteners are properly secured to the frame.
Side awnings do not adjust smoothly.	Mechanism obstruction or damage.	Check for any debris or obstructions in the awning adjustment mechanism. Ensure the frame is not bent. Apply a silicone-based lubricant if necessary.
Water pooling on canopy.	Canopy not taut enough or improper installation.	Ensure the canopy is installed correctly and stretched tightly across the frame to allow water runoff.

Specifications

- **Brand:** Garvee
- **Model Number:** HJS-GV-GrillTent-2Side-Claret-0z
- **Material:** Metal (Frame), Polyester (Canopy)
- **Product Dimensions (L x W x H):** 203.94" x 48.03" x 97.24" (approximately 8 ft x 5 ft x 8.1 ft)
- **Item Weight:** 61.73 Pounds
- **Water Resistance Level:** Water Resistant

- **Ultraviolet Light Protection:** UPF 100
- **Assembly Required:** Yes
- **Floor Area:** 40 Square Feet

Warranty and Support

Garvee stands behind the quality of its products. For specific warranty details, claims, or technical assistance, please refer to the warranty card included with your purchase or contact Garvee customer service directly. Please have your model number (HJS-GV-GrillTent-2Side-Claret-0z) and purchase date available when contacting support.
Contact Information: Please visit the official Garvee website or refer to your purchase documentation for the most current customer service contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GKSHBMWY

More documents and user manuals: **https://manuals.plus/**