Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EazeHome Extendable Dining Room Table

EazeHome Extendable Dining Table User Manual

Model: Extendable Dining Room Table

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your EazeHome Extendable Dining Table. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.

The EazeHome Extendable Dining Table is designed to comfortably seat 8-10 people, featuring a modern design with U-shaped wooden legs and a smooth hidden lift system for easy extension. Its durable MDF material with water-proof resistance ensures long-lasting service.

2. Safety Information

WARNING:

- Always follow assembly instructions carefully.
- Do not exceed the maximum weight capacity of 300 lbs to ensure stability and prevent accidents.
- Keep small parts away from children during assembly.
- Ensure all screws and bolts are securely tightened before use.
- Do not stand or sit on the table.
- Use caution when extending or retracting the table to avoid pinching fingers.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact EazeHome customer support.

- Tabletop components
- U-shaped wooden legs
- Assembly Tools (e.g., Hex Key, Screwdriver)
- Assembly Guide (this manual)
- All necessary screws, bolts, and fasteners



Image: All components of the EazeHome Extendable Dining Table laid out for assembly.

4. Assembly Instructions

Assembly is recommended for two people. Please follow these steps carefully.

1. **Attach Legs:** Securely attach the U-shaped wooden legs to the tabletop frame using the provided screws. Ensure they are oriented correctly as per the diagrams.
2. **Tighten Fasteners:** Use the provided tools (hex key, screwdriver) to tighten all screws and bolts. Do not overtighten.
3. **Insert Tabletop Support Brackets:** Place the tabletop support brackets into the pre-drilled holes on the underside of the table.
4. **Secure Legs to Brackets:** Fasten the legs to these brackets using the included hex bolts.
5. **Final Positioning:** Once all connections are secure, carefully flip the table upright.



Image: Diagram illustrating the assembly process for the dining table.

5. Operating Instructions: Extending and Retracting the Table

The EazeHome Extendable Dining Table features a smooth hidden lift system for easy adjustment.

5.1. To Extend the Table:

1. **Unlock the Buckle:** Locate and unlock the secure clamps beneath the tabletop. These latches secure the center leaf.
2. **Pull Apart Tabletop:** Gently pull the two halves of the tabletop away from each other. The smooth slides will allow them to separate effortlessly and noiselessly.
3. **Place the Hidden Panel:** Retrieve the hidden extension panel from its storage compartment (if applicable, or place the separate leaf). Position it in the gap created.
4. **Close and Lock:** Push the tabletop halves back together until they meet the extension panel. Secure the tabletop by engaging the clamps beneath. This creates a zero-gap board joint.



Image: Visual guide for extending the dining table.

5.2. To Retract the Table:

1. **Unlock the Buckle:** Unlock the secure clamps beneath the tabletop.
2. **Separate Tabletop:** Gently pull the tabletop halves apart to create a gap.
3. **Remove Hidden Panel:** Carefully remove the extension panel and store it in its designated compartment (if available) or a safe place.
4. **Close and Lock:** Push the tabletop halves back together until they meet. Engage the secure clamps to lock the table in its retracted position.

6. Maintenance

Proper care will ensure the longevity and appearance of your dining table.

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.

- **Spills:** Clean spills immediately to prevent staining, especially on the water-resistant MDF surface.
- **Protection:** Use placemats or coasters to protect the surface from hot items, scratches, and spills.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or warping.



Image: Detail of the thickened tabletop, showing its durable construction.

7. Troubleshooting

If you encounter any issues with your EazeHome Extendable Dining Table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly	Loose fasteners or uneven floor.	Check and tighten all assembly screws and bolts. Ensure the table is on a level surface.
Tabletop difficult to extend/retract	Clamps are engaged or slides are obstructed.	Ensure all secure clamps are disengaged. Check slides for any debris and clear if necessary. Apply a silicone-based lubricant if slides are stiff.
Gap between tabletop sections	Clamps not fully engaged or extension panel not seated correctly.	Ensure the extension panel is properly aligned and fully seated. Engage all secure clamps firmly.

8. Specifications

Feature	Detail
Brand	EazeHome
Model Name	Extendable Dining Room Table
Product Dimensions (Retracted)	70.9"W x 31.5"D x 29.5"H
Product Dimensions (Extended)	86.6"W x 31.5"D x 29.5"H
Maximum Weight Capacity	300 lbs

Feature	Detail
Frame Material	Wood
Top Material Type	Engineered Wood (MDF)
Color	Walnut Brown
Seating Capacity (Retracted)	8 people
Seating Capacity (Extended)	10 people
Special Features	Silent Glides, Wooden U-shaped Legs, Zero-gap board joint



Image: Product dimensions for the EazeHome Extendable Dining Table.

9. Warranty and Support

EazeHome is committed to providing high-quality products. For any questions regarding assembly, missing parts, or product functionality, please contact EazeHome customer support. Please refer to your purchase documentation for specific warranty details.

Contact Information: Refer to your purchase receipt or the EazeHome official website for customer service contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GNG337WV

More documents and user manuals: **https://manuals.plus/**