Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Erivess HA301B-02

Erivess Countertop Ice Maker Machine

Model: HA301B-02 User Manual

Introduction

Thank you for choosing the Erivess Countertop Ice Maker Machine. This appliance is designed to provide fresh bullet-shaped ice quickly and efficiently for your home, office, or recreational vehicle. Please read this manual thoroughly before operating your new ice maker to ensure safe use, optimal performance, and longevity of the product. Keep this manual for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Ensure the appliance is placed on a stable, level surface away from direct sunlight or heat sources.
- Always unplug the appliance before cleaning, servicing, or when not in use.
- This appliance is for household use only. Do not use outdoors.
- Keep children away from the ice maker.
- Use only potable water in the water reservoir.
- Do not block ventilation openings on the appliance.

Package Contents

Upon unpacking, please ensure all items listed below are present and in good condition:

- Erivess Countertop Ice Maker Machine

- Ice Basket
- Ice Scoop
- User Manual

Note: The product may also include shovels, a water inlet pipe, and a water outlet pipe as specified by the manufacturer.

Product Features

- **Fast Ice Production:** Produces 9 bullet-shaped ice cubes in 5-8 minutes, with a capacity of up to 26 lbs of ice per 24 hours.
- **Quiet Operation:** Operates at less than 40dB, ensuring a peaceful environment.
- **Compact and Portable Design:** Weighs approximately 15 lbs with dimensions of 10.6"(L) x 8.7"(W) x 11"(H), making it suitable for various locations.
- **Two Ice Cube Sizes:** Offers small and large bullet-shaped ice cubes to suit different beverage needs.
- **Smart Operation:** Features "ADD WATER" and "ICE FULL" indicators for convenient monitoring and automatic shut-off.
- **One-Touch Self-Cleaning:** Simplifies maintenance with an automatic cleaning function.
- **Transparent Visual Window:** Allows easy viewing of the ice-making process and ice level.
- **Energy Efficient:** Equipped with a 280W compressor for efficient ice production.



Image: Erivess Countertop Ice Maker Machine, black model, showcasing its compact design.

Setup Guide

1. **Unpack and Inspect:** Carefully remove the ice maker from its packaging. Check for any shipping damage and ensure all accessories are present.
2. **Placement:** Place the ice maker on a flat, stable, and level surface. Ensure there is at least 4 inches of clearance around the unit for proper ventilation. Avoid placing it near heat sources or in direct sunlight.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance and Cleaning" section for detailed instructions.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet (110V).
5. **Add Water:** Open the water reservoir lid and fill it with potable water up to the "MAX" fill line. Do not overfill.



Image: Illustration showing how to add water to the ice maker's reservoir.

Operating Instructions

1. **Power On:** After adding water, press the **"ON/OFF"** button on the control panel to start the ice-making cycle. The power indicator light will illuminate.
2. **Select Ice Size:** Press the **"SELECT"** button to choose between small (S) or large (L) ice cubes. The corresponding indicator light will turn on.
3. **Ice Production:** The ice maker will begin producing ice. The first batch of ice cubes will be ready in approximately 5-8 minutes.
4. **Ice Full Indicator:** When the ice basket is full, the **"ICE FULL"** indicator will flash, and the ice maker will automatically pause operation. Remove ice from the basket to resume ice production.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the **"ADD WATER"** indicator will flash. Add

more potable water to the reservoir to continue ice production.

6. **Power Off:** To stop the ice maker, press the**"ON/OFF"** button again.



Image: Close-up of the Erivess ice maker control panel with "ON/OFF", "SELECT", "ADD WATER", and "ICE FULL" indicators.



Image: Diagram illustrating the two available ice cube sizes (small and large bullet ice) and their typical uses.

▶ **Watch video online**

Self-Cleaning Ice Makers, 9 Bullet Cubes Ready in 6 Mins

Video: Official Erivess video demonstrating the self-cleaning function and rapid ice production of the ice maker.

Maintenance and Cleaning

Self-Cleaning Function

1. Ensure the ice maker is empty of ice and water.
2. Fill the water reservoir with clean, potable water up to the "MAX" line.
3. Press and hold the **"ON/OFF"** button for 5 seconds. The self-cleaning cycle will begin.

4. The cleaning cycle will run for several minutes. Once complete, drain the water from the unit.
5. Repeat the cycle with fresh water if desired for a more thorough rinse.

General Cleaning

- Always unplug the ice maker before cleaning.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Remove the ice basket and wash it with mild soap and warm water. Rinse thoroughly.
- Clean the interior water reservoir and ice-making components with a soft cloth and a solution of water and mild vinegar (1:1 ratio) to prevent mineral buildup. Rinse thoroughly with clean water afterward.
- Ensure all parts are dry before reassembling and operating the ice maker.



Image: Visual guide demonstrating the steps for activating the automatic cleaning function of the ice maker.

Troubleshooting Guide

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; "ADD WATER" indicator flashing.	Fill the water reservoir with potable water.
Ice maker stopped, "ICE FULL" indicator flashing.	Ice basket is full.	Remove ice from the basket. Ice production will resume automatically.
Ice cubes are too small or not forming properly.	Water temperature is too high; ambient temperature is too high.	Use colder water. Place the ice maker in a cooler environment. Ensure proper ventilation.

Problem	Possible Cause	Solution
Unusual noise during operation.	Unit not level; internal components vibrating.	Ensure the ice maker is on a flat, stable surface. If noise persists, contact customer support.
Water leakage.	Drain plug not properly sealed; unit overfilled.	Check the drain plug at the bottom of the unit. Do not overfill the water reservoir.

Product Specifications

Feature	Detail
Brand	Erivess
Model Name	HA301B-02
Product Dimensions (L x W x H)	10.6" x 8.7" x 11"
Ice Production Capacity	26 lbs per 24 hours
First Batch Ice Time	5-8 minutes
Water Tank Capacity	1.2 Liters (approx.)
Wattage	280 watts
Voltage	110 volts
Item Weight	15 pounds
Refrigerant	R290a
Material Type	Stainless Steel



Image: Diagram showing the internal layers and components of the Erivess ice maker, including the insulation layer and exhaust fan.

Warranty and Customer Support

Erivess is committed to providing high-quality products and customer satisfaction. This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. We offer lifetime technical service support for your Erivess ice maker. If you encounter any quality issues or require assistance, our dedicated customer service team is available to respond promptly within 24 hours.
For support, please contact us via the contact information provided on your warranty card or through the Erivess official website.

© 2023 Erivess. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GSZKPTY5

More documents and user manuals: **https://manuals.plus/**