Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cricut 8003319

Cricut Maker® 5 Ultimate Bundle Instruction Manual

Model: 8003319 | Brand: Cricut

Introduction

The Cricut Maker® 5 is an advanced smart cutting machine designed for a wide range of creative projects. This ultimate bundle includes the machine, a Mini Heat Press, and various supplies to help you get started with up to 135 projects immediately. It is capable of working with over 300 materials and supports 13 different tools for cutting, engraving, writing, drawing, foiling, scoring, and debossing.
This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Cricut Maker® 5 Ultimate Bundle.

Package Contents

Your Cricut Maker® 5 Ultimate Bundle includes:

- Cricut Maker® 5 Machine (Slate Blue)
- Cricut EasyPress Mini™ LT Heat Press
- Assortment of tools: Premium Fine Point Cutting Tool (2), Scoring Tool, Engraving Tool, Deep Cutting Tool, Knife Blade, Rotary Blade, Scraper, Reverse Tweezers, Weeder, Spatula, Scissors, Portable Trimmer & Paper Ruler
- Variety of materials: Smart Vinyl, Smart Iron-On, Value Cardstock, Insert Card Sets, Printable Vinyl, Transfer Tape
- Light Grip Machine Mat (2) & Card Mat
- Dual-Sided Marker (Black), Markers (Metallic Gold, Acrylic White)
- Digital Content (available in Cricut Design Space app)

Ready for any project*

Bundle includes specialty machine tools, materials, and a heat press



Cricut Maker® 5
Slate Blue



Premium Fine Point Cutting Tool (2)** & Scoring Tool



Engraving Tool & Deep Cutting Tool



Knife blade



Rotary Blade



Cricut EasyPress Mini™ LT in Blue



Pressing Mat



Scraper, Reverse Tweezers, Weeder, Spatula, Scissors



Portable Trimmer & Paper Ruler

*Based on 4 in x 6 in (10.2 cm x 15.2 cm) average size using included materials
**Tools shown may differ in box. All machines include pre-installed cutting blade—either with metal housing or new all-in-one Cutting Tool
†Digital Content provided online via Cricut Design Space app only

Image: Overview of the Cricut Maker 5 Ultimate Bundle contents, including the machine, various tools, and materials.



Image: A selection of materials included in the bundle, such as Smart Vinyl, Smart Iron-On, cardstock, and printable vinyl, enabling up to 135 projects.

Setup

1. **Unboxing:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the Cricut Maker® 5 on a stable, flat surface with adequate space around it for material loading and operation.
3. **Power Connection:** Connect the power adapter to the machine and then to a wall outlet.
4. **Initial Setup & Software:**
    - Turn on the machine.
    - Download and install the Cricut Design Space app on your compatible computer or mobile device.
    - Follow the on-screen instructions in Design Space to register your machine and complete the initial setup, including connecting via Bluetooth® wireless.

- Access your included digital content within the Design Space app after registration.

Your browser does not support the video tag.

Video: An official overview of the Cricut Maker 5, demonstrating its features and capabilities. This video provides a visual guide to understanding the machine's potential.

Operating Instructions

1. Design Your Project

Use the Cricut Design Space app to create or select your project. The app offers a vast library of images, fonts, and templates. You can also upload your own designs. Ensure your design is finalized before proceeding to cutting.



Image: A laptop and mobile device displaying the Cricut Design Space interface, highlighting the ease of designing projects.

2. Prepare Materials and Tools

- **Material Selection:** The Cricut Maker® 5 works with over 300 materials, from delicate fabrics and paper to thicker items like wood, leather, and foam core board.
- **Tool Insertion:** Select the appropriate tool for your material and desired action (cut, engrave, score, etc.). The machine features a hassle-free snap-in pen holder and supports 13 different tools.
- **Mat Preparation:** Place your chosen material onto the correct Cricut mat (Light Grip, Standard Grip, Strong Grip, or Fabric Grip) as recommended by Design Space.



Image: A variety of Cricut Maker 5 tools, including blades for cutting, engraving, and scoring, demonstrating the machine's versatility.



Image: A hand holding a leather keychain, illustrating the Cricut Maker 5's ability to cut thicker materials up to 3mm.

3. Load and Start

- Load the mat with your material into the machine.
- Follow the prompts in Design Space to begin the cutting or crafting process.



Image: A four-step visual guide showing the process: Design, Cut, Assemble, and the final product, demonstrating how the Cricut Maker 5 works.

4. Print-Then-Cut Feature

The Cricut Maker® 5 includes a Print-Then-Cut sensor, allowing you to print designs on your home printer and then have the Cricut machine precisely cut them out. This is ideal for full-color stickers, decals, and more.



Image: A hand applying a custom-cut sticker, showcasing the full-color possibilities of the Print-Then-Cut feature.

5. Cricut EasyPress Mini™ LT

Use the included Cricut EasyPress Mini™ LT for heat transfer projects, such as applying iron-on designs to apparel or small, intricate items. Refer to the EasyPress Mini™ LT specific instructions for temperature and time settings.

Maintenance

- **Cleaning the Machine:** Regularly wipe down the exterior of your Cricut Maker® 5 with a soft, dry cloth. Keep the cutting area free of debris.
- **Mat Care:** Clean your cutting mats periodically to maintain their stickiness. Use a scraper to remove small pieces of material.
- **Blade Maintenance:** Replace blades when they become dull to ensure precise cuts. Store blades safely when not in use.
- **Software Updates:** Ensure your Cricut Design Space software is always up-to-date for optimal performance and

access to new features.

Troubleshooting

If you encounter issues with your Cricut Maker® 5, consider the following common solutions:

- **Connectivity Issues:** Ensure Bluetooth® is enabled on your device and the machine is within range. Try restarting both the machine and your device.
- **Cutting Problems:**
  - If cuts are not clean, check if the blade needs replacement or if the correct material setting is selected in Design Space.
  - Ensure the material is properly adhered to the cutting mat.
- **Software Glitches:** Close and reopen the Design Space app. If the problem persists, check for software updates or reinstall the application.
- **Machine Not Responding:** Turn the machine off and on again. If the issue continues, disconnect and reconnect the power cable.

For more detailed troubleshooting or persistent issues, please refer to the official Cricut support resources.

Specifications

Feature	Detail
Brand	Cricut
Model Number	8003319
Color	Slate Blue
Operation Mode	Automatic
Max Cut Width	12 in (30.5 cm)
Material Compatibility	300+ materials (e.g., vinyl, iron-on, cardstock, fabric, wood, leather, foam core)
Supported Tools	13 tools (cut, engrave, write, draw, foil, score, deboss, etc.)
Connectivity	Bluetooth® wireless, High-speed internet connection required
Dimensions	30% more compact than previous models
UPC	093573524080



Make with thicker materials

Cuts and engraves materials up to 3 mm.*

*For compatible materials see cricut.com/materials

Image: A diagram highlighting key features of the Cricut Maker 5, including the snap-in pen holder, compatibility with 13+ tools, 300+ materials, 30% more compact design, and Print-Then-Cut sensor.

Compare Machines

	 Cricut Joy™ 2 Ultra-compact machine for quick, everyday projects	 Cricut Joy Xtra™ Compact cutting machine with full-size possibilities	 Cricut Explore® 5 12-inch cutting machine that makes in multiples	 Cricut Maker® 5 Our ultimate cutting machine with maximum versatility
Max Cut Width	4.5 in (11.4 cm)	8.5 in (21.6 cm)	12 in (30 cm)	12 in (30 cm)
What You Can Make	• Full-color stickers • Cards • Decals • Apparel & more	• Full-color stickers • Cards • Decals • Apparel & more	• Full-color stickers • Cards • Banners • Apparel • Jewelry & more	• Full-color stickers • Cards • Banners • Apparel • Jewelry • Wood decor • Engraving & more
Material Compatibility	75+ materials	75+ materials	100+ materials	300+ materials
Machine Tools	4	4	6	13
Machine Capabilities	• Cut • Write • Draw • Foil • Score	• Cut • Write • Draw • Foil • Score	• Cut • Write • Draw • Foil • Score	• Cut • Write • Draw • Foil • Score • Engrave • Deboss • & more

Image: A comparison table showing different Cricut machines, highlighting the Cricut Maker 5's maximum versatility, 12-inch cut width, 300+ material compatibility, and 13 machine tools.

Warranty Information

The Cricut Maker® 5 Ultimate Bundle comes with a Limited Warranty. For complete terms and conditions, please visit the official Cricut website or contact the manufacturer or an authorized regional representative at the applicable address.

Support

For assistance with your Cricut Maker® 5, including technical support, project ideas, and community engagement, please utilize the following resources:

- **Cricut Design Space App:** Your primary resource for design, project management, and machine operation.
- **Cricut Access™ Subscription:** Unlock the full content library and certain software features with a paid subscription.

- **Official Cricut Website:** Visit cricut.com for FAQs, tutorials, and contact information for customer support.
- **Cricut Community:** Connect with other Cricut users for inspiration and tips.



Image: A smiling customer service representative, symbolizing the availability of Cricut Member Care for support and assistance.



Image: A collage of diverse individuals, representing the supportive Cricut community available to assist users on their creative journey.

© 2023 Cricut. All rights reserved. Cricut® and Cricut Maker® are registered trademarks of Cricut, Inc.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Cricut, Inc. is under license.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0HDQV56VQ

More documents and user manuals: **https://manuals.plus/**