🌿 Manuals+

☰

ASTI LectroFan Micro2 Plus Sleep Sound Machine User Guide 📄

Contents [hide]

ASTI

## ASTI LectroFan Micro2 Plus Sleep Sound Machine

OVERVIEW

1. Microphone

2. Previous Track / Sound

3. Volume Down/Up

4. Play / Pause, Answer / Hang Up / Redial

5. Next Track / Sound

6. Indicator Lamp

7. Charging Port

8. Power Switch (left–right):

Off / Arrêt / Aus / Off

Charge Your Micro2 Before First Use

Connect the Micro2 to a USB power source using the supplied cable. The indicator lamp will glow red, then change to green when fully charged. A power adapter for any smartphone or a PC USB jack can be used to charge your Micro2.

**Tip:** to conserve battery power, always place the slider in the OFF position when not in use.

/SoundOfSleep

hello@soundofsleep.com

@SoundofSleepOfficial

- /SoundOfSleep
- hello@soundofsleep.com
- @SoundofSleepOfficial

Sound Masking:

1. Slide switch to

2. Select sound ◄❙ ❙►

Sounds, Sonores, Klangs, Suonos

White Noises: Super Dark Brown Noise (#1),
Darker Brown Noise (#2), Darker Pink Noise (#3), Hot Pink Noise (#4), Fan Sounds:
Large Fan (#5), Industrial Fan (#6), Mellow Fan Low (#7), Attic Fan (#8), Vent Fan (#9),
Ocean Sounds: Ocean (#10), Surf (#11)

Bluetooth Audio

1. Slide switch to the left ✳

2. Select Lectro Fan MICRO2 from your Bluetooth device. If it doesn't appear, make sure it is not connected to another phone and is within range.

Tip: only one Bluetooth device can be connected at a time.

Answering Calls

- When your Micro2 is connected to a smartphone, press to answer the call, and again

to ▶❚❚ end the call.

- Double-press to ▶❚❚ redial the last dialed number.

To Pair 2 Micro2+'s together for stereo listening go to:

https://www.soundofsleep.com/stereo/

Specifications

- Power: 5V, 1A USB-A
- Audio Output: < = 3W
- Bluetooth Range: Up to 50 feet/15 meters Lithium-ion
- Battery Capacity: 1200 mAh
- Battery Run Time (at typical volumes):
- Bluetooth Audio: Up to 20 hours White Noise/Fan/Ocean
- Sounds: Up to 24 hours
- Battery Charge Time: 2 ½ hours

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FC CE ⚠ (PS E) CAN ICES-3 (B)/NMB-3(B)

trademarks or registered trademarks of Adaptive Sound Technologies, Inc. All other marks, including Bluetooth®, are registered trademarks of their respective owners.

Warranty

Warranty and Licensing Information:

astisupport.com

Frequently Asked Questions

- **Q: How do I know when my Micro2 is fully charged?**

  A: The indicator lamp will change from red to green when the Micro2 is fully charged.
- **Q: Can I pair multiple Micro2 devices for stereo listening?**

  A: Yes, you can pair two Micro2 devices together for stereo listening by visiting https://www.soundofsleep.com/stereo/ for instructions.
- **Q: What is the range of the Bluetooth connection?**

  A: The Bluetooth range of the Micro2 is up to 50 feet or 15 meters.

Documents / Resources

	[ASTI LectroFan Micro2 Plus Sleep Sound Machine](#) [[pdf](#)] User Guide Micro2, LectroFan Micro2 Plus Sleep Sound Machine, LectroFan Micro2 Plus, Sleep Sound Machine, Sound Machine

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz   **Search**

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube