Manuals+ — User Manuals Simplified.

AUSDOM AMCAP Software User Manual

AMCAP User Manual

Contents [**hide**

Introduction

This manual is not to tell you how to use the AMCAP software, because all settings are simple. In this guide, we present carefully some settings shown in Chinese.
Besides, what you adjust from the AMCAP may not default when you use other software.
But what you set under Options will default even when you use other software to record videos.

NOTE: the AMCAP software is compatible with all AUSDOM webcams, and you could select t to stop the autofocus function via AMCAP. The exact steps are not shown in this manual, if you need them, plz contact us via **support@ausdom.com** and you will get in touch in 48hrs.
When you open the AMCAP software, there are 6 function options at the top: File, Devices, Options, Capture, Photo, and Help.

File:
→Click "set capture directory…." to save captured videos wherever you want on your PC
→Click "set photo directory…." to save captured photos wherever you want on your PC
→Click "save captured video as…." to name captured videos and save them on your PC

Devices: To select the video/audio devices that you want to use when you plugged in several webcams or

earphones in your PC.

Options:
→ Default "Preview" when you open the "Options" function
→ Click "audio capture filter…." to adjust audio parameters(when the AUSDOM webcam is plugged in, there is no need to adjust as the AUSDOM webcam is set when it is published)



→Click "video capture filter…." to adjust video parameters

Note: When you want to customize some of the parameters of recording video, please uncheck the automatic option(the corresponding option box below   ) of this parameter.

属性 ✕

视频 Proc Amp | 照相机控制

Auto
自动

亮度(B) Brightness 135 ☐
对比度(C) Contrast 35 ☐
色调(H) Tone 0 ☐
饱和度(S) Saturation 40 ☐
清晰度(P) Clarity 5 ☐
伽玛(G) Gamma 140 ☐
白平衡(W) White Brightness 4600 ☑
逆光对比(B) Backlight Contrast 64 ☐
增益(G) Gain 16 ☐

启用颜色(E) ☐ 电力线频率(防闪烁)(P) 50 Hz ▼
Enable Color Power Line Frequency (Anti-Flicker)

默认值(D) Default

Confirm   Cancel   Apply

确定   取消   应用(A)

→ Click "video capture pin…." to adjust stream format parameters.

属性 ✕

数据流格式

视频格式 Video Format — 压缩

Video Standard 视频标准: None

Frame Rate 帧率(R): 30.000   I 帧间隔(I):

Flip Sideways   Frame Interval
横向翻转(F): ☐ 快照   P 帧间隔(P):

颜色空间/压缩(C):   Snapshot

MJPG   Quality
Color Space/Compression   质量(Q):
输出大小(S):

640 x 480

Output Size

Confirm   Cancel   Apply

确定   取消   应用(A)

**Capture:**
→Click "Start Capture" to start video recording (then the system will ask you to select a directory to save the video)
→Click "Stop Capture" to stop video recording.
→Click "Capture Video" / "Master Stream" to select the option you want.
→ Click "Set Frame Rate…" to set the video frame rate(if the software that you use supports frame rate adjustment, you could adjust directly from the software).

Choose Frame Rate   ✕

☑ Use Frame Rate

Frame Rate: 30   f/sec

Apply   Cancel

→Click "Set Time Limit…" to set the time that you want to record(If you want to end recording before the deadline,

you could click on stop capture).

→Click "Capture Compressor" to compress the output video.

Photo:

→Click "Photo" to capture a photo.

→Click "Set Photo Capture" to choose photo format and clarity.

Help: To show the version you used.

Documents / Resources

	AUSDOM AMCAP Software [pdf] User Manual AMCAP Software, AMCAP, Software