Manuals+ — User Manuals Simplified.

B O W HB357-3 Bluetooth Keyboard Instruction Manual

Contents

B.O.W

B O W HB357-3 Bluetooth Keyboard

Product display

- ⏻
  ○ Power Indicator

- 1
  ○ Numlk indicator

- ❊
  ○ Pairing indicator

-

- A
  ○ Upper and lower case indicator

| Keyboard status light color		light status
Power-on indicator	blue light	Capslock+Numlock+Fn lock+backlight on at the same time for 3S
power supply		Turn on green light, charge red light, full green light, red light
Upper and lower case indicator	green light	Enter Press the Caps Lock key to switch to uppercase, long light
Pairing indicator	red light green light blue light	The channel indicator flashes 5 times for about 1 second, and then flashes for about 180 seconds. If the pairing is successful, it will enter the sleep state, and the pairing success indicator will be on for a long time. 1 channel red light, 2 channel green light, 3 channel blue light
Numlock	green light	The open state is always on, realizing digital

Power switch   USB charging port

Bluetooth channel pairing connection steps

1. Turn on the power switch of the keyboard, the indicator light stays on for 3 seconds and then turns off.
2. Long press the Bluetooth channel 1 ( ) of the keyboard, the pairing indicator will flash blue slowly; enter the pairing state,
3. Turn on the Bluetooth of the tablet and search, the tablet itself or manually search to find the keyboard name (Bluetooth name: B.O.W), click connect;
4. A successful connection will appear and the keyboard status indicator will turn off.

Note:

1. The connection method of Bluetooth channel 2 ( ) and channel 3 ( ) is the same as that of 1.
2. Switch channel: Just click the corresponding bluetooth channel
3. Reconnect: Tap the corresponding Bluetooth channel
4. The 180S unpaired keyboard will go to sleep, and then you need to press the corresponding bluetooth channel when pairing again.

Instructions for use of function keys

button icon	Android	IOS	Windows	button icon	Android	IOS	Windows
⏦× F1	mute	mute	mute	All F9	Select All	Select All	Select All
⏦› F2	volume down	volume down	volume down	F10	copy	copy	copy
⏦)) F3	volume up	volume up	volume up	F11	paste	paste	paste
⏮ F4	previous piece	previous piece	previous piece	✂ F12	cut	cut	cut
⏯ F5	play / Pause	play / Pause	play / Pause	🔍 Fn	search	search	search
⏭ F6	next track	next track	next track	❽1	Bluetooth 1 channel	Bluetooth 1 channel	Bluetooth 1 channel
☀ F7	Brightness decrease	Brightness decrease	Brightness decrease	❽2	Bluetooth 2 channel	Bluetooth 2 channel	Bluetooth 2 channel
☀ F8	Brightness Plus	Brightness Plus	Brightness Plus	❽3	Bluetooth 3 channel	Bluetooth 3 channel	Bluetooth 3 channel

The above multimedia function keys are realized by single key by default; F1-F12 is realized by single pressing in Fn lock state.

keyboard parameters

Working voltage	3.0V-4.2V
Boot current	≤19(boot backlight defaulthighest gear)
Charging	≤190mA @3.4V
Standby	≤1.5mA
Sleep time	30mins
Sleep current	0.1mA
Sleep wake-up	≤25mA
Shutdown	20UA
Battery capacity	280Mah
Charging time	≤ 4 hours
Standby time ≥	365 days
Working current	Lighting up all LEDs working current 6.0mA, single-finger tap≤2.5mA
	Any key to wake up

Power-saving sleep mode

When the keyboard does not have any operation command within 30 minutes, it will automatically enter the sleep mode. When you need to use it, you only need to press any key and wait for ÿ4 seconds, the keyboard will wake up and the keyboard can work normally.

FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources

	B O W HB357-3 Bluetooth Keyboard [pdf] Instruction Manual HB357-3, HB3573, 2AKHJ-HB357-3, 2AKHJHB3573, Bluetooth Keyboard, HB357-3 Bluetooth Keyboard, Wireless Keyboard, Keyboard