Manuals+

BenQ JVPEC1 Wireless Mouse DW Version

**Contents** [hide]

Package Contents

When unpacking please check you have the following items. If any are missing or damaged, please contact the place of purchase for a replacement.

- Mouse

- Enhanced wireless receiver


- USB Type-C Adapter


- USB wireless receiver

- Spare skatez

- USB cable

- Quick start guide

- Warranty card

- Regulatory statements

ⓘ **Note**

- Consider keeping the box and packaging in storage for use in the future when you

may need to transport the product.

- Always keep the product and accessories out of reach of small children.

Product Overview

No.	Descriptions
1	Left button
2	Right button
3	Scroll wheel
4	Backward side button
5	Front side button
6	Power LED indicator
7	USB-C port - For charging - For connection with USB cable in wired operation
8	Enhanced antenna
9	Polling rate button
10	Optical sensor
11	Pogo pin (for charging)
12	DPI button

13	Mode switch • ⊡ Wireless mode via the USB receiver • ⏻ Power off mode • ▬ Wireless mode via the enhanced receiver

Power supply

Battery power check

To check the battery power level, switch to ◼ or ▱ mode from the bottom of the mouse. Alternatively, charge the mouse. The power LED indicators on the mouse will light up and show the battery power level.

Power LED indicators

Power LED indicators		
		≤ 25%
		26 sim 50%

	51~99%
	100%
Battery status during mouse use	
	≤ 10%

ⓘ **Tips**

The power LED indicators do not light up during mouse operation until the battery power is very low. To manually check power level, see Battery power check on page 6.

Specifications

Item	Description
Driver	No driver needed.
DPI	400/800/1000/1200 / 1600 / 3200
Polling rate	(125/500) / 1000 /2000^ * /4000^ * Hz **Note:** * available only when working with enhanced receiver (ER2-80).
USB	USB 2.0 / 3.0 plug & play
Buttons	7 buttons
Click response time	Fast / Normal

Connectivity	- Wireless: 2.4G RF - Wired: USB **Note:** The mouse is switched to wired operation when it is connected to PC via the USB cable.
Connectors	- USB type-A on a PC - USB type-C on a device
Battery life	- 80 hours when polling rate is 1000 Hz (constant movement) - 24 hours when polling rate is 4000 Hz (constant movement)
Battery charging	Approximately 2 hours to reach a full charge
Switch	1, for power off / enhanced receiver / USB receiver
Cable	USB type-A to USB type-C (2 meters/6.6 feet)

Applicable models:

- FK2-DW (FK2-DW-D)
- S2-DW (S2-DW-D)
- ZA13-DW (ZA13-DW-D)
- U2-DW (U2-DW-D)
- U3-DW (U3-DW-D)
- EC1-DW (EC1-DW-D)
- EC2-DW (EC2-DW-D)

- EC3-DW (EC3-DW-D)

BenQ

Documents / Resources

	[BenQ JVPEC1 Wireless Mouse DW Version](#) [[pdf](#)] User Manual JVPEC1-DW-D, JVPEC2-DW-D, JVPEC3-DW-D, JVPEC1 Wireless Mouse DW Version, JVPEC1, Wireless Mouse DW Version, Mouse DW Version, DW Version

References

- [User Manual](#)

📁 BenQ

🏷 BenQ, DW Version, JVPEC1, JVPEC1 Wireless Mouse DW Version, JVPEC1-DW-D, JVPEC2-DW-D, JVPEC3-DW-D, Mouse DW Version, Wireless Mouse DW Version

---

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube