Manuals+

User Manuals Simplified.

BLUEDEE SK010 Dynamic RGB Computer Sound Bar User Manual

BLUEDEE Computer Soundbar
SK010
User Manual

Only for white SK010

Contents hide

What's Included

BLUEDEE Computer Soundbar   User Manual

Specification

| Device Model	SK010
Two Connection Options	Bluetooth 5.0 & 3.5 mm Audio Plug
Power Supply	USB Plug (no built-in battery)
Power Input	DC 5V-2A Max
Two Lighting Modes	Multicolor Breathing & Lights Off

Product Diagram

1. 3.5 mm Audio Plug
2. USB Power Plug
3. 3.5 mm Earphone Jack
4. Multi-function Button

Button Function

- **Volume Control:** Clockwise to raise the volume, and counterclockwise to lower the volume.
- **Pause/Play:** Press once.
- **Change lighting modes:** Press twice quickly.
- **Switch to Bluetooth/wired mode:** Hold for 3 seconds.

- **Clear the paired devices on the soundbar:** Hold for 7 seconds in Bluetooth mode.

Wired Connection with 3.5 mm Plug

1. Insert the USB Plug into a USB port of a desktop, laptop, tablet, power bank, etc.
2. Insert the 3.5 mm Audio plug into the 3.5 mm jack of your device.

NOTE:

- Make sure the soundbar is not in Bluetooth mode.
- Extra driver or software installation is not needed, just plug and play.

Wireless Connection via Bluetooth

1. **Switch to Bluetooth mode**

   1. Hold the button for 3 seconds then release it.
   2. The Bluetooth mode is on when the light flashes blue/red.

2. **Pair with your device**

   1. Turn on the Bluetooth of your device.
2. Find "SK010" in the search results and tap to connect.
NOTE:
How to switch to wired mode from Bluetooth mode:
Hold the button for 3 seconds then release it, you will hear a tone meaning the Bluetooth mode is off.

LED Light Mode

1. Two lighting modes: multicolor breathing & lights off.
2. Change lighting modes: Press the button twice quickly.

Troubleshooting of Sound

Configure the sound output device on your device (System> Sound > Output > Choose your output device).
> Raise the volume on your soundbar, device, or application.
> Press the button of the soundbar to resume.
> Reinsert the USB plug firmly into the USB power port.

Troubleshooting of Bluetooth Connection

> Make sure that the soundbar Bluetooth paring mode is on(LED light bar flashes blue/red).
> Make sure the Bluetooth of the soundbar is not connected by other devices.
> Clear the paired devices on the soundbar (hold the button for 7 seconds in Bluetooth mode), and delete the memorized "SK010" on your device, then reconnect the soundbar with your device

Worry-Free Service Guarantee

- 30 days free returns and exchanges.
- 18 months warranty.
- Lifetime friendly customer service.

Documents / Resources

BLUEDEE SK010 Dynamic RGB Computer Sound Bar [pdf] User Manual
SK010, Dynamic RGB Computer Sound Bar, SK010 Dynamic RGB Computer Sound Bar, Computer Sound Bar, Computer Soundbar, Sound Bar