Manuals+ — User Manuals Simplified.

BLUESOUND N230BLKUNV Powernode Edge User Guide

BLUESOUND N230BLKUNV Powernode Edge

1. STATUS INDICATOR

2. PLAY/PAUSE BUTTON

3. PREVIOUS/NEXT TRACK

4. VOLUME UP/DOWN

5. IR RECEIVER

6. SPEAKERS

7. SUBWOOFER OUT

8. IR IN

9. HDMI ARC

10. OPTICAL/ANALOG IN

11. LAN PORT

12. USB (TYPE A)

13. AC MAINS INPUT

MOUNTING

1

Connect rubber mount attachment to bottom panel of POWERNODE EDGE with supplied metal mounting screw.

2

Use supplied metal mounting bracket to mark the mounting location. Ensure mounting location does not conceal electrical wiring or plumbing. Pre-drill each hole for mounting screws (recommended M4–0.7 x 3, 4 pieces, not supplied). Anchors may be required.

3

Slide the POWERNODE EDGE with rubber mount attachment onto the bracket. Push down to secure.

ACCESSORIES

- **120V AC Power Cord**

- **230V AC Power Cord**


- **Metal Mounting Screw**

- **Rubber Mount Attachment**

- **Ethernet Cable**

- **Mini Jack to To slink Adaptor**

- **Metal Mounting Bracket**

WELCOME TO #LIVINGHIFI

The POWERNODE EDGE is a network music streaming smart amplifier that conveniently brings the enjoyment of hi-resolution audio to everyday life. Simply add a pair of loudspeakers to create the ultimate two-channel system, which can also be grouped with other Blue sound players to create multi-room and home theater listening experiences. The POWERNODE EDGE must be wired or connected wirelessly to your home network for full functionality.

This Quick Setup Guide will take you through the basic steps to get your POWERNODE EDGE positioned, plugged in, and connected to your network.

Go to **bluesound.com/downloads** to download the App.
The initial network setup is done using the Blousy App on your phone or tablet. Make sure you have the App downloaded and installed, and your phone or tablet nearby as you get started.


The POWERNODE EDGE online owners manual has even more in-depth information, including troubleshooting tips and tricks. Please visit bluesound.com/products/power node-edge to download the latest version of the manual.

CONNECT FOR SOUND

HOOK UP YOUR SPEAKERS

For source audio (like a TV or turntable), connect via HDMI ARC, Optical, or Analog inputs. Use the supplied To slink adaptor for Optical sources.

PLUG IN YOUR PLAYER

WATCH FOR THE LED TO TURN SOLID GREEN, INDICATING 'HOTSPOT' MODE

ADD YOUR POWERNODE TO THE NETWORK

USING YOUR PHONE OR TABLET, DOWNLOAD AND OPEN THE BLUOS APP The 'Add A Player' wizard will guide you through the steps to complete your setup.

bluesound.com/downloads

HAVE QUESTIONS?GET IN TOUCH

- **support.bluesound.com**
- **support@bluesound.com**
- North America: 1 855 531 4666 EU: 00 800 53 14 66 66

Documents / Resources

	BLUESOUND N230BLKUNV Powernode Edge [pdf] User Guide N230BLKUNV Powernode Edge, N230BLKUNV, Powernode Edge, Edge

References

- **Wireless multi-room speakers and components for music streaming - Bluesound**
- **Downloads - Bluesound**
- **POWERNODE EDGE - Bluesound**

Manuals+,