Cobra DASH CAM SC 200D User Guide

SC 200D
DASHCAM

QUICKSTART GUIDE

Scan QR Code For Additional Languages:



https://drivesmarter.com/support/manuals/

Contents

1 SC 200D Features
2 Button Functions (Recording Stopped):
3 Button Functions (While Recording):
4 Voice Commands
5 For Cabin View*
6 For a View of the Road Behind You
7 Documents / Resources
7.1 References
8 Related Posts

SC 200D Features





1. Attach GPS mount and remove the protective film from mount and front lens



2. Attach Camera Assembly to Windshield



3. Connect and Power



To 12V Power Source

Button Functions (Recording Stopped):

	Settings Button: Access the dash cam's Settings menu.
	Takes a snapshot and stores it in the Photo Folder.
	Enters the playback menu to review previous recordings and photos.
	Begins loop recording.

Button Functions (While Recording):

	When pressed the camera saves the current clip from being overwritten.
	Takes a snapshot and stores it in the Photo Folder.
	Toggles the microphone on/off. Note that the icon on the button indicates the action that will be ta ken when the button is pushed, not the current setting. The current setting is shown on the status bar at the top of the screen.
	Stops loop recording. While in an Emergency Recording you will be asked to confirm.

Voice Commands

SC200 will respond to certain voice commands so you can stay focused on the road ahead. Try the following voice commands.

Say	Camera Action
“Front Video On”	The front-View camera is displayed on screen
“Rear Video On”	Rear-View camera is displayed on screen (optional accessory camera required)
“Record Video”	Begins loop-recording
“Lock Video”	(If currently recording), Camera locks the video and tags as Favorite
	(If not currently recording), Camera begins emergency recording, locks first vide o and tags as favorite
“Screen On”	Turn Display On
“Screen Off”	Turn Display Off
“Take Photo”	Takes a photo of the front and/or rear view and saves to the “Photos” folder

For Cabin View*

Connect Cabin Camera to the Video Input Port on the SC 200



optional accessory sold separately.

For a View of the Road Behind You

1. Connect Extension Cable to the Video Input Port on the Dash Cam
2. Connect Extension Cable to the Rear Camera
3. Attach Rear Camera to the Vehicle’s Back Window

Warning: Please position the camera on the rear windshield so it faces out of the vehicle in the orientation shown



THANK YOU! For purchasing the new COBRA® SC 200D
View, edit, and share from your smartphone or desktop.
Share & receive real-time driver alerts.
Download today!
drivesmarter.com/downloads

	Download on the App Store GET IT ON Google Play

http://drivesmarter.com/downloads

Full manual available at: **www.cobra.com**	

FCC ID:BBOSC200, IC:906A-SC200. THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

FCC NOTE: Modifications not expressly approved by the manufacturer could void the user's FCC granted authority to operate the equipment.

Cobra® and the snake design are registered trademarks of Cobra Electronics Corporation, USA. Cobra Electronics Corporation™ is a trademark of Cobra Electronics Corporation, USA. Other trademarks and trade names are those of their respective owners.

©2020 Cobra Electronics Corporation

Documents / Resources

	Cobra DASH CAM SC 200D [pdf] User Guide DASH CAM, SC 200D, Cobra

References

- Downloads - DriveSmarter
- Portable Power & Automotive Electronics | Cobra.com

Manuals+,