COOPER HHPR-RC Room Controller Personal Remote Instructions

COOPER HHPR-RC Room Controller Personal Remote Instructions

Contents

Greengate

Room Controller Personal Remote (HHPR-RC)
Handheld tool that provides the user the ability to individually control relays, dimmers and scenes

Typical Applications

- Office
- Education
- Healthcare
- Hospitality
- Retail

Interactive Menu

- Order Information page 2
- Additional Resources page 3
- Product Warranty

Product Features

Manual Dimmer

Manually Switched ON/OFF

Scenes

Overview

The Room Controller Personal Remote is a handheld tool that provides the user the ability to individually control relays, dimmers and scenes. It also allows programmability of the individual scene buttons that can be packaged/configured to create Scene Wall stations.

Each scene button can be programmed with user specified load ON/OFF and dimmer settings. Using the Room Controller Personal Remote (HHPR-RC) and daylight sensor (DSRC-FMOIR) the user can define up to six scenes and save them into the Room Controller to be recalled later from the Scene buttons or the Personal Remote.

Product Features

- Simple to use personal remote
- Personalize the scene buttons with your ON/OFF and dimming needs
- Program Auto ON Lighting Scene
- Handheld scene control

Order Information

This is an accessory for the Greengate Lighting Control System.

Catalog Number

Catalog Number	Description
HHPR-RC	Room Controller Personal Remote

Optional Accessories

Catalog Number

Catalog Number	Description
DSRC-FMOIR	Daylight Sensor/IR Receiver

Product Specifications

Key Features

Room Controller
Personal Remote
HHPR-RC

- S1 = Button Address 12
- S2 = Button Address 13
- S3 = Button Address 14
- S4 = Button Address 15
- S5 = Button Address 4
- S6 = Auto On Scene (DIP #4 UP)
- The Personal Remote can send IR commands to the Room Controller using the Daylight Sensor (DSRC-FMOIR) as an IR receiver.
- The Personal Remote contains the following buttons for temporary override of the space lighting:
- Dimmer 1 (Raise/Lower)
- Dimmer 2 (Raise/ Lower)
- Dimmer 3 (Raise/ Lower)
- Relay 1 (Toggle)
- Relay 2 (Toggle)
- Relay 3 (Toggle)
- Auxiliary Output (can be used for Solatube or Shade)
- Scenes 1 – 6
- Set (to store programmed scenes)

Battery: 2 AAA (included)
Communication: IR (requires DSRC-FMOIR)

Warranty

Consult website for warranty information

Sample System Topology

Documents / Resources

[COOPER HHPR-RC Room Controller Personal Remote](#) [pdf] Instructions
HHPR-RC Room Controller Personal Remote, HHPR-RC, Room Controller Personal Remote,
Controller Personal Remote, Personal Remote

References

- **Commercial Lighting Company | Cooper Lighting Solutions**
- **User Manual**