🌿 Manuals+

☰

Contents [hide]

DJI MATRICE 4D Series Standalone Combo Drone

v1.0

This guide uses the Matrice 4TD aircraft as an example. Refer to the actual product purchased. The aircraft comes with a micro SD card. In some regions, an FTS module is included. The aircraft needs to be installed with an FTS module to meet C6 requirements.

https://enterprise.dji.com/dock-3/video

https://enterprise.dji.com/dock-3/downloads

Installing DJI Cellular Dongle 2 (Optional)

- Operate when the aircraft is powered off. To avoid damage, DO NOT apply force onto

the dongle surface or pull the antennas by force.

Make sure the antenna cables are firmly connected and the cable routing is tidy.

- The aircraft supports installing DJI payloads. And the installing method for the dongle is different if the aircraft is used with the FTS module.

Scan the code or visit the link to access the user manual or the accessory guide and learn about product usage and safety instructions.

Charging

- Charge the remote controller to activate the internal battery before using for the first time.

Preparing the Aircraft

**Power on:** Press, and then press and hold the power button.

Linking and Activation

- The devices require activation before first Make sure the remote controller is connected to the internet and follow the instructions in the app for activation.
- When using with the dock, refer to the manuals in the dock package to complete installation, preparation, linking, and activation.

Preparing the Remote Controller

- DO NOT operate other wireless devices at the same frequency as the remote controller, to avoid signal interference.

Start (Stop) Motors

Perform Combination Stick Command and hold for two seconds.

Take off   **Land**

- Always set an appropriate RTH mode and RTH altitude before takeoff.
- Press the Flight Pause button 11 for emergency braking during flight.

Manual Flight

Matrice 4TD

Matrice 4D

1	2	3	4	5	6	7	8	9	10

Gimbal and Camera	Auxiliary Light	Front LEDs	Aircraft Status Indicators	Beacon	Power Button	Battery Level LEDs	Assistant Port (E-Port Lite)	microSD Card Slot	E-Port

Documents / Resources

	dji MATRICE 4D Series Standalone Combo Drone [pdf] User Guide MATRICE 4D Series Standalone Combo Drone, MATRICE 4D Series, Standalone Combo Drone, Combo Drone, Drone

References

- User Manual

Related Posts

dji AIR 3S Fly More Combo Drone User Guide

dji AIR 3S Fly More Combo Drone User Guide Connection Power on/off: press, then press and hold. Apps…

dji MINI 4K Fly More Combo Drone User Guide

dji MINI 4K Fly More Combo Drone Instructions to Use Charge to activate the Intelligent Flight Battery before…

dji Mini 2 Fly More Combo Drone User Guide

ore Combo Drone DJI Fly Overview Check battery level: press once. Power on/off: press,…

[dji FPV Combo FPV Drone User Guide](#)

dji FPV Combo FPV Drone User Guide Download The App DJI Fly App Installation Check battery level: press…

📁 DJi

🏷 Combo Drone, DJI, drone, MATRICE 4D Series, MATRICE 4D Series Standalone Combo Drone, Standalone Combo Drone

----

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search