Manuals+ — User Manuals Simplified.

Eyedro E5B-M-T2 Temperature Monitoring System User Guide

Contents

Eyedro E5B-M-T2 Temperature Monitoring System

Product Information

The Temperature Monitoring System with Wireless Mesh connectivity, model E5B-M-T2, is a product designed for indoor use. It allows you to monitor temperature levels using thermocouples and provides wireless connectivity through a mesh network. This product comes with a limited one-year warranty, and detailed installation instructions can be found in the Product Guide available at **eyedro.com/support**. For any questions or comments, you can visit **eyedro.com** or access their online support resources.

Product Usage Instructions

1. Verify Package Contents: Check that you have the following items:
   - **A:** Eyedro temperature module – 1 quantity
   - **B:** Thermocouple(s) – 2 quantities
   - **C:** 5VDC power adapter – 1 quantity
2. **Install Hardware:** Follow these steps to install the hardware:
   - Place the tip of the thermocouple in direct contact with the surface you want to measure the temperature of.
   - Connect the thermocouple cables and power adapter to the Eyedro module.
3. Record Serial Number:

Follow these steps to create a MyEyedro user account

- Go to **my.eyedro.com** and create an online account (or log in if you already have one).
- Add the device to your user account by going to Configuration, selecting Devices, and entering the serial

number recorded in Step 2.

- Enjoy! Log into MyEyedro as often as you like to view your electricity consumption.
- For more details about the MyEyedro cloud service, refer to the MyEyedro User Guide available at **eyedro.com/support**.

Before Getting Started

This Quick Start Guide provides very high level installation instructions. Detailed installation instructions are available in the Product Guide at **eyedro.com/support**. This product is intended for indoor use only.

Verify Package Contents

	Quantity	Description
A	1	Eyedro temperature module
B	2	Thermocouple(s)
C	1	5VDC power adapter

Record Serial Number:

- (located under barcode on module)

Install Hardware

1. Place the tip of the thermocouple in direct contact with the surface to measure the temperature.
   - Optionally, apply thermal paste or thermal padding between the surface and the thermocouple tip.

Ports
A & B
(Thermocouples)

Power
Adapter
Port

2. Connect thermocouple cables and power adapter to the Eyedro module.

Create a MyEyedro User Account

1. Go to **my.eyedro.com** to create your online account (or log in if you have an existing account).
2. **Add the device to your user account:** go to Configuration, select Devices then enter the serial number you recorded in Step 2.
3. ENJOY! Log into MyEyedro as often as you like to view your electricity consumption.
4. For more details about the MyEyedro cloud service, review the MyEyedro User Guide located at **eyedro.com/support**

Visit **eyedro.com** for any questions or comments. We value your feedback.

Online Support Resources

Visit **eyedro.com/support** for an online product setup wizard, user manuals, videos, and various support resources

- **eyedro.com/support**

Limited One Year Warranty

- Full warranty details are available in the Product Guide at **eyedro.com/support**.

Important: This product contains no user serviceable components. Do not attempt to open the case of the unit or tamper with the internal components. Doing so will void the product warranty.

Copyright © 2023, Eyedro Green Solutions Inc.

Documents / Resources

Eyedro E5B-M-T2 Temperature Monitoring System [pdf] User Guide
E5B-M-T2 Temperature Monitoring System, E5B-M-T2, Temperature Monitoring System, Monitoring System

References

- **Electricity Monitors for Home and Business**
- **Support - Eyedro**
- **MyEyedro**