Manuals+ — User Manuals Simplified.

Faizan MOTORSPORTS RIDESYNC2 Helmet Bluetooth Intercom User Manual

Contents

Faizan MOTORSPORTS RIDESYNC2 Helmet Bluetooth Intercom

POWER ON/OFF	power off		⏻	press & hold 3s			remind
	power off		⏻	press & hold 3s	flash in	red ls	power off
POWER	battery detect	standby	⬦+⬦ press at the same time				remind the battery status
CELLPHONE CONNECTION			@press&holdSs		flash in blue		
PHONE CALL	answer the call	incoming call					tones same with cellphone
	reject	incoming call	Ⓜ	press & hold 2s	flash in blue		
	hangup	during phone call	Ⓜ	briefly press	flash in blue		
	redial	standby			flash In blue		
	voice command	standby	Ⓜ	press & hold 2s	flash in blue		
MUSIC	play/pa11se	standby	Ⓜ	briefly press	flash In blue		play/pause
	volume+	standby	+ briefly press		flash in blue		""
	volume-	standby	– briefly press				beep
	previous	play	+press & hold 2s				previous
	play		-press & hold 2s		flash in blue		

VOLUME-

VOLUME+

POWER
ON/OFF

FUNCTION

2.5mm JACK   HEADPHONE/CHARGING JACK

| FUNCTION	DESCRIPTION	STATUS	BUTTON/METHOD	LED	VOICE REMINDER
INTERCOM CONNECTION	pairing mode	power off	Ⓜ press&hold 5s	flash between red&blue	paring
	searching mode	power on	⏻ briefly press	flash between red&blue	searching
	cancel pairing	pairing	Ⓜ press&hold 2s		beep
	memory clean	connected	⏻ press&hold 6s after power off	flash in red	beep
INTERCOM	intercom on	connected	⏻ briefly press	keep in blue	intercom on
	intercom off	connected	⏻ briefly press	flash in blue	beep
	re-connect	power on	⏻ briefly press		beep
FM RADIO	FM on	stand by	Ⓜ+⏻ press at the same time	flash in blue	FM on
	FM off	FM on	Ⓜ+⏻ press at the same time	flash in blue	FM off
	previous	FM on	⬦ press&hold 2s	flash in blue	previous
	next	FM on	⬦ press&hold 2s	flash in blue	next

Configuration List

INSTALLATION

Documents / Resources

Faizan MOTORSPORTS RIDESYNC2 Helmet Bluetooth Intercom [pdf] User Manual
2ATVZ-RIDESYNC2, 2ATVZRIDESYNC2, RIDESYNC2, RIDESYNC2 Helmet Bluetooth Interco
m, Helmet Bluetooth Intercom, Bluetooth Intercom, Intercom

References

- **User Manual**