Fanvil X7A Android Touch Screen IP Phone Installation Guide

Fanvil X7A Android Touch Screen IP Phone


Fanvil
HD
1
2 ABC
3 DEF
4 GHI
5 JKL
6 MNO
7 PQRS
8 TUV
9 WXYZ
*.
0
🔒
OK

Contents

1 Packing List
2 Screen Icon
3 Keys Feature
4 Installation the device
  4.1 Bracket desktop installation
  4.2 Connecting to the Device
5 Configuration
  5.1 Configuration via Phone
  5.2 Configuration via Web
6 Language setting
7 Making a call
8 Accepting a call
9 Putting a call on hold
10 3-party conference
11 Call transfer
12 Call forward
13 Call Mute
14 Call list
15 Phonebook
16 Programmable keys
17 Redial
18 Do not disturb
19 Voice message
20 Bluetooth
21 Wi-Fi
22 Customer Support
23 Documents / Resources
24 Related Posts

Packing List

IP Phone 	Handset 	Handset Cord 
Stand 	Ethernet Cord 	Power Adapter (Optional) 
Quick Installation Guide 		

Screen Icon

	In hands-free mode		New SMS
	In headset mode		New VM Messages
	In handset mode		Do not disturb activated

	Mute activated		Missed call(Status bar)
	Ringer off		Received call
	Call is on hold		Dialed call
	Auto-answering activated		Missed call (s)
	Call Forward activated		Forward call
	Internet is disconnected		Enable Blacklist
	Internet is connected		Enable White List

Keys Feature

	Message waiting indicator

	Up/down/left/right navigation keys, Return key OK key, Shortcut to Menu Return key, Go back to the previous directory
	Hold key, Hold/Resume the call
	In idle mode: ringer off In communication mode: mute/un-mute a call
	In idle mode or during ringing: increase or decrease ringer volume In communication: increase or decrease earpiece, headset or hands-free volume
	Voice message key
	Headset key, Activate/deactivate Headset
	Redial key, Access to redial the last record
	Long press to lock keypad. Enter PIN to unlock keypad (default 123)

	Hands-free key, Activate/deactivate hands free

Installation the device

Bracket desktop installation



Connecting to the Device

Please connect power adapter, network, PC, handset, and headset to the corresponding ports as described in below picture.

1. **USB port:** connect USB device (U disk)
2. **Power port:** connect the power adapter.
3. **Network port:** connecting local area network or internet.
4. **PC port:** the network port connect to the computer.
5. **Headset port:** connect headset.
6. **Handset port:** connect IP Phone handset.



Configuration

Configuration via Phone

1. Press Phone Settings icon .
2. **Select Ethernet Settings:** To configure the Network Settings (DHCP/Static)
3. **Select Line:** To configure enable the account, fill the SIP server address, port, user name, password etc.

Configuration via Web

1. Get the IP address from the phone: Press Phone Settings icon > Common.
2. **Login:** Input the IP address in the web browser. The PC and phone should be in the same IP address segment (The default username and password are both ‘admin’ .)
3. **Configure:** Select network/Account, etc. And fill the relevant content.

Language setting

1. Press Settings icon > System > Language & Input > Languages.

2. Select the desired language.

Making a call

1. **Pre-dialing:** enter the phone number and pick up the handset.
2. **Direct dialing:** lift the handset and enter the phone number.
3. **Handsfree:** enter phone number and press or vice versa.
4. **Headset:** enter phone number and press or vice versa.
5. **Dial icon:** Click dial icon and then enter the phone number.
6. **Designated line:** press line key, enter phone number and press dial key.

Accepting a call

1. With the handset: pick up the handset.
2. With a headset: press .
3. With the handsfree: press).

Putting a call on hold

1. Press key or Hold icon, caller is put on hold.
2. To retrieve the call press key or Resume icon.
   Note: with more than one active call, select desired call by sliding screen and use the corresponding icon to hold or resume.

3-party conference

1. Once in line with 1st caller, press Conference icon, 1st caller is put on hold.
2. Then call the 2nd number.
3. After, 2nd call is established, press Conference icon to set up the conference.

Call transfer

Attended transfer:

1. Press Xfer icon during the active conversation, the call is put on hold.
2. Dial the second telephone number.
3. When the call is answered, then press Xfer icon to complete the operation.

Blind transfer:

1. Press Xfer icon during the active conversation, the call will be on hold.
2. Then enter the 2nd telephone number and press Xfer icon.

Call forward

1. Press Phone Settings icon >Line> Select the line > Forward Settings
2. Enter the destination number and the type of forward and press OK icon .

Call Mute

1. Press to Mute the microphone during the call.
2. Press again to un-mute the conversation.

Call list

1. Press Call Logs icon .
2. Scroll the list using navigation key or slide the screen
3. To dial an entry, press Dial icon or click the phone icon at left then click dial icon or pickup handset or press or .

Phonebook

Access phonebook:

1. Press Contact icon .
2. Select All Contacts or other group.
3. To dial an entry, press Dial icon .

Add new entry:

1. Press Contact icon a , Press All Contacts or other group > Press Add icon.
2. Enter name and number and press OK icon .

Programmable keys

DSS virtual keys:

1. You can use the phone web interface to configure the keys of the screen.
2. Press unfold > you can press any keys which is still blank or long press the key that have configured, select a type and value, press √ icon.

Other keys:

1. You can also configure shortcuts for the navigation keys and softkeys on web ui.
2. You can press Phone setting icon Key, select the Softkey Screen you need, t hen select among the configurable items, and select your desired type and value, press Save.

Redial

1. Press , redial a call number.

Do not disturb

1. Press ONO icon when standby or click Phone Settings icon > DND.
2. Select the Mode.

Voice message

1. To access your voice mailbox, press Voice message key or Voice message icon , number of message be indicated if provided by your server or PBX.
2. Select the line and press phone icon to call.

Bluetooth

1. Press Bluetooth icon in the status bar to open Bluetooth.
2. Press Settings icon > Connected devices> Pair new device. After opening, it displays the scanned Bluetooth list, select any device, and click on t he device pairing.

Wi-Fi

1. Enter the Settings icon > Network & internet> Wi-Fi, enable Wi-Fi, and you can browse the list of available Wi-Fi;
2. Select the available network, click on the network to enter the password to connect and click connect button.

Customer Support

Fanvil Technology Co., Ltd
www.fanvil.com
Email: sales@fanvil.com Tel:0755-2640-2199
Add: 4F, Block A, Building 1#, GaoXinQi Hi-Tech Park (Phase-II),67th District, Bao'An, Shenzhen, China

Documents / Resources

	Fanvil X7A Android Touch Screen IP Phone [pdf] Installation Guide X7A Android Touch Screen IP Phone, X7A, Android Touch Screen IP Phone, Touch Screen IP Phone, Screen IP Phone, IP Phone, Phone

Manuals+,