**FOXX A55AM
Smart Phone**

FOXX A55AM Smart Phone Instruction Manual

Contents

FOXX A55AM Smart Phone

Thank you for choosing FOXXD product.
Please follow the instructions when starting to use this product.

Product Safety Information

⚠	Do not use while re-charging.
⚠	Do not use hand-held while driving.
⚠	This device may produce a bright or flash light.
⚠	For body-worn operation, maintain aspiration of 5 mm.
⚠	Do not dispose of the phone in a fire.
⚠	Small parts may cause a choking hazard.
⚠	Avoid contact with magnetic media.
⚠	This device may produce a loud sound.
⚠	To prevent possible hearing damage, do not listen at high volume levels for long periods.
⚠	Avoid extreme temperatures.
⚠	Keep away from pacemakers and other personal medical devices.
⚠	Avoid any contact with liquid. Keep it dry.
⚠	Switch off when instructed in hospitals and medical facilities.
⚠	Do not attempt to disassemble your phone.
⚠	Switch off when instructed in aircrafts and airports.
⚠	Do not rely on this device for emergency communications.
⚠	Switch off in explosive environments.
⚠	Only use approved accessories.

What are in the Box

The phone packaging box should contain the following items and accessories:
Phone, Battery, Charger, USB cable, Phone case and Quick Start Guide.

Notices for the Use of Your Phone

Your phone should be treated with care. The following suggestions can help you extend the life of your mobile phone.

1. Place the mobile phone and its parts and components out of reach of young children.
2. Keep the phone dry. Rain, humidity and all types of liquids which contain minerals will corrode electronic circuits.
3. Don't touch the phone with wet hands when charging, it will cause an electric shock or damage the phone. Avoid placing the device in high temperature environments. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
4. Avoid placing the device in a low temperature environment. When the temperature rises, the phone will produce water vapor that may damage electronic circuits.
5. Avoid placing the phone in dusty, dirty places, otherwise parts may be damaged.
6. Avoid placing the phone near a lit cigarette, open flame or any heat source.
7. Do not drop, knock or shake the phone. Rough handling can damage internal circuit boards.
8. Do not paint the phone. The paint may block headphones, microphones or other removable parts, and cause them not to work.

9. Use a clean, soft, dry cloth to clean the camera, light sensor lenses. Prohibit the use of harmful chemicals and cleaning agents to clean the phone.

10. Pacemaker manufacturers recommend that a minimum separation of 5mm be maintained between a mobile phone and a pacemaker to avoid a potential interference with the pacemaker (when the device is used in the USA, the separation distance can be maintained at 10mm between user's body and handset).To achieve this use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

11. Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

12. Turn off your mobile phone or wireless devices when in a blasting area or in areas posted, turn off "two-way radios" or 'electronic devices" to avoid interfering with blasting operations.

13. There is a risk of explosion if the battery is replaced with an incorrect type. Dispose of a used battery according to the instructions.

Getting to Know Your Phone

- **Power Key**
  - Press and hold to Power on/off, or Restart the phone.
  - Press to wake up or turn off the display.
- **Home Key**
  - Touch to return to the home screen.
  - Touch and hold to open the Google Assistant for AndroidTM.
- **Menu Key**

  Touch to see recently used applications.
- **Back key**

  Touch to go back to the previous screen.
- **Volume Keys**

  Press or hold to turn the volume up or down.

Before Getting Started

Removing the Back Cover

Insert the SIM card into the lower tray

Installing the Battery

Insert the SD card into the upper tray

NOTE: Some applications may require a microSD card to work normally or may store certain data on it. Therefore, it is recommended that you keep a microSD card installed and not remove or replace it randomly

Closing the Back Cover

Basic Settings

Your service provider may default some device settings, so you may not be able to change these settings.

Display

- **Brightness**

  Brightness level: Adjust the screen brightness.

- **Lock display**

  Lock screen: Customized what to show on lock screen.

  Screen timeout: Adjust the time allowed before the screen goes to sleep after inactivity.

- **Appearance**

  - Dark theme: turn on/off the dark background.
  - Font size: Set the font size of the system.
  - Display size: Set the display size of the screen.

- **Other display controls**

  - Auto-rotated screen: Swipe to turn on or off.
  - Screen saver: Choose the screen saver and when to start.

System

Languages and input

1. You can set up all the languages supported by the phone.
2. Keyboards: You can set an on-screen keyboard and Physical keyboard.

Date and time

1. Set time automatically: Swipe right to use date and time provided by network.
2. Time zone: You can choose to use the time zone provided by network or use the location to set time zone.
3. Time format: You can choose to use local default time format or to use 24-hour format.

About phone

Here you can check out basic information including:
Device name, phone number, local software update, and device details including SIM status, Model, RAM, IMEI, Android version, IP address, Uptime, Build number, etc.

Technical Specifications

- Network:
    - GSM:850/900/1800/1900 WCDMA: B2/4/5
    - LTE: B2/4/5/12/25/26/41/66/71
- Display: 5.5″
- Memory : 2GB RAM+16GB ROM
- Camera: 5MP+2MP
- FM / MP3 / MP4 / GPS/ G-sensor.
- Battery Capacity: 2000mAh Li-ion

(*): The storage capacity actually available in the unit's internal memory may be less due to the preloaded operating system and/ or other pre-installed or configured applications. Check the space actually available on your computer.

SAR Information Statement
The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: smart phone (FCC ID: 2AQRM-A55AM)has a lso be entested agains t this SAR limit. The highest SAR value for this mobile phone tested is 0.988W/kg against the head and 0.446W/kg at 10mm from the body.

FCC Declaration of Conformity

- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- Use the smartphone in an environment with the temperature between -10°C and 45°C.
- Use the earphone carefully. Excessive sound pressure from earphones and headphones can cause hearing loss.
- The product shall only be connected to a USB interface of version USB2.0
- CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF

USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

- Manufacturer: Foxx Development Inc.
- 3480 Preston Ridge Road, Suite500, Alpharetta, GA 30005

Information for auxiliary equipment

Battery	
Model	A55AM
Power Rating	7.6Wh
Manufacturer	ShenZhen Powercom Electronics Co. Ltd
Address of Manufacturer	B1202, building 1, Mogen Fashion Industrial Park, No. 10, Shilongzi Road, Xinshi community, Dalang street, Longhua District, Shenzhen

WEEE Recycling

This product should not be treated as household waste, instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

GSM	
Operation	GSM 850
Frequency	TX:824-849MHz; RX:869-894MHz GSM 900
	TX:880-915MHz;RX:925-960MHz
	DCS 1800
	TX:1710-1785 MHz;RX:1805-1880MHz
	PCS 1900
	TX:1850-1910MHz;RX:1930-1990MHz

WCDMA	
Operation Frequency	Band 2:TX:1852-1908MHz; RX:1932-1988MHz Band 4:TX:1712-1753MHz; RX:2112-2153MHz Band 5:TX:826-847MHz; RX:871-892MHz
LTE	
Operation Frequency	Band 2:TX:1850-1910MHz; RX:1930-1990MHz Band 4:TX:1710-1755MHz;
	RX:2110-2155MHz
	Band 5:TX:824-849MHz;
	RX:869-894MHz
	Band 12:TX:699-716MHz;
	RX:729-746MHz
	Band 25:TX:1850-1915MHz;
	RX:1930-1995MHz
	Band 26:TX:814-849MHz;
	RX:859-894MHz
	Band 41:TX:2496-2690MHz;
	RX:2496-2690MHz
	Band 66:TX:1710-1780MHz;
	RX:2110-2180MHz
	Band 71:TX:663-698MHz;
	RX:617-652MHz
FM	
Operation Frequency	87.5MHz-108MHz
GPS/GLONASS	
Operation Frequency	L1:1559MHz~1610MHz R1:1559MHz~1610MHz

Google and Android are trademarks of Google LLC.

Frequently Asked Questions

Q: What should I do if my phone gets wet?

A: If your phone gets wet, power it off immediately, remove the battery (if possible), and place it in a bag of rice to

absorb moisture. Do not attempt to turn it on until fully dry.

Q: How often should I clean my phone?

A: It is recommended to clean your phone regularly using a soft, dry cloth. Avoid using harsh chemicals that may damage the device.

Documents / Resources

	FOXX A55AM Smart Phone [pdf] Instruction Manual 2AQRM-A55AM, 2AQRMA55AM, a55am, A55AM Smart Phone, Smart Phone

References

- **User Manual**