Manuals+ — User Manuals Simplified.

FUNSNAP Capture 2s Axis Gimbal User Guide

FUNSNAP Capture 2s Axis Gimbal User Guide

Contents

Charge

- Charging:

 The battery Level Indicator flashes red.

- Fully Charged:

  The Battery Level Indicator turns solid green.

Download Capture2 App

Scan the QR codes on the right side or search for "Capture2" on Google- Play/ App Store, then download and install it.

- Google Play

- iOS

Mount and Balance Your Phone Horizontally

1.


2.

Mounting Slot

3.

Please fit one side of your mobile phone into the Mounting Slot.

Please make sure the part with camera on the top side.



4.

5.

Adjustable Arm

6.

7.

8.

Tips: If Your phone is too heavy to balanced by the adjustable arm, you can stick the counterweight on to the tilt motor.

**Mount an Balanced Your Phone Vertically**

1.

2.

90°

3.

①

②

4.

5.

Please make sure the part with camera on the right side.

6.

7.

Adjustable Arm

8.

Left -------- Right

9.

Connect to Capture 2s

1. Enable the Bluetooth on your mobile phone.

2. Long press the power button for 3 seconds to turn on the gimbal.

3. Launch Capture2 App

4. Follow the in-app instructions to Connect to Capture 2s.

Tips: After the above steps are completed, if you encounter problems, please refer to the troubleshooting guide on page 22 of the manual.

Documents / Resources

FUNSNAP Capture 2s Axis Gimbal [pdf] User Guide
Capture 2s, Axis Gimbal, Capture 2s Axis Gimbal, Gimbal

Manuals+,