Manuals+ — User Manuals Simplified.

Goowis Smart Camera IPC4-2 V1 User Manual

Goowls IPC4-2
Thank you for choosing Goowls Smart Camera
User Manual

Contents

Packing List

X1

X2

X2

X2

X2

IR LED

Microphone

Photoresistor

Lens

Reset Button

TF Card Slot

Please open the cover with a screwdriver to Insert or remove a TF card. (The reset button Is designed Inside)

Specification

Model	IPC4-2
Smart APP	Y1 IoT
Storage	4- 640/Closet 0 TF card, cloud o•,
Waterproof Certification	IP 65
Network	Wi- FiFreguency:2AGHz
Supported Protocols	IP, TCP, DHCP WPS
Image Sensor	1/2.7- inch CMOS
Resolution	1920x1080P/ 200 Mega Pixels
Lens	lid,
Compatible	Android / OS/ Windows
Wireless Encryption	WEP, WPA, WPA2
Power	5V/1A
Communication	Two-Way Audio/ Interco i

Component description

Please press and hold the reset button for about 5 seconds. You have reset the camera successfully when you hear the short voice.

It is recommended to insert a 4-64GB high-speed Micro TF card, otherwise, it will not be able to store, view historical video and support important functions such as firmware upgrading.

Install YI IoT APP

Download APP: scan the QR code below to download and install. Register and log in: open the YI IOT APP to register and log in according to the prompts.


http://www.yunyiiot.com/yunyiapp

YI IOT service supports PC downloads (Only support Windows, Mac cannot be supported) Please download from this website: **http://yunyiiot.com/html/download.html**

Add The Device

Please make sure that Goowls camera connects to the 2.4GHz Wi-Fi network and works well.(Not support 5G network)

Find the USB port on the bottom of the device and plug in the power cord to power it on, please wait 20 seconds until you hear "DiDiDi".

Then go to the APP home page, click the "+" on the main screen, configure according to the instructions in the APP

APP Video Browsing Details

| 1. Preview mode
2. Recording
3. Mute button
4. Intercom button | 5. More settings
6. Cloud Storage
7. Floating window
8. Full-screen preview | 9. Snapshot
10. History file (Make sure in
F card) |

How to connect with Amazon Alexa

Requirement:

1. Amazon Alexa device and Alexa app.

2. the smart Wi-Fi camera connected with YI loT App.

3. YI loT App user ID and password.

4. Please make sure your Alexa device has been added in the "Add Device" of the Alexa app

Add YI loT as a Skill for Alexa

Open the Alexa app and choose Skill & Games

-> Search for VI loT -> ENABLE TO USE -> Enter the VI loT account
-> Authorize to use
-> And then, the device you added on VI loT App will sync to Alexa App.
Also, you can ask Alexa to discover new devices for you at this moment.
Note: you need to set an exact name for the smart camera on VI loT App, if not, Alexa may tell you: " Sorry, I can't find the device named xxx…"

How can I receive the notification from the app?

Step 1:Make sure to turn on the Motion detection.

1. Enter the camera "Settings" of Y1 lot

2. Find the"Smart Detection-Settings-Motion"

3. Turn on the "Motion Detection"

4. Choose Sensitivity Level "High"

5. Schedule alert time"24-hour alert"

Step 2:Make sure to allow notification of phone.

1. 10S

    Enter the "Setting-Notifications-YI IOT app-Allow Notifications"

2. Andriod

    Enter the "Setting-Apps-YI loT-Notifications-Allow notifications-Lock screen notifications-Show"

Step 3:Please make sure both camera and phone are well connected.

1. Enter the "setting" of the phone

2.)Find the YI lot app

3. Click 'Wireless Data-WLAN&Cellular Data"

Warm tips

- To avoid the risk of electric shock, do not disassemble or attempt to repair the unit.
- Please make sure the camera is turned off before plugging in/out a TF card to avoid TF card damage or data loss.
- Never dispose of the product in fire or water, which may result in an explosion and/or injury.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Protect the adapter cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where it exits the unit. The unit should be situated away from direct sunlight or heat sources such as radiators, electronic heats, stoves, or other units that produce heat. Avoid placing on top of stereo equipment that radio heat.

Warranty

60 days money-back guarantee:
If you are not satisfied with this purchase, you can choose to refund this order within 60 days.
12 months limited warranty:
The device was used in proper technical working conditions.

Contact Us

We are always striving to be the best for our customers, and customer satisfaction is of paramount importance to us.
For any question or advice about our product, please don't hesitate to contact our customer service.
Email address: **amzservice@goowls.net**
Tel: **1-844-394-5218**

Documents / Resources

	GOOWIS Goowis Smart Camera IPC4-2 V1 [pdf] User Manual
	Goowis, Smart, Camera, IPC4-2, V1