Goowls IPC-2 Smart Camera User Manual

Goowls IPC-2 Smart Camera User Manual

Contents

Package

- 2 x Goowls WiFi indoor Camera
- 2 x Power adapter
- 2 x Power cord
- 2x Accessories
- 1 x User Manual

Front

Photoresistor ---------- o
IR LED ---------------- Lens

Back

Reset Button ---------- Reset
TF Card Slot ---------- Microphone
USB Interface

Please use the **"L"** reset tool in the accessory fat to complete the reset settings. Please press and hold the reset Mutton for about 5 seconds. when you hear the short voice. the camera is reset successfully.

Specification

Model	IPC1-2
Smart APP	VI loT
Storage	4-64G/Class10 TF card, cloud storage
Wi-Fi	Frequency: 2.4GHz
Image Sensor	1/2.7-inch CMOS
Resolution	1920x1080P/ 200 Mega Pixels
Lens	110°
Compatible	Android / OS / Windows
Wireless Encryption	WEP, WPA, WPA2
Power	5V / 1 A
Communication	Two-Way Audio! Intercom

Component description

Reset Button Press and hold Reset for about 5 seconds. When the horn sounds short voice, the reset is successful. It is recommended to insert 4-64GB high-speed Micro TF card, otherwise it will not be able to store, view historical video and support I mportant functions such as firmware upgrading.

1 install YI loT APP

Download APP: scan the QR code below to download and install. Register and login: open the YI IOT APP to registerand login according to the prompts.

YI IOT service supports PC downloads (Only support Windows, Mac cannot be supported) Please download from this website: **http://yunyiiot.com/html/download.html**

Add The Device

Please make sure that there is a available Wi-Fi and the Internet is connected. Find the USB port on the bottom of the device and plug in the power cord to power it on, please wait 20 seconds until you hear "DiDiDi". Then go to APP home page, click the **"+"** on the main screen, configure according to the instructions in the APP.

APP Video Browsing Details

1. Preview mode
2. Recording
3. Mute button
4. Intercom button
5. More settings
6. Cloud Storage

7. Floating window

8. Full screen preview

9. Snapshot

10. History file (Make sure insert Micro TF card)

How to connect with Amazon Alexa

Requirement:

1. Amazon Alexa device and Alexa app.

2. the smart Wi-Fi camera connected with VI loT App.

3. YI loT App user ID and password.

4. Please make sure your Alexa device has been added in the **"Add Device"** of the Alexa app

Add VI loT as a Skill for Alexa
Open Alexa app and choose Skill & Games

- ->Search for YI loT -> ENABLE TO USE

- -> Enter the VI loT account

- -> Authorize to use

- -> And then, the device you added on YI loT App will sync to Alexa App. Also, you can ask Alexa to discover new devices for you in this moment.

Note: you need to set exact name for the smart camera on VI loT App, if not, Alexa may tel you: " Sorry, I can't find the device named xxx…"

Warm tips

To avoid the risk of electric shock, do not disassemble or attempt to repair the unit. Please make sure the camera is turned off before plugging in/out a TF card to avoid TF card damage or data loss. *Never dispose of the product in fire or water, which may result in explosion and/or injury. *Unplug this unit during lightning storms or when unused for long periods of time. Protect the adapter cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where it exits the unit. The unit should be situated away from direct sunlight or heat sources such as radiators, electronic heats, stoves, or other units that produce heat. Avoid placing on top of stereo equipment that radio heat.

Warranty

60 days money-back guarantee: If you are not satisfied with this purchase, you can choose to refund this order within 60 days. 12 months limited warranty: Device was used in proper technical working condition.

Contact Us

For any inquiries or comments concerning our product, please send
Email to: amzservice@goowls.net
Tel: 1-844-394-5218
Your advice is very much appreciated.

Documents / Resources

	Goowls IPC-2 Smart Camera [pdf] User Manual IPC-2 Smart Camera