Manuals+ — User Manuals Simplified.

# HOVER Camera User Guide

Contents

HOVER Camera

OVERVIEW

- Power Button
- LED Indicator Light
- Flash
- Camera
- USB Port
- Battery
- Top Plate
- Side Frame

- 9,11: Propeller (CW*)
- 10,12: Propeller (CCW*)
- 13: Bottom Plate
- 14: Sonar
- 15: Optical Flow Sensor
- 16: Heat Vent

Download the Hover Camera App

Scan the QR code below to download and install the Hover Camera App.

Download the User Manual from the official website for more information.

This guide is subject to change without prior notice. Please visit the official website for more detailed information.

Charge the Battery

To charge batteries, plug them into the battery charger

**Note:** The charger can charge up to 2 batteries at a time.

- **Solid Yellow:** Charging
- **Solid Green:** Fully Charged

Note: A fully charged battery offers a better flying experience.

Plug in/ Remove the Battery

Press and hold the grips on each side of the battery, and pull the battery out firmly as demonstrated.

Turn on and connect

- Press the power button for 2 seconds until the green LED indicator light blinks twice.
- Wait for approximately 15 seconds for Hover Camera Passport to initialize. Once it's finished booting up, you will hear a sound. At the same time Hover Camera Passport's power light will stop flashing and turn into a solid color.

- Enter the Wi-Fi Settings screen on your device and connect the device to the "Hover Camera" hotspot.

Wi-Fi Name:
HoverCamera_XXXXXX

Default Password:
12345678

- We recommend you to change your Wi-Fi name and default password.

Release and Hover

- Unfold Hover Camera Passport and hold it level to the ground. Press the power button to start the propellers.


Caution: Do not cover the optical flow sensor or sonar before releasing it.

- When the propellers speed up, let go!


Control Your Hover Camera Passport

- Open the Hover Camera App and enjoy flying Hover Camera Passport.

Retrieve/Land Hover Camera Passport

- Grab Hover Camera Passport as demonstrated, and then press the power button to stop the propellers.

- Or tap the "Landing" icon in the app to land Hover Camera Passport.

Caution: Do not insert finger or object into the frame.

Please check the Disclaimer and Safety Instructions for more details at: zzrobotics.com/support

zzrobotics.com

Copyright © 2016 Shenzhen Zero Zero Infinity Technology Co., Ltd. All Rights Reserved.

Documents / Resources

	HOVER Camera [pdf] User Guide Camera