HyperX HX-HSCSCX-BK CloudX Stinger Core Wireless Headset User Guide

HyperX CloudX Stinger Core
Wireless Headset
CS005
QUICK START GUIDE

Contents

1 Overview
2 Charging
3 Setup for Xbox Console Usage
4 Volume Wheel
5 Game/Chat Balance Wheel
6 Questions or Setup Issues?
7 Documents / Resources
8 Related Posts

Overview



A. Swivel-to-mute microphone
B. Status LED
C. Power button
D. Volume wheel
E. USB charge port
F. Pairing button
G. Game/chat balance wheel
H. USB charge cable

Charging

It is recommended to fully charge the vow headset before first use



CHARGE STATUS	LED
Fully charged	Solid white
15%— 99% battery	Breathing white
<15%battery	Breathing red

Power Button
Power on/off – Hold the power button for 3 seconds
Mic monitoring
Short press paver button to toggle mic monitoring on/off

Setup for Xbox Console Usage



1. Power on the Xbox console. Press the connect button on your Xbox Console. The Xbox logo on the console will start blinking
2. Power on the headset. Press and hold the pairing button for 3 seconds to enter pairing mode. The headset status LED will start blinking green
3. The headset will connect to the Xbox Console.

Volume Wheel

Scroll up or down to adjust the volume level.
WARNING: Permanent hearing damage can occur a headset is used at ..s for extended periods of time.

Game/Chat Balance Wheel

Scroll up or down to adjust the mix between game audio and chat audio.

The game/chat balance functionality operates independently from the overall headset audio volume Swivel to Mute Microphone.

Questions or Setup Issues?

Contact the HyperX support tear- hyperxgaming.com/support/headsets
Swivel to mute Microphone.



Documents / Resources

	HyperX HX-HSCSCX-BK CloudX Stinger Core Wireless Headset [pdf] User Guide HX-HSCSCX-BK, CS005, CloudX Stinger Core Wireless Headset

Manuals+,