Manuals+ — User Manuals Simplified.

i Board IB-027C Running Boards Nerf Bars Side Steps

i Board IB-027C Running Boards Nerf Bars Side Steps Instruction Manual

Contents

iBoard®

**i Board IB-027C Running Boards Nerf Bars Side Steps**

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM THE BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

- ROCKER PANEL MOUNT
- NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)	Required
6mm	6-7	X
8mm	16-18	√
10mm	31-32	X
12mm	56-58	X
14mm	92-94	X

PART LIST

Front

Driver Side Step Bar

Passenger Side Step Bar

1#

2#

2#

1#

Mounting Bracket List

Item	QTY	Description	Item	QTY	Description
1#	2	Passenger Front / Driver Rear Mounting Brackets	2#	2	Driver Front / Passenger Rear Mounting Brackets

- Hardware Package A (For Bracket Installation)

Item	QTY	Description	Item	QTY	Description
1#	12	M8X1.25-30mm Hex Bolts	3#	12	M8 Lock Washers
2#	12	M8 Large Flat Washers	4#	8	M8X1.25 Clip Nuts
		1 #	2 #	3 #	4 #

- Hardware Package B (For Stainless Steel Step Bar Installation)

| Item	QTY	Description	Item	QTY	Description
1#	8	M8X1.25-35mm Carriage Bolts	3#	8	M8 Nylon Lock Nuts
2#	8	M8 Large Flat Washers	4#	4	Sliders (Packed with Step Bars)

1#   2#   3#

4#

STEP 1

Start installation from the driver-side front of the vehicle. Locate on the backside of the rocker panel (3) mounting holes where the plastic fascia is cut out. Select (2) M8 Clip Nuts, and line up the Clip Nuts with the holes. Locate a threaded hole above the clip nuts on the rocker panel. If equipped, remove the plug to expose the threaded hole. **NOTE:** Threaded nut on Clip nut must face inside of the side panel, (Fig 1).

**(Fig 1) Driver Side Front Mounting Location**

STEP 2

Attach the assembled Driver Front Bracket to the installed M8 Clip Nuts with the included (2) M8X1.25-30mm Hex Bolts, (2) M8 Lock Washers and (2) M8 Large Flat Washers; to the threaded hole using (1) M8X1.25-30mm Hex Bolt, (1) M8 Lock Washers and (1) M8 Large Flat Washer, (Fig 2). Do not fully tighten at this time.

(Fig 2) Driver Front Mounting Bracket Installation

- (2) installed Clip Nuts
- (3) M8X1.25-30mm Hex Bolts
- (3) M8 Flat Washers
- (3) M8 Lock Washers

STEP 3

Move to the driver-side rear mounting location. Repeat Steps 1—2 to install (1) Driver Rear Mounting Bracket, (Fig 3). Do not fully tighten the hardware at this time.

(Fig 3) Driver Rear Mounting Bracket Installation

- (2) installed Clip Nuts
- (3) M8X1.25-30mm Hex Bolts
- (3) M8 Flat Washers
- (3) M8 Lock Washers

STEP 4
Once all (2) Driver side mounting brackets are installed, then proceed to the Step Bar installation. (Figs 4 & 5)

(Fig 4) Slider Installation

(Fig 5) Step Bar Installation

1. Select (1) Slider and (2) M8X1.25-35mm Carriage Bolts;
2. Install (2) M8X1.25-35mm Carriage Bolts in (1) Slider.
3. Slide the Slider (with carriage bolts) to the Step Bar.
4. Repeat to install the other (1) slider to the step bar.
5. Attach the Step Bar (with the Sliders) to the installed mounting brackets.
6. Position the Sliders to the installed brackets. Secure the Step Bar to the installed Brackets by using (4) M8 Large Flat Washers (4) M8 Nylon Lock Nuts and (2) Sliders, (Fig 5). Do not fully tighten the hardware at this time.

   Note: The Sliders are packed with the Step Bars. Level and adjust the Step Bar and fully tighten all hardware. Repeat Steps 1-4 for the other side Step Bar installation. The installation is completed!!!

Attention

- Do periodic inspections of the installation to make sure that all hardware is secure and tight.
- To protect your bars/boards, please use mild soap/non-abrasive products for cleaning only.

Documents / Resources

i Board IB-027C Running Boards Nerf Bars Side Steps [pdf] Instruction Manual
IB-027C Running Boards Nerf Bars Side Steps, IB-027C, Running Boards Nerf Bars Side Steps
, Boards Nerf Bars Side Steps, Nerf Bars Side Steps, Side Steps

References

- **User Manual**