Manuals+ — User Manuals Simplified.


IQUNIX OG80 Series: Wireless Mechanical Keyboard Instruction Manual

The IQUNIX OG80 Series Wormhole Wireless Mechanical Keyboard Instruction Manual provides users with comprehensive information on how to use this high-quality mechanical keyboard. This manual is designed to help users understand the various features of the IQUNIX OG80 Series keyboard, including LED indicator status descriptions, special keys combinations, and the three ways of connecting devices. The manual explains how to connect the keyboard through Bluetooth mode, 2.4GHz mode, and wired mode. It also provides users with safety precautions and information about the manufacturer and packing list. The IQUNIX OG80 Series keyboard is a high-performance mechanical keyboard that is designed to meet the needs of professionals and gamers alike. By reading this manual thoroughly, users can unlock the full potential of this keyboard and enjoy a seamless typing experience.

Contents

IQUNIX L80 Series Mechanical Keyboard

0G80 SERIES
MECHANICAL KEYBOARDS

We recommend that you read this manual thoroughly before using the product.

LED Indicator Status Description

- Red Light Blinking

  Low Battery Level

- Blue Light Blinking / Flashing

  Bluetooth Device #1 Re-Connecting / Pairing On

- Turquoise Light Blinking / Flashing

  Bluetooth Device #2 Re-Connecting / Pairing On

- Yellow Light Blinking / Flashing

  Bluetooth Device #3 Re-Connecting / Pairing On

- Pink Light Blinking / Flashing

  2.4GHz Device Re-Connecting / Pairing On

- White Light On/ Blinking

  Caps Lock On & Off / Special Keys Combination Enabled

Hold **FN** first, then corresponding keys to enable special keys combination.
Short Press: Hold FN first, then the corresponding key, and release both keys.
Long Press: Hold FN first, then the corresponding key. Hold for 5 seconds until the indicator starts blinking.

Three Ways of Connecting Devices

Bluetooth Mode

1. Toggle the keyboard Mode Switch to the wireless side.

2. Short Press **FN** + **! 1** to make the indicator blink in blue,

   then Long Press **FN** + **! 1** to make the indicator flash in blue.

3. Select the pairing device [IQUNIX L80 BT 1]. The indicator turns off when the keyboard is paired successfully. In order to complete the pairing of the keyboard with a second or third new Bluetooth device, repeat the instructions from Step 8 and replace the "FN+1" with "FN+2" or "FN+3". The devices will be shown as [IQUNIX L80 BT 2] and [IQUNIX L80 BT 3].

2.4GHz Mode

1. Toggle the keyboard Mode Switch to the wireless side.

2. Plug the 2.4GHz receiver into your computer.

3. (D Press **FN** + **$ 4** to enter 2.4GHz pairing mode. The indicator turns off when the keyboard is paired successfully.

Wired Mode

1. Toggle the keyboard Mode Switch to the wired side.

2. Plug the USB cable into your device.

*When being plugged into the computer, the keyboard will start to charge automatically.
*Caution: The rated power for the charger must not exceed 5V=1A. Connection to a higher power output will damage the keyboard.

Special Keys Combinations

Long Press FN+TAB: Switch Between Mac/Windows Layout

TAB

Short Press FN+Enter:
Play/Pause

ENTER

Short Press FN+←:
Previous

B

WIN

FN

◁

▷

Short Press FN+→:
Next

Long Press FN+Win:
WinLock

Long Press FN+Space:
Reset to Default

Short Press FN+B: Battery Level Check
The LED Indicator blinks 1, 2, 3,...10 times, which stands for 10%, 20%, 30%,...100% battery level)

Backlight Keys Combinations (Short Press)

DEL --- FN+Del: Backlight On/Of

PGUP --- FN+PgUp: Brightness +

PGDN --- FN+PgDn: Brightness −

HOME --- FN+Home: Backlight Effects Switching

△ END --- FN+End: Backlight Colors Switching

▽

FN

FN+↑: Backlight Speed +   FN+↓: Backlight Speed −

*Available for Backlit version only.

Keyboard Layout

Follow us: IQUNIX

To learn more details, please reach out to us on official website or social media. Official website: **www.IQUNIX.store**

- **Series:** LSD
- **Number** of Keys: 83
- **Input:** 5V=1A
- **Battery** Specifications: 3.7V 4000mAh
- **Precautions:** See Warranty Card
- **Manufacturer:** Shenzhen Silver Storm Technology Co., Ltd. A905, Rongchaobinhai Bldg., Haixiu Rd., Bao'an District, Shenzhen, China
- **Packing List:** Keyboard, Dust Cover, USB Cable, 2.4GHz Receiver, Keycap & Switch Puller, Bluetooth Dongle, Manual, Warranty Card

SPECIFICATION

Product Specification	Description
Series	OG80
Number of Keys	83
Input	5V=1A
Battery Specifications	3.7V 4000mAh
Precautions	See Warranty Card
Manufacturer	Shenzhen Silver Storm Technology Co., Ltd. A905, Rongchaobinhai Bldg., Haixiu Rd., Bao'an District, Shenzhen, China
Packing List	Keyboard, Dust Cover, USB Cable, 2.4GHz Receiver, Keycap & Switch Puller, Bluetooth Dongle, Manual, Warranty Card

FAQS

What is included in the packing list for the IQUNIX OG80 Series keyboard?

The packing list includes the keyboard, dust cover, USB cable, 2.4GHz receiver, keycap & switch puller, Bluetooth dongle, manual, and warranty card.

How do I connect the IQUNIX OG80 Series keyboard through wired mode?

To connect through wired mode, toggle the keyboard Mode Switch to the wired side. Plug the USB cable into your device. The keyboard will start to charge automatically.

How do I connect the IQUNIX OG80 Series keyboard through 2.4GHz mode?

To connect through 2.4GHz mode, toggle the keyboard Mode Switch to the wireless side. Plug the 2.4GHz receiver into your computer. Press "FN+D" to enter 2.4GHz pairing mode. The indicator turns off when the keyboard is paired successfully.

How do I connect the IQUNIX OG80 Series keyboard through Bluetooth mode?

To connect through Bluetooth mode, toggle the keyboard Mode Switch to the wireless side. Short press "FN+1" to make the indicator blink in blue, then long press "FN+1" to make the indicator flash in blue. Select the pairing device [IQUNIX L80 BT 1]. The indicator turns off when the keyboard is paired successfully. To pair with a second or third new Bluetooth device, repeat the instructions and replace "FN+1" with "FN+2" or "FN+3". The devices will be shown as [IQUNIX L80 BT 2] and [IQUNIX L80 BT 3].

What are the three ways of connecting devices to the IQUNIX OG80 Series keyboard?

The three ways of connecting devices are Bluetooth mode, 2.4GHz mode, and wired mode.

How do I enable special keys combinations on the IQUNIX OG80 Series keyboard?

To enable special keys combinations, hold "FN" first, then the corresponding key. For short press, release both keys. For long press, hold for 5 seconds until the indicator starts blinking.

What are the LED indicator status descriptions for the IQUNIX OG80 Series keyboard?

The LED indicator status descriptions are as follows: – Red Light Blinking: Low Battery Level – Blue Light Blinking / Flashing: Bluetooth Device #1 Re-Connecting / Pairing On – Turquoise Light Blinking / Flashing: Bluetooth Device #2 Re-Connecting / Pairing On – Yellow Light Blinking / Flashing: Bluetooth Device #3 Re-Connecting / Pairing On – Pink Light Blinking / Flashing: 2.4GHz Device Re-Connecting / Pairing On – White Light On/ Blinking: Caps Lock On & Off / Special Keys Combination Enabled

Documents / Resources

IQUNIX **OG80 SERIES** MECHANICAL KEYBOARDS We recommend that you read this manual thoroughly before using the product. Start Reading →	**IQUNIX OG80 Series Wormhole Wireless Mechanical Keyboard** [pdf] Instruction Manual OG80 Series, OG80 Series Wormhole Wireless Mechanical Keyboard, Wormhole Wireless Mechanical Keyboard, Wireless Mechanical Keyboard, Mechanical Keyboard, Keyboard