JBL E65BTNC Manual

HBL E65BTNC

Contents

1 1. What’s in the box
  1.1 E65BTNC
  1.2 Charging cable
  1.3 Detachable audio cable with remote
  1.4 Warranty card, Warning card, Safety sheet, QSG
2 2. Overview
  2.1 a. Buttons & LEDs
  2.2 b. Connections
3 3. Bluetooth ® Connection
4 4. Controlling music
5 5. Managing phone calls
6 6. Voice Assistant
7 7. Wired listening mode
8 8. Active noise cancelling (ANC)
9 9. Seamlessly switch between devices
10 Items to note:
11 10. LED behavior
12 Specification
13 Related Posts

1. What’s in the box

E65BTNC

x1

Charging cable

x1

Detachable audio cable with remote



x1

Warranty card, Warning card, Safety sheet, QSG

x1

2. Overview

a. Buttons & LEDs

b. Connections



3. Bluetooth ® Connection

1. Turn on the headphone

***Note**: A 3 seconds interval is necessary between switching the headphones on and off again to avoid false trigger.*

2. If connecting for the first time, the headphone will enter the pairing mode automatically after it is powered on
3. Connect to Bluetooth device



Choose "JBL E65BTNC" to connect



4. Controlling music



5. Managing phone calls



6. Voice Assistant



7. Wired listening mode



8. Active noise cancelling (ANC)

1. ANC is on as factory default.
2. In wireless listening mode, long press ANC button to switch it off and on.
3. In wired listening mode, power on the headphone and long press ANC button to switch it on; power off the headphone to switch the ANC off.



9. Seamlessly switch between devices

1. Pair and connect the headphone with the 1st Bluetooth device (see Section 3 Bluetooth Connection)
2. Pair and connect the headphone with the 2 nd Bluetooth device



3. Connect to Bluetooth device



4. Go back to the Bluetooth device list on the 1st device and select the headphone* to connect

Items to note:

a. Maximum 2 devices can be connected simultaneously

b. To switch music source, pause the music on the current device and select play on the 2 nd device.
c. Phone calls will always take priority.
d. If one device goes out of Bluetooth range or powers off, you may need to manually reconnect the other device. See Section 9 Step 3.

10. LED behavior



Headphone mode	LED Status
Power on	Slow
BT Pairing	Fast
BT Connected	On
Low Battery	Slow
Charging Complete	Off
Charging in Progress	On
ANC	On
ANC	Off

Specification

- **Driver size:** 40mm
- **Dynamic frequency response range:** 20Hz-20kHz
- **Sensitivity:** 95dB
- **Maximum SPL:** 108dB
- **Microphone sensitivity:** @1kHz dB v/pa: -42
- **Impedance:** 32ohm
- **Bluetooth transmitted power:** 0-4dbm
- **Bluetooth transmitted modulation:** GFSK, π/4DQPSK, 8DPSK
- **Bluetooth frequency:** 2.402GHz-2.48GHz
- **Bluetooth profiles:** HFP v1.6, HSP v1.2, A2DP v1.2, AVRCP v1.4
- **Bluetooth version:** V4.1
- **Battery type:** Polymer Li-ion Battery (3.7V, 610mAh)
- **Charging time:** 2 hours
- **Talk time with BT on:** Up to 24 hours
- **Music play time with BT on and ANC off:** Up to 24 hours
- **Music play time with BT on and ANC on:** Up to 15 hours
- **Music play time with BT off and ANC on:** Up to 30 hours
- **Weight (g):** 258g

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.

JBL E65BTNC Manual – **Optimized PDF**
JBL E65BTNC Manual – **Original PDF**

Manuals+,