Manuals+ — User Manuals Simplified.

JENSEN CAR1013 Media Receiver With Android Auto And CarPlay User Guide

Contents

CAR1013 Media Receiver With Android Auto And CarPlay

Specifications

- Model: CAR1013
- Designed and Engineered in: USA

Quick Start Guide

This Quick Start Guide will help you get started with your CAR1013. For detailed instructions, please download the complete owner's manual from **https://www.jensenmobile.com** or contact customer service at 1-888-921-4088 (Monday-Friday, 9AM-5PM EST).

1. **Step 1: Power On**

   Ensure that your CAR1013 is connected to a power source. Press the power button located on the device to turn it on.

2. **Step 2: CD Playback**

   To play a CD, insert the CD into the CD slot. The CAR1013 will automatically start playing the CD. Use the controls on the device to adjust the volume, skip tracks, and pause/play.

3. **Step 3: USB Playback**

   To play music from a USB device, connect the USB device to the USB port on the CAR1013. The device will detect the USB and start playing the music files. Use the controls on the device to navigate through the files and control playback.

4. **Step 4: Radio**

   To listen to the radio, press the "Radio" button on the device. Use the tuning knob to select your desired radio station. Use the volume control to adjust the volume.

Wiring Diagram – Inputs/Outputs

Note: When replacing a fuse, make sure to use the correct type and amperage. Using an incorrect fuse could cause damage. The unit uses (1) 15 amp ATC mini style fuse located on the power connector.

Installation

For detailed installation instructions, please refer to the included Installation Guide.

Screen Adjustments

Control Locations

The radio display features the following functions and displays:

1. Voice Activation Button
2. CD SOURCE/HOME
3. PowerNolume/Mute
4. Previous Button
5. Next Button
6. RESET

Main Menu

In main menu, press the desired icon to enter the corresponding mode: AM/FM/Bluetooth Phone/ Bluetooth Audio/Apple CarPlay/Android Auto/USB/ Camera/EQ /AV In/Settings

Tuner Operation

1. Main Menu
2. Dimmer
3. Local/Distance
4. Seek Tune Up
5. Seek Tune Down
6. Preset Stations
7. Settings
8. EQ

USB Operation

1. Main Menu
2. Current Mode Indicator
3. Repeat
4. Random
5. List
6. ID3 Tag Display Area
7. Track Down
8. Play/Pause
9. Track Up
10. Album Art

Audio Operation

Select from the below 3 icons in the Settings menu to select between Balance, Fader and Time Alignment Settings, EQ Presets and 10-Band EQ Settings or Surround Settings


Screen Operation

Press the Monitor icon in the Settings menu to access the Brightness, Contrast, Button Illumination Colors and Wallpaper Settings.

General Operation

Press the Function icon in the Settings menu to access the Time Zone, Date and Time and other radio Settings.


Wired & Wireless CarPlay Operation

Wired connedion

1. Connect an Apple CarPlay compatible device to this unit via USB.
2. Press the Apple CarPlay icon.

The Apple CarPlay home screen appears.

Wireless connedion
Before using Apple CarPlay wirelessly. tum on the Bluetooth/Wifi function on the Phone.

1. Press icon on the main menu:

2. Press " ✔ " to confirm to use wireless CarPlay:

3. Press 🔍 "icon to search phone device. The available devices appear on the list:

4. Find the desired device on the screen and press "Pair":

5. A pass key will be displayed on the screen:

6. The same key appears on the iPhone. press "Pair" and then press "Allow" for the popups:

7. Press ✔ "on the screen to confirm to connect:

8. Press "Use CarPlay" on the iPhone. The unit configures the connection then starts the application.

Wired & Wireless Android AutoTM Operation

Wired connedion

1. Connect an Android Auto™ compatible device to this unit via USB.

2. Press the Android Auto icon.

The Android Auto home screen appears

Wireless connection
Before using Android Auto wirelessly. tum on the Bluetooth/Wifi function on the Android device.

1. Press 🔺 icon on the main menu:

2. Press ✔ " to confirm to use wireless Android Auto:

3. Press 🔍 icon to search phone device. The available devices appear on the list:

4. Find the desired device on the screen and press "Pair":

5. A pass key will be displayed on the screen,

6. The same key appears on the Android device. press "Pair" and then press "Allow" for the popups:

7. Press ✔ " on the screen to confirm to connect: The unit configures the connection then starts the application.

Bluetooth Operation

Before using Bluetooth
Before you can use a Bluetooth device to make hands-free calls or stream audio. it must be authenticated.
This is also referred to as "pairing" a device.

Pairing a New Device
The unit broadcasts the pairing signal constantly when no devices are currently connected. Complete the pairing sequence from your Bluetooth device. Refer to the owner's manual for your device for more
details. The device name is The unit can be in any mode of operation when pairing is performed.
On certain phones. pairing may need to be done more than once.

Connect
The head unit will automatically connect to the last connected device when the connect feature is set to Auto connect On.
If the connect feature is set to Auto Connect Off. the head unit will not automatically connect to any device.

Bluetooth Phone
From the main menu. touch the Bluetooth on the screen.
Bluetooth icon will appear anytime a Bluetooth device is connected.

DiaUng a Number

Press ▦ to display keypad and dial a number.

Making and Ending a Call

Press ☎. to connect a call, and press 📞 to end a call.

Transferring Audio

Press ▦ to transfer andio between the head unit and mobile phone.

Streaming Audio

- Press ► to play or pause the music.
- Press I◄ to skip to the previous track.
- Press ► I to advance to the next track.

Rear Camera

Limited Three Year* Warranty

- This warranty gives you specific legal rights. You may also have other rights which vary from state to state. Jensen warrants this product to the original purchaser to be free from defects in material and workmanship for a period of three years from the date of the original purchase.
- Jensen agrees, at our option, during the warranty period, to repair any defect in material or workmanship or to furnish an equal new, renewed, or comparable product (whichever is deemed necessary) in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase. Subsequent replacement products are warranted for the balance of the original warranty period.
- What is covered? This warranty covers all defects in the material and workmanship in this product.
- The following are not covered: software, installation/removal costs, damage resulting from accident, misuse, abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair, or failure to follow instructions supplied with the product, or damage occurring during return shipment of the product. Specific license conditions and copyright notices for the software can be found via **www.jensenmobile.com.**

Warranty Coverage
Limited 3-year warranty. (Proof of purchase required) Jensen recommends professional installation of any electronics in your vehicle to ensure the best performance.

What to do?

1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any custom controls may save you a service call.
2. If you require service during the warranty period, you must carefully pack the product (preferably in the original package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized service center.
3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not acceptable), and a daytime phone number with your shipment.
4. For more information and for the location of the nearest authorized service center please contact us by one of the following methods:

- Call us toll-free at (888) 921-4088 (Monday-Friday, 9:00 am, to 5:00 pm, Esn
- E-mail us at **cs@jensenmobile.com**

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or

implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence, actual or imputed. No person or representative is authorized to assume for the company any other liability in connection with the sale of this product. In no event shall the company be liable for indirect, incidental, or consequential damages.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions,

1. this device may not cause harmful interference. and
2. this device must accept any interference received, including interference that may cause undesired operation

Warning, Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures,

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Installation Guide

Preparing for Installation

Package Contents

1. Main Unit
2. Mounting Sleeve
3. Release Keys
4. Screw Kit
5. Bracket For 2 Din
6. Trim Ring
7. Wiring Harness
8. Microphone
9. GPS Antenna (for CarPlay and Android Auto only)

①　②　③

④
Mounting Screw for 2DIN Bracket M2.5*6 5PCS
Flat Head Screw M5*6 8pcs
Round Head Screw M5*6 8pcs

⑤　⑥

⑦　⑧　⑨

Before You Begin

- Consult a qualified technician for instructions.
- We always recommend professional installation.
- Disconnect the negative battery terminal.
- Remove trim ring from unit (if installed).
- Insert the removal keys, and remove the mounting sleeve from the receiver.

Note: Most vehicles require an installation kit, wiring harness and/or antenna adapter (all sold separately) to properly install the head unit in the vehicle.

Install Mounting Sleeve and Trim Ring

1. Install the mounting sleeve into a dash kit (sold separately) or dash opening, bending the tabs to secure the mounting sleeve.
2. Connect the wiring harness, microphone and antenna to the chassis of the radio.
3. Snap trim ring into place making sure the notched area is on the bottom.
4. Slide the receiver into the mounting sleeve to secure.

Connecting the LCD to the Chassis Kansall

To connect the LCD to the unit, carefully push the LCD connector into the receiver's chassis, until you hear a click as shown below.


Removing the LCD from the Chassis

1. Hold down the two release buttons

2. Gently pull the dis.play panel forward

Installing the 2-DIN Bracket

Attach the 2-DIN bracket using (4) M2.5*4 screws

2-DIN Bracket

A

Install the 2-DIN mounting bracket to the top of the chassis (shown above) or to the bottom of the chassis (shown below).

OR

B

Install Mounting Brackets

Mounting brackets shown below or optional vehicle mounting kit are not included

Install the mounting brackets to the chassis of the radio or to the 2-DIN bracket depending on choice of mounting option as shown in Step #1 to the left.

Installation Complete

Register your warranty

Scan to register, or visit:
https://iensenmobile.com/register.html
Upon registration you may also choose to be notified of product updates or special promotions.

Visit **www.jensenmobile.com** for detailed owner's manuals on most products.
If you need any assistance, please contact customer service at **cs@iensenmobile.com** or call 1-888-921-4088
M-F 9 am – 5 pm ET
Thank you for your purchase!

www.JensenMobile.com Follow us to keep up to date with new products and information! Facebook @JensenAudio Instagram @JensenAudio Twitter @JensenAudio

---

Documents / Resources

JENSEN CAR1013 Media Receiver With Android Auto And CarPlay [pdf] User Guide
CAR1013 Media Receiver With Android Auto And CarPlay, CAR1013, Media Receiver With
Android Auto And CarPlay, Receiver With Android Auto And CarPlay, Media Receiver, Receiver

References

- ⊕ **Home - Jensen Mobile**
- ⊕ **Home - Jensen Mobile**
- **User Manual**