Keystone LDTR02 Wireless Remote User Guide

LDTR02 Wireless Remote
User Guide



1. For the function instruction of the front plate please see picture 1
2. Press the power on button for 3 seconds to start the remote, the blue wireless light will be on.
   The remote will close if there is no operation within 2mins by itself. Press the OUT button, the winch will send out the rope (nylon rope /steel wire rope), press IN button, which will recycle the rope (nylon rope /steel wire rope)
3. The voltage of the sender: is DC2-3.0V voltage of the receiver: is DC9-15V

4. Distance 515M Due to the interference from the actual environment always changes when in use, So the usage distance of the remote will change (distance is shorter).
5. To learn the matching function, keep pressing the power on button of the sender until the green light flicker, in the meantime press the learn button on the receiver until the red light on, flickers, and closed with the voice “tick”, then it means it’s successful to match the sender.
6. the receiver function please see picture 2

Contents

1 FCC Statement:
2 Documents / Resources
3 Related Posts

FCC Statement:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
RF warning for Portable devices:
The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
ISED RSS Warning:
This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
ISED RF exposure statement:
This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirements.

Documents / Resources

	Keystone LDTR02 Wireless Remote [pdf] User Guide LDTR02, 2AWOX-LDTR02, 2AWOXLDTR02, LDTR02 Wireless Remote, LDTR02, Wireless Remote

Manuals+.