Manuals+ — User Manuals Simplified.

kwikset How to Enable Alexa Voice Control Instruction Manual

Kwikset
How to Enable Alexa Voice Control

There are two ways to enable Alexa voice control of your Kwikset Halo Smart Lock:
Method 1 – Linking the Kwikset Smart Home skill
Method 2 – Adding a lock to your Alexa account (page 3)

Contents

Method 1 – Linking the Kwikset Smart Home skill

1. On your Android or iOS the device, open the Alexa app.	2. Tap on the hamburger menu.	3. Tap on Skills and Games.

4. Tap the search icon on the upper right of the screen.	5. Search for "Kwikset Smart Home " and tap on it.	6. Tap Enable to Use.
7. On the account linking page, ent er your Kwikset app username and password, then tap Sign In.	8. When the accounting linking is c omplete, tap the X in the top right c orner to continue to devise discover y.	9. Tap "Discover Devices" to show t he newly discovered Halo devices t hat you can control using Alexa.

Continue to the next page for additional steps.

How to Enable Alexa – Method 1 (Continued)

10. Wait while Alexa searches for your device.	11. After your device is discovered, tap Set Up Device.	12. You can tap Skip or tap Choose Group to add your device to a group.
13. Tap the group name and Add to Group to add the device.	14. The device is now in the group. Tap Continue.	15. Your device is now ready to use. Tap Done.

|		
SETUP **Where is your lock?** YOUR GROUPS Family Room Master Bedroom COMMON GROUPS Kitchen Dining Room SKIP **ADD TO GROUP**	**SETUP** ✓ **Front Door added to Family Room** Now you can refer to this device using room name and device type instead of remembering the device name. **CONTINUE**	**SETUP** ✓ **Front Door is set up and ready to use** To control it, say "Alexa, lock Front Door" **DONE**
16. You're done! Now, you are able to use the following commands: "Alexa, is [Lock Name] unlocked?" "Alexa, is [Lock Name] locked?" "Alexa, lock [Lock Name]." "Alexa, unlock [Lock Name]." **NOTE:** Unlocking will require an additional PIN for security.	For a secondary method of enabling Alexa, continue to the next page.	

How to Enable Alexa – Method 2

Method 2 – Adding a lock to your Alexa account

1. On your Android or iOS device, open the Alexa app.	2. Tap on the hamburger menu.	3. Tap on Add Device.

4. Scroll down until you see Lock then tap on it.	5. Scroll down until you see Kwikset Halo then tap on it.	6. Set up your Kwikset account and activate your lock if you haven't already. If your Kwikset account is already set up and your lock is already activated, tap Continue.

7. Tap Enable to Use.	8. On the account linking page, enter your Kwikset app username and password, then tap Sign In.	9. When the accounting linking is complete, tap the X in the top right corner to continue to devise discovery.

How to Enable Alexa – Method 2 (Continued)

10. Tap "Discover Devices" to show the newly discovered Halo devices that you can control using Alexa.	11. Wait while Alexa searches for your device.	12. After your device is discovered, tap Set Up Device.

Discover Devices Smart Home devices must be discovered before they can be used with Alexa. CANCEL DISCOVER DEVICES	**Alexa is looking for devices to connect...** This may take up to 45 seconds	Alexa found a device called "Front Door" ✓ **1 Kwikset Halo lock found and connected** Your lock has been added to your Alexa account. Next, continue setting up your device. SET UP DEVICE Home Communicate Play Devices
13. You can tap Skip or tap Choose Group to add your device to a group.	14. Tap the group name and Add to Group to add the device.	15. The device is now in the group. Tap Continue.
SETUP **Add your lock to a group** To keep your devices organized, place your lock in a group. SKIP CHOOSE GROUP	‹ **SETUP** **Where is your lock?** YOUR GROUPS Family Room Master Bedroom COMMON GROUPS Kitchen Dining Room SKIP ADD TO GROUP	**SETUP** ✓ **Front Door added to Family Room** Now you can refer to this device using room name and device type instead of remembering the device name. CONTINUE

16. Your device is now ready to use . Tap Done.	17. You're done! Now, you are able to use the following commands: "Alexa is [Lock Name] unlocked?" "Alexa, is [Lock Name] locked?" "Alexa, lock [Lock Name]." "Alexa, unlock [Lock Name]."	
	NOTE: Unlocking will require an additional PIN for security.	

Documents / Resources

	kwikset How to Enable Alexa Voice Control [pdf] Instruction Manual Kwikset, Enable, Alexa, Voice, Control, Smart Home