Manuals+ — User Manuals Simplified.

Logitech BOOM 3 Super-Portable Wireless Speaker

# Logitech BOOM 3 Super-Portable Wireless Speaker User Manual

Contents

logitech G

**Logitech BOOM 3 Super-Portable Wireless Speaker User Manual**

GET STARTED

POWER ON THE SPEAKER
SHORT PRESS the Power button to turn on your BOOM 3

PAIR YOUR PHONE TO THE SPEAKER
PRESS AND HOLD the Bluetooth® button to put it in pairing mode. Go to the Bluetooth® setting on your phone and select BOOM 3 to connect.

USE THE MAGIC BUTTON

- USE THE MAGIC BUTTON TO CONTROL YOUR MUSIC
- SHORT PRESS to play and pause
- DOUBLE PRESS to skip a track



ADJUST VOLUME
PRESS the "+" / "−" button to increase/decrease volume.

CHARGE YOUR SPEAKER
LIFT THE WEATHER DOOR to charge using the USB cable. You can also charge your speaker by placing it on a POWER UP charging dock (sold separately).

You can also charge your speaker by placing it on a POWER UP charging dock (sold separately).

CHECK BATTERY LEVEL
SIMULTANEOUSLY PRESS the "+" / "−" button to check the battery level.

MAGIC BUTTON – LAUNCH PLAYLIST SETUP

- Search for and download the BOOM & MEGABOOM by Ultimate Ears app from the Apple App Store or Google Play Store. Please be sure to download the latest version of the app. BOOM 3 AND MEGABOOM 3 are only compatible with the BOOM & MEGABOOM by Ultimate Ears app.

BOOM & MEGABOOM by Ultimate Ears

Logitech Europe S.A.   Music & Audio

★ ★ ★ ★ 17,212 ♦

Everyone

This app is compatible with your device.

Installed

FOR ALL BOOM & MEGABOOM SPEAKERS

REFRESHED DESIGN

MEGA-BOOM 3

ONE TO YOUR PL

- These speakers will not work with the BLAST & MEGABLAST app by Ultimate Ears app.
- Connect your speaker via Bluetooth settings on your phone.
- Launch the app. Your speaker should show on the app's speaker list. If you have only one speaker, then the app will land directly on the speaker home screen.

- Tap the top, right gear icon to view speaker settings, and verify that your speaker's firmware is up-to-date. If not, then tap "Update Now" to update your firmware. Once the firmware is up-to-date, exit settings and return to the speaker home screen.

Once on the speaker home screen, tap the "Get Started" banner at the bottom to start setting up the Magic Button.

Select Spotify for your music service and follow the on-screen instructions for selecting your audio content.

When you are done selecting your audio content (e.g. playlists, albums, podcasts, songs, etc.), long press the magic button for 2 seconds to launch your selections.

The app does not recognise the speaker in iOS 13 After updating to iOS 13, you will need to allow the app to access Bluetooth. To do so, in your iOS Settings, go to your speaker's app settings and turn on the Bluetooth access.

In case you have installed the app after the iOS update, you will be prompted with a message requesting Bluetooth access for the app. In this case, just click on "OK" to give access.

MANUAL / QUICK START GUIDE

Connecting your speaker to your device
You can connect your BOOM 3 or MEGABOOM 3 to your smartphone, tablet or other device using the Bluetooth button. Out of the package, your BOOM 3 or MEGABOOM 3 is ready to pair with your first Bluetooth device. Here's how:

1. Turn the speaker on by pressing the power button on the top of the speaker. The power indicator will glow white, the Bluetooth connect button (above the power button) will blink white rapidly, and you will hear a tone indicating the speaker is ready to pair.

2. On your Bluetooth device, go to the Bluetooth menu and scan for devices (make sure Bluetooth is enabled).

3. Select BOOM 3 or MEGABOOM 3 from the list of devices. Once paired and connected, you'll hear an audible confirmation from the speaker. This means your BOOM 3 or MEGABOOM 3 is ready to use.

4. You can pair additional devices with your speaker, see Connecting your speaker to additional devices.

Connecting your speaker to additional devices
Your UE speaker will remember the last eight devices it connected with. Pairing additional devices After you pair

the first device, here's how to pair additional devices:

1. Turn the speaker on.
2. Hold down the Bluetooth button until you hear a tone. NOTE: The
3. The bluetooth connection button will blink rapidly, indicating that the speaker is ready for pairing.
4. On your device, go to the Bluetooth menu and scan for devices.
5. Select the name of your speaker from the list of devices.
6. Once paired and connected, you'll hear an audible confirmation from the speaker.
7. Your speaker is now ready to use with the device you added.

Reconnecting to a device
To reconnect a device to your Ultimate Ears speaker after the initial pairing or after pairing another device:

1. Turn the speaker on
2. On your device, go to the Bluetooth menu and select the name of your speaker from the list of devices.
3. Once reconnected, you'll hear an audible confirmation from the speaker. Your speaker is now ready to use with the device you selected.

Pairing/Grouping Speakers Together
PartyUp allows you to connect multiple speakers. To join the party, you'll need to get the BOOM & MEGABOOM by Ultimate Ears App and the latest firmware for your speakers first. Check the iOS App Store or Android Play Store for the latest app update. Once you have the latest app, you can update your speaker firmware through the app via OTA (over-the-air). Please ensure that all the speakers that you would like to join the party are up-to-date with the latest
firmware.
NOTE: If the guest speaker is not set as a public speaker, you will see a message with an extra step before that guest speaker can join the party. The owner of that speaker will need to press the Bluetooth button twice on the speaker.

What speakers can group with my speakers?
The following speakers can join the party:

- BOOM BOOM 2
- BOOM 3
- MEGABOOM
- MEGABOOM 3

To join the party, you'll need to get the latest and greatest App and firmware for your speakers first. Check the iOS App Store or Android Play Store for the latest app update. Once you have the latest app, you can update your speaker software through the app via OTA (over-the-air). Please ensure that all the speakers that you would like to join the party are up-to-date with the latest firmware.

Can I connect to my speaker via NFC?
No, BOOM 3 and MEGABOOM 3 don't support NFC pairing.

How to use the Magic Button
Standard music controls You can use the magic button to pause, play, or skip tracks for music you're currently playing from any music provider*:

- Pause: Single-press the Magic Button to pause music that is currently playing
- Play (Resume): Single-press the Magic Button to resume the music that you paused.
- Skip song/track: Double-press the Magic Button to skip to the next track of the current playlist
- One Touch To Your Playlist You can also use the magic button to directly access your playlists from select streaming music providers.
- To use this feature, you must set it up in the BOOM & MEGABOOM app (see Setting up the app)
- Play (first playlist): Long press — hold for 3 seconds — the Magic Button to start playing the first playlist you selected.
- Skip (to next playlist): Long press — hold for 3 seconds — the Magic Button to play the next playlist you selected.
- If the last playlist is playing, then the first playlist you selected will begin to play when you long-press the Magic Button.
- Pause/Play/Skip song in any of your playlists is the same as described above.

I can't connect to my device
If your Bluetooth device won't connect to your Ultimate Ears speaker, try the following:

- Make sure your speaker is turned on.
- Make sure your device is paired with your speaker and Bluetooth is active.
- Place your Bluetooth device closer to the speaker — it might be out of range.
- Move your Bluetooth device and speaker away from other wireless sources
- you could be experiencing interference.
- Turn your speaker off, and then back on again.
- If you have multiple speakers, make sure you're connected to the correct one.
  NOTE: If this is the first time you're pairing a device with your speaker, you don't need to press the Bluetooth connection button. It comes out of the box ready to pair.

Music drops out occasionally
If you're having trouble with audio distortion or drop-outs on your speaker, try these suggestions:

- Move the audio source closer — it might be out of the range of your speaker.
- Move away from other sources of wireless signal (microwave, routers, cordless phones, etc.) — you could be experiencing interference.
- Make sure your speaker has enough battery power (connect it to a power source with the supplied adapter).
- Adjust the volume on both the audio source and your speaker.
- Restart both your speaker and the audio source.
- Repair your device with your speaker.
  NOTE: If you're streaming audio content from the internet, the issue could be with the internet connection and not your speaker.

Setting up the app
To set up the app for your speakers:

1. Connect your speaker to your speaker to your smartphone, tablet, or any other device using Bluetooth. For help, see Connecting your speaker to your device.

2. Download the BOOM & MEGABOOM APP from the Google Play store or the App Store.

3. Once the app is installed, open your app. When the app is open, the first screen you will see is the screen with your speaker name, speaker image, the features available for your speaker, and access to speaker settings.
4. You are now ready to use the app to take advantage of all the features of your speaker.

One Touch To Your Playlists — BOOM 3 and MEGABOOM 3 only

1. On the first screen of the app (see step 3 above), you will see an action at the bottom to Get Started with One Touch To Your Playlist. The setup will allow you to choose playlists to directly access from the Magic Button of your speaker.
2. Read the tutorial and follow the on-screen instructions to select your playlist from Apple Music (iOS only) or Deezer Premium (Android Only). There is no limit to the number of playlists you can select.
3. Once setup is complete, you are now ready to access your selected playlists from the Magic Button of your speaker.
   NOTE: To access your playlist from the Magic Button of your speaker, please make sure that you've completed the setup of your playlists and that the app remains running and has access to the internet.

App features

The BOOM & MEGABOOM app by Ultimate Ears has everything you need to get the most out of your Ultimate Ears speaker. From #PartyUp to customizable EQ, unlock even more awesome ways to use your BOOM and MEGABOOM speakers.

- One App: Use one app to access speaker features for all BOOM and MEGABOOM speakers. Works with BOOM, BOOM 2, BOOM 3, MEGABOOM and MEGABOOM 3.
- One Touch To Your Playlists: BOOM 3 and MEGABOOM 3 only. Follow the on-screen instructions to select your playlist from Apple Music (iOS only) or Deezer Premium (Android Only).
- Remote On/Off: You'd never walk to your TV to turn it on and you shouldn't have to with your wireless speaker either. Use the app to turn your speaker on/off from afar.
- Alarms: Don't be late again. Choose your favourite music to wake up to.
- PartyUp: Pair up to 150 speakers for the ultimate sound experience. You can pair any BOOM or MEGABOOM together. To pair your speakers together, every speaker must be updated with the latest speaker Firmware (check the app to ensure your speaker has the latest firmware).
- EQ: You Control the Sound: Want to bump up the bass for your next party? Customize your beats in the app. You control the atmosphere with the recommended presets or customize the EQ to your listening preferences
- Speaker updates: When new software is available for your speaker, a simple tap in the app updates your speaker with the latest features in no time. Your speaker keeps getting better with the in-app updates.
- Much more: Personalize your speaker's name and customize EQ preferences. For BOOM 3 and MEGABOOM 3 preset Magic Button playlists.

New BOOM and MEGABOOM app
The new BOOM & MEGABOOM app by Ultimate Ears has everything you need to get the most out of your

Ultimate Ears speaker. From #PartyUp to customizable EQ unlocks even more awesome ways to use your BOOM and MEGABOOM speakers.

- Remote On/Off: You'd never walk to your TV to turn it on and you shouldn't have to with your wireless speaker either. Use the app to turn your speaker on/off from afar.
- PartyUp: Pair up to 150 speakers for the ultimate sound experience.
- You can pair any BOOM or MEGABOOM together. To pair your speakers together, every speaker must be updated with the latest speaker Firmware (check the app to ensure your speaker has the latest Firmware).
- Tap on the PartyUp icon on the tab bar to get your party started. Level up the party by connecting as many Ultimate

Ears speakers as you can handle!

- You'll find your available speakers in the drawer – simply drag & drop them onto the screen and get ready to turn up. Touch each speaker to see its name and make sure it's the right one.
- When someone's ready to go, you can drag their speaker back to the drawer and it's instantly out of your party and ready for something else. Or you can go old school and just turn the speaker off. It's up to you.
- Pro Tip: You can Party Up with BOOM, BOOM 2, BOOM 3, MEGABOOM and MEGABOOM 3. Just make sure each speaker is updated to the latest and greatest firmware, otherwise, they won't be able to join the party and no one wants to be left out.
- EQ: You Control the Sound: Want to bump up the bass for your next party? Customize your audio settings in the app. You control the atmosphere with the recommended presets or customize the EQ to your listening preferences.
- One Touch To Your Playlist: You can also use the magic button to directly access your playlists from select streaming music providers. To use this feature, you must set it up in the BOOM & MEGABOOM app (see Setting up the app)
- LONG PRESS TO LAUNCH PLAYLISTS Press and hold for 3 seconds.
- Your speaker will play the playlists you set.
- TAP ONCE TO PAUSE / PLAY When music is streaming on the speaker, tap once to pause/play the music.
- DOUBLE TAP TO SKIP When music is streaming on the speaker, tap twice on the button to skip the song.
- LONG PRESS AGAIN TO SKIP PLAYLISTS Long press again to skip the current playlist.
- **Alarm:** Don't miss an important appointment. You can set your alarm to go off daily or just once and play the music you choose.

Old BOOM and MEGABOOM apps

We removed the old MEGABOOM app from the App Store and Google Play Store. With the new BOOM & MEGABOOM app, you can control all of your Ultimate Ears BOOM, BOOM 2, BOOM 3, MEGABOOM, and MEGABOOM 3 speakers from one app now.

BOOM app: If you have auto updates set on your phone, you should automatically receive the newly updated app. If not, please go to the BOOM.

MEGABOOM app in the App Store (iOS) or Google Play Store (Android) and update your app.

MEGABOOM app: You will be prompted to download and install the new app. Once you have installed the new app, you will no longer be able to use the MEGABOOM app.

NOTE: BOOM (1st generation) users must update the speaker to the latest firmware using our Mac and PC update tool, to use the new app.

Alarms and Alexa

We are focusing on improving and streamlining our more actively used features in the app for a better overall user experience. Therefore, with the release of our newly designed app, we decided to retire the following features:

Alexa "Tap-to-Talk" (Android)

PartyUp out-of-the-box

To enable your speaker for PartyUp, please do the following:

- Exit pairing mode by either pairing to a source device or by long-pressing (holding for 3 seconds) the Bluetooth button on the speaker.
- After exiting pairing mode, your speaker should appear as an available speaker on the PartyUp screen.

How do I charge my speaker?

There are two ways to charge your speaker.

- Using USB
- Using the Power Up charging dock

Charging using USB

1. Open the sealed weather door on the back of your speaker to locate the micro USB port.
2. Plug a power adapter into the wall, connect the USB cable to the power adapter, and then connect the micro USB connector to the speaker.
3. A white LED next to the micro USB charging port will illuminate and pulse while the speaker is charging. Once it is fully charged, the LED will be solid white.

Charging using the Power Up charging dock

1. Connect your Power Up charging dock to a wall outlet using the included USB cable and a power adapter.
2. Place the speaker on the charging dock. Make sure you see the LED blinking to indicate that the speaker is properly charging. When the speaker is fully charged, the LED will stop blinking and stay ON.
3. Be sure that the micro-USB port and the charging ring at the bottom of the Speakers are both clean and dry before charging.

ONLY CHARGE WHEN CLEAN AND DRY.

WARNING! A wet or contaminated micro-USB connector may cause excessive heat or melting and may lead to fire damage or personal injury. Always charge your speaker with a clean, dry micro-USB connector.

Follow these instructions

- After the speaker has been exposed to water, dust, or similar elements, you must clean and dry the speaker's USB charging port before charging.
- For example, compressed air or a similar alternative may be used to clean and dry this charging port.
- If you use the Power Up charging accessory, ensure the following are clean and dry before charging:
    - The charging ring (on the bottom of your speaker)
    - The charging pins (on the top of Power Up)
    - The USB charging port (on the side of Power Up)
    - The included USB charging cable is not waterproof.
- Ensure that the cable's connectors are clean and dry before charging.

Can I use third-party charging adapters and cables to charge my speaker?
Yes. You can use third-party charging adapters and cables to charge your speaker. However, the charge time might vary depending on the power rating of the charging adapter. If you continue to have issues charging your speaker, please contact Customer Service.

Do I need to clean my speaker after using it in or around water?
Always thoroughly rinse and dry your speaker, micro-USB port and charging ring with fresh water after using it in a swimming pool or the ocean. While the speaker is waterproof, the chemicals and salt in your pool or the ocean can damage the waterproof seals over time if not rinsed off after use.

Are my speakers waterproof?
Your speaker is rated IP67. This means it can survive immersion in 1 meter or 3.3 feet for up to 30 minutes.

Can my speaker float?
Yes. BOOM 3 and MEGABOOM 3 float in water and are completely waterproof.

Can I use my speaker to make phone calls?
No, BOOM 3 and MEGABOOM 3 don't support voice calls.

Does my speaker have a voice assistant feature?
No, BOOM 3 and MEGABOOM 3 don't have a voice assistant feature.

Can I stream music through the auxiliary port?
No, BOOM 3 and MEGABOOM 3 don't have auxiliary ports.

Do BOOM 3 and MEGABOOM 3 support HFP and Speakerphone?
The new BOOM 3 and MEGABOOM 3 do not support Bluetooth HFP, so speakerphone functionality is unavailable for these products. Older BOOM products will continue to work with Siri and Google Voice.

Update using the app
Your ULTIMATE EARS speaker gets better all the time through regular, over-theair updates. These updates are quick and easy and can be wirelessly downloaded through your ULTIMATE EARS speaker app. To get started, connect your ULTIMATE EARS speaker to your smart device, open the app for your ULTIMATE EARS speaker, and tap on "More" to see if there are updates available. If there are, just tap to begin the update and the app will take care of the rest.

Update without the app
While it is quickest and easiest to update over-the-air with the app for your ULTIMATE EARS speaker, if you can't update using the app or you simply prefer to use an old-school desktop updater, we've still got you covered. Click on the Mac or Windows download link below to download the update utility. After you download the app, run it and follow the on-screen instructions. You'll need to connect your ULTIMATE EARS BOOM 3 to your computer to complete the update.
REQUIREMENTS: This update supports Windows 7 and above, Mac OS X (10.8.x) and above.

Download PDF: [Logitech BOOM 3 Super-Portable Wireless Speaker User Manual](#)

References

- **[User Manual](#)**